

OPERATING MANUAL

MODEL NO. 960 BUNGALOW

GAS FIRED HOT AIR BLOWER

TRACK SWITCH SNOW MELTER

WITH STEEL TIE DUCT

MANUFACTURED

BY

RAILWAY EQUIPMENT COMPANY

16400 MEDINA ROAD

PLYMOUTH, MINNESOTA 55447

TEL. 763-972-2200

FAX. 763-972-2900

E-Mail:

Support: Techsupport@rwy.com

Sales: Order@rwy.com



CAUTION

GENERAL HAZARD WARNING

FAILURE TO COMPLY WITH THE PRECAUTIONS AND INSTRUCTIONS PROVIDED WITH THIS HEATER, CAN RESULT IN DEATH, SERIOUS INJURY AND PROPERTY LOSS OR DAMAGE FROM HAZARDS OF FIRE, EXPLOSION, BURN, ASPHYXIATION, CARBON MONOXIDE POISONING, AND/OR ELECTRICAL SHOCK.

ONLY PERSONS WHO CAN UNDERSTAND AND FOLLOW THESE INSTRUCTIONS SHOULD USE OR SERVICE THIS HEATER.

IF YOU NEED ASSISTANCE OR HEATER INFORMATION, SUCH AS INSTRUCTION MANUALS, LABELS, ETC., CONTACT THE MANUFACTURER.



WARNING

WARNING: FIRE, BURN, INHALATION, AND EXPLOSION HAZARD.

KEEP SOLID COMBUSTIBLES, SUCH AS BUILDING MATERIALS, PAPER OR CARDBOARD, A SAFE DISTANCE AWAY FROM THE HEATER AS RECOMMENDED BY THE INSTRUCTIONS. NEVER USE THE HEATER IN SPACES WHICH DO OR MAY CONTAIN VOLATILE OR AIRBORNE COMBUSTIBLES, OR PRODUCTS SUCH AS GASOLINE, SOLVENTS, PAINT THINNER, DUST PARTICLES OR UNKNOWN CHEMICALS.



WARNING

NOT FOR HOME OR RECREATIONAL VEHICLE USE

The heater is designed and approved for use as a construction heater under ANSI Z83.7

We cannot anticipate every use which may be made of our heaters.

CHECK WITH LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT APPLICATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

PLEASE READ THIS INSTRUCTION MANUAL ENTIRELY BEFORE HANDLING THIS MATERIAL OR ATTEMPTING TO INSTALL, OPERATE OR SERVICE THIS HOT AIR BLOWER SYSTEM.

PLEASE READ THE WARNINGS AND CAUTIONS LISTED BELOW.




CAUTION

SHEET METAL EDGES MAY BE VERY SHARP AND CAN CAUSE SEVERE CUTS OR LACERATIONS. PROTECTIVE GLOVES AND CLOTHING SHOULD BE WORN. USE CAUTION WHEN HANDLING ALL SHEET METAL COMPONENTS.



CAUTION

THIS HOT AIR BLOWER TRACK SWITCH SNOWMELTER SYSTEM CAN BE OPERATED REMOTELY OR BY A SNOW DETECTOR SYSTEM. THEREFORE, OPERATION MAY BEGIN UNEXPECTEDLY. USE CAUTION WHEN IN THE AREA.



CAUTION

SYSTEM OPERATES WITH VARIOUS VOLTAGE LEVELS UP TO 240VAC. CONTACT WITH ELECTRICITY CAN BE HAZARDOUS OR LETHAL. MAKE SURE THAT THE MAIN CIRCUIT BREAKER IS TURNED OFF BEFORE ATTEMPTING TO SERVICE THIS SYSTEM. EVEN WITH CIRCUIT BREAKER OFF LINE VOLTAGE IS PRESENT AT THE TOP CIRCUIT BREAKER CONNECTIONS.



CAUTION

THIS SYSTEM CONTAINS A HIGH SPEED AIR FAN WHICH ROTATES AT UP TO 3600RPM AND CREATES FORCEFUL SUCTION WHEN OPERATING. DO NOT OPERATE THE BLOWER SYSTEM IF ANY OF THE DUCTWORK COMPONENTS HAVE BEEN REMOVED.



CAUTION

THIS SYSTEM OPERATES WITH NATURAL GAS OR PROPANE. BOTH ARE GASES WHICH ARE FLAMMABLE AND EXPLOSIVE. USE EXTREME CAUTION WHEN WORKING IN THE AREA. AVOID ANY OPEN FLAME, SPARKS OR OTHER SOURCE OF IGNITION.



CAUTION

THE OUTLET AIR TEMPERATURE FROM THIS GAS SNOW MELTER SYSTEM SHOULD NOT EXCEED 375°F FROM ANY NOZZLE OR DUCT. **DO NOT OPERATE THIS BLOWER SYSTEM IF THE OUTLET TEMPERATURE EXCEEDS 375°F.** AN ACCURATE THERMOMETER SHOULD BE USED TO REGULARLY CHECK THE OUTLET AIR TEMPERATURE. IF THE OUTLET TEMPERATURE EXCEEDS 375°F, CHECK TO MAKE SURE THAT THE FLOW OF AIR IS NOT RESTRICTED AT ANY POINT, THAT THE BLOWER/MOTOR ARE OPERATING PROPERLY, THAT THE CORRECT ORIFICE IS USED FOR THE TYPE OF FUEL USED, AND THAT THE REGULATOR(S) ARE PROPERLY ADJUSTED FOR THE FUEL BEING USED. CONSULT RAILWAY EQUIPMENT COMPANY IF YOU ARE UNABLE TO OPERATE THIS GAS SNOW MELTER SYSTEM BELOW 375°F.

A HIGH TEMPERATURE LIMIT SYSTEM HAS BEEN INCORPORATED INTO ALL RAILWAY EQUIPMENT COMPANY GAS SNOW MELTER SYSTEMS BEGINNING IN 1999. RAILWAY EQUIPMENT COMPANY ALSO HAS A HIGH TEMPERATURE LIMIT MODIFICATION KIT THAT CAN BE ADDED TO GAS SNOW MELTER SYSTEMS MANUFACTURED PRIOR TO 1999. IT IS RECOMMENDED THAT THIS HIGH TEMPERATURE LIMIT SYSTEM BE INSTALLED AND USED. CONSULT RAILWAY EQUIPMENT TO ORDER THE HIGH TEMPERATURE MODIFICATION KIT, OR IF YOU NEED ASSISTANCE REGARDING THE HIGH TEMPERATURE LIMIT SYSTEM.

THIS SNOW MELTER SYSTEM HAS BEEN DESIGNED TO PROVIDE DEPENDABLE EFFECTIVE OPERATION IN ALL WEATHER CONDITIONS **WITHOUT SWITCH COVERS**. SWITCH COVERS MAY CAUSE HIGHER AIR TEMPERATURES. IF SWITCH COVERS ARE USED, **YOU** MUST DETERMINE A SAFE OPERATING AIR TEMPERATURE AND ADJUST BURNER PARAMETERS ACCORDINGLY. ADJUSTMENT OF BURNER PARAMETERS MAY NEGATIVELY AFFECT BURNER PERFORMANCE AND COMBUSTION CHARACTERISTICS TO THE EXTENT THAT THE BURNER MAY BE UNABLE TO MAINTAIN COMBUSTION. CONSULT RAILWAY EQUIPMENT COMPANY REGARDING BURNER OPERATING PARAMETERS.

TWO (2) COMPLETE INSTRUCTION MANUALS HAVE BEEN INCLUDED WITH THIS SNOW MELTER SYSTEM. PLEASE KEEP ONE OF THE MANUALS WITH THE SYSTEM AFTER INSTALLATION. ANYONE OPERATING OR SERVICING THIS SNOW MELTER SYSTEM SHOULD READ THE MANUAL ENTIRELY BEFORE PROCEEDING.

IF YOU HAVE ANY QUESTIONS CONCERNING THE MANUFACTURE, DESIGN, FUNCTION, INSTALLATION, OPERATION OR MAINTENANCE, CONTACT RAILWAY EQUIPMENT COMPANY BEFORE PROCEEDING.


TABLE OF CONTENTS

I.	GENERAL INFORMATION	1
A.	MODEL NUMBER DESCRIPTION	1
B.	STANDARD FEATURES	1
II.	COMPONENT DESCRIPTION	3
A.	MAIN HAB UNIT	3
B.	STANDARD DUCTWORK	4
C.	OPTIONAL DUCTWORK	5
III.	INSTALLATION	7
A.	TIE DUCT	7
B.	MAIN HAB UNIT	8
C.	POINT NOZZLES AND TRACK DUCTS	9
D.	GAS CONNECTION	10
E.	CHANGING THE GAS ORIFICE	13
F.	ELECTRICAL CONNECTION	14
IV.	CONTROL MODULE	17
A.	DESCRIPTION	17
B.	SET-UP AND ADJUSTMENTS	18
C.	LED STATUS INDICATING LIGHTS	26
D.	OPERATION	27
E.	FAULT CONDITIONS	28
V.	SEASONAL MAINTENANCE	31
VI.	LOW PRESSURE REGULATOR ADJUSTMENT	32
VII.	TROUBLESHOOTING	33
A.	UNIT DOES NOT START	33
B.	UNIT DOES NOT MAINTAIN OPERATIONS	33
C.	LOW HEAT LEVEL	34
D.	LOW AIRFLOW	34
E.	GAS VALVE	34
F.	HIGH HEAT LEVEL	35
VIII.	SNOW DETECTOR	35
A.	INSTALLATION	35
B.	OPERATION	36
C.	MAINTENANCE	36
D.	TROUBLESHOOTING	37
IX.	SPECIFICATIONS	38

X. DRAWINGS	39
XI. LIMITED WARRANTY	40

I. GENERAL INFORMATION

A. MODEL NUMBER DESCRIPTION



B. STANDARD FEATURES OF 960 SERIES TRACK SWITCH HOT AIR BLOWER

1. GHAB complies with AREMA 12.6.10.
2. Gas fired operation, allows for both propane and natural gas (convertible in the field)
3. Two stage operation (400,000 / 200,000 BTU) that allows savings on fuel costs.
4. 2 H.P. direct drive motor, totally enclosed fan cooled, 230VAC 60Hz, single phase.
5. High efficiency, quiet operation , 2000 CFM blower.
6. Remote operation via contact closure (low voltage, low current) with timed shut off.
7. Built-in snow detector system (requires Snow Detector assembly option).
8. Auto-Off-Force switch.
9. High temperature limit thermostat/shut off.
10. Adjustable air temperature control.
11. Adjustable rail temperature control.
12. Reply indication via GHAB contact closure.
13. Fail indication via GHAB contact closure.
14. Main circuit breaker.
15. Audible tone before blower startup
16. Weathertight gasketed control enclosure

17. Status indicating lights for all control functions
18. Start delay timer for sequential startup
19. Run timer for timed operation
20. Selectable "Transparent" snow detector operation
21. Snow detect timer
22. All ductwork and nozzles are thermally and electrically isolated from tracks
23. Quick-release track duct
24. Blower motor starter with overload protection
25. Remote auxiliary gas valve (115vac) supplied connection
26. Gas line accessories:
 - Manual gas valve
 - Gas line strainer
 - Low pressure regulator
 - Flexible gas line connection pipe
27. Elevated air intake
28. Adjustable delay for start up (10 Sec. -5 Min.)
29. Complete flame safeguard control:
 - Pre-ignition air purge.
 - Air flow proving switch
 - Direct spark ignition
 - Flame proving sensor
 - Post shut off air purge 4 Min.
 - Automatic shut off on loss of flame or air flow
 - Leaky gas valve
 - Automatic retry on flame loss
 - Automatic reset on flame safeguard control
 - All flame safeguard controls CSA listed.
30. All components mounted and wired within main unit – no external wiring required except for remote control, indications and optional snow detectors
31. Galvanized case constructed of 14-gauge steel, high temperature baked enamel finish.
32. Convenient panel access to high efficiency burner, flame sensor and spark igniter.
33. Galvanized steel adjustable mounting foundations.
34. Standard ductwork: 1.5' flame duct with 2.5' straight insulated flexible duct and heavy duty insulated offset duct connects to main tie duct electrically insulated between rails, 24 inch (minimum) switch point nozzles.

The following items are recommended for use with propane gas service:

Tank "pigtail" with POL/POL fittings (P/N 45038-12" or 60127-36")

High pressure regulator (P/N 45103)

Gas line strainer (P/N 45040)

Remote solenoid valve (P/N 45036)

OR

Complete Propane Package (P/N 9458-0100)

II. COMPONENT DESCRIPTION

A. MAIN HOT AIR BLOWER (HAB) UNIT

- 1. MAIN CIRCUIT BREAKER:** Provides main over-current protection and manual on-off control of electrical power
- 2. MOTOR CONTACTOR:** Provides automatic blower motor control, with high current contacts
- 3. MOTOR OVERLOAD RELAY:** Protects the blower motor from an over-current condition
- 4. CONTROL MODULE:** Provides complete control of operation. See separate description and details, section IV
- 5. CONTROL TRANSFORMER:** Provides control power for the control module and other control components. The multi-tapped secondary provides, 36VAC CT and 17VAC CT. The primary has 115VAC input plus a 230VAC step-up winding and 12.6 VAC CT windings
- 6. IGNITION TRANSFORMER:** Provides 10000VAC to the spark igniter during the ignition sequence
- 7. AIRFLOW SWITCH:** Located in the flame duct, the sail switch indicates proper airflow before and during burner operation. The differential setting is determined by elevation.
- 8. BURNER:** Contains the actual flame. Also holds the spark igniter and the flame-sensing rod.
- 9. PROPANE/NATURAL GAS ORIFICE PLATE:** Controls the rate of flow of gas to the burner.

10. **SPARK IGNITER:** The spark plug type igniter provides spark for the burner. The spark igniter is momentary - sparks only until the flame has been established.
11. **FLAME DETECTION ROD:** The flame detection rod monitors the flame at the burner nozzle using the rectification principle. This provides a low-level signal to the control module if a proper flame exists.
12. **AIR TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the ambient air temperature.
13. **RAIL TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the actual rail temperature.
14. **GAS VALVE:** This is an electric solenoid valve which controls the flow of gas for burner operation. It is controlled directly from the control module.
15. **BLOWER MOTOR:** The 2HP 3450RPM motor is totally enclosed and fan cooled.
16. **BLOWER:** The high efficiency blower wheel provides up to 2000CFM airflow. It is dynamically balanced for smooth and quiet operation.
17. **BUZZER:** The buzzer will sound a 10-second tone immediately before the motor contactor is energized.

B. STANDARD DUCTWORK

1. **HEAT DUCT:** The first section of ductwork attached to the main HAB unit. This duct contains the burner, air flow switch, spark igniter and the duct pressure sensor
2. **FLEX DUCT:** Connects the heat duct to the offset duct. It is a section of flexible duct, 30" long, enclosed in an insulated sheet metal wrapper.
3. **HEAVY DUTY OFFSET DUCT:** Connects the flex duct to the tie outlet duct. This duct provides an 8" offset and encloses the air mixer.
4. **TIE OUTLET DUCT:** The outlet duct extends under the rails in place of a tie and directs the airflow to the point nozzles and track ducts. The rail attaches to the duct using tie plates and E clips. The tie plates are electrically insulated from the rail using an insulating kit. There are six openings in the top for point nozzles and track duct

nozzles. Refer to drawing 9278-4804 and 950N32903 for the duct layout.

5. **TRACK DUCTS:** These ducts rest on brackets on the ties and the outlet duct. They are installed over the track duct nozzles. The track ducts consist of a 5' point, a 5' mid, and 10' sections to complete the desired length.
6. **TRACK DUCT NOZZLE:** Attaches to the inner two rectangular openings on the top of the outlet duct. Directs airflow down the length of the switch through the track ducts.
7. **TRACK DUCT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0027 for proper installation.
8. **TRACK DUCT SUPPORT BRACKET:** These brackets are used to secure the track duct in position. Refer to drawing 92774.
9. **SWITCH POINT NOZZLE:** These nozzles direct heated air down the switch point. They are mounted on the outlet duct. They can be adjusted for proper airflow direction. Nozzles may be shortened by up to 10" for proper fit.
10. **POINT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0021 for proper installation.

C. OPTIONAL DUCTWORK

1. **EXTENSION DUCTS:** Extension ducts of various lengths are available to meet specific requirements. These are insulated and enclosed in a metal wrapper. Make sure the duct is mounted in the correct orientation, as there is an access opening underneath the insulating wrapper cover. If additional duct extensions are required, this assembly can be added between the outlet duct and the offset duct.
2. **7' TRACK DUCT:** These track ducts are seven feet long. They are often mounted outside of the track near the switch machine. A kit is available (P/N 9278-0270) that includes a 7' track duct, a track duct nozzle and a track duct isolation kit.

OTHER DUCTWORK ASSEMBLIES ARE AVAILABLE. CONSULT THE FACTORY FOR SPECIAL DUCTWORK NEEDS.

(INTENTIONALLY LEFT BLANK)

III. INSTALLATION

INSTALLATION SHOULD BE DONE IN THIS ORDER:

- A. TIE DUCT OUTLET DUCT/OFFSET DUCT
- B. MAIN HAB UNIT/FLEX DUCT
- C. POINT NOZZLES AND TRACK DUCTS
- D. GAS
- E. CHANGING THE GAS ORIFICE
- F. ELECTRICAL

PLEASE READ THROUGH THE ENTIRE INSTRUCTIONS BEFORE BEGINNING INSTALLATION.

A. TIE DUCT

1. Remove the appropriate tie. Choose the tie that will result in the point nozzles being as close to the switch point as possible without interfering with normal switch operation. The distance from the center of the tie duct to the end of the point nozzles is 33". If necessary, up to 10" may be cut off each point nozzle.
2. Remove sufficient ballast to provide at least 14" clearance from the bottom of the rails.
3. Carefully slip the tie duct under the rails and position it so that the rails are directly above the tie plates. Ensure that the tie duct is centered between the adjacent ties.
4. Place a rubber pad on the tie plate, then using a suitable lever, raise one end of the tie duct until the rail lies correctly on the pad on the tie plate. Place two e-clip insulators, one on each side of rail, in place and then fasten the rail to the tie plate using two of the four 927248 rail clips. Use a heavy hammer or maul to drive the clips securely into place.
5. While keeping the tie duct supported in place, firmly pack ballast under the tie duct from the rail out to the end.
6. Repeat steps 4 and 5 for the other end of the tie duct.
7.
 - a. Remove the end flange plate nearest the HAB by loosening the six retainer bolts.
 - b. Install the two-foot heavy duty offset duct (P/N 9278-3403) to the tie duct using hardware and gasket supplied with the offset duct.
8. Firmly repack ballast under the entire tie duct.

B. BUNGALOW PLACEMENT

1. Attach the 2' flex duct (P/N 9528-4222) to the flame duct using the bolt and gasket kit from the flame duct.
2. Attach the 2' offset duct (P/N 9528-3103) to the flex duct on the flame duct, using the bolt kit from the offset duct.
3. Position the bungalow to line up with the 2' heavy duty offset duct and the 2' offset duct (Refer to Drawing #960n36964).
4. Connect the heavy duty offset duct to the flex duct using the bolts and gasket provided with the offset duct and level the bungalow.
5. Adjustable Air Intake. To start the GHAB in a new location, set the intake screen in the closed position. If there proves to be a moisture problem where frost builds up on the intake screen, the screen can be set in the open position to improve the air intake to the GHAB.
6. The airflow switch differential setting is factory set on "D" which is for elevations below 2000 ft. If your location is set at a higher elevation, this differential setting will need to be adjusted. Adjust per the following instructions:
 - a) Remove the galvanized cover over the airflow switch.
 - b) Remove the cover from the airflow switch.
 - c) Adjust the differential wheel on the base of the airflow switch as follows:

Below 2000 ft elevation, set Airflow Differential Wheel to "D"

Below 4000 ft elevation, set Airflow Differential Wheel to "C"

Below 6000 ft elevation, set Airflow Differential Wheel to "B"

Above 6000 ft elevation, set Airflow Differential Wheel to "A"

C. POINT NOZZLES AND TRACK DUCTS

REFER TO DRAWING 960K32902 FOR TRACK DUCT AND POINT NOZZLE POSITIONS.

1. Attach switch point nozzles to the openings in the outlet duct. Position nozzles for proper airflow direction. Instructions are included in the isolation kit (P/N 9278-0021) used with the point nozzles.
2. Attach track duct nozzles to the outlet duct, observing airflow direction. Refer to instructions included with the isolation kit (P/N 9278-0027).
3. Assemble the individual track duct sections into two complete track duct sections. The mid and heel sections contain splices wrapped around the outside of the duct. Unhook the clips to remove the three cover pieces. The bottom can now be removed from the duct.

To assemble the splice:

- a. Center the bottom splice piece on the seam between the two track ducts.
 - b. Connect the center cover piece over the seam. (NOTE: The center cover piece has slots to contain the bolts on the track duct).
 - c. Finally connect the two end cover pieces.
4. Lay the track ducts on the rail ties alongside where they will be installed.
 5. Refer to the drawing 92774. Place the track duct support brackets in position on the ties so that one is near the heel end and one near each joint. Use the lag bolts to fasten the brackets in place. Lay the track duct on the bracket bases. Place the hold-down straps over the track ducts. Attach the hold-down strap to the track duct support brackets by inserting the spring clip into the strap.
 6. Push in the square knockouts in the track ducts where airflow is desired. The knockout should be pushed in and bent completely so that no portion of the knockout obstructs the airflow in the duct. Knockout tabs that are not bent back completely will obstruct the airflow as it moves through the track duct resulting in reduced air pressure and airflow further along the track duct.
 7. Inspect the track duct nozzles for proper operation. The damper plate should rotate without binding. Ensure that the damper plate is in the proper position, then tighten the locking nut. Ensure that the damper plate is locked firmly in place.

D. GAS CONNECTION



CAUTION

When tightening gas line fittings or components to the HAB unit be sure that you do not rotate the pipe that enters the blower unit. This could cause the gas control valve inside the blower unit to rotate also. Please reference the label attached just above the pipe that enters the blower unit

1. The following items are shipped in a carton marked "GAS LINE ACCESSORIES", along with various pipe fittings, so that they may be arranged to fit the particular installation. Refer to Instruction Sheet R9500-0027 included with Gas Line Accessories for the proper placement of these components.

Flexible pipe (P/N 61052)

Y strainer (s) (P/N 45040)

Manual shutoff valve (P/N 45017)

Low pressure regulator (P/N 45047)

Spring RED (P/N 45142)

2. The following items are available as optional items
 - * High pressure regulator (P/N 45103)
 - * 36" Gas tank "pigtail" (P/N 60127)
 - * 12" Gas tank "pigtail" (P/N 45038)
 - * Remote gas valve (P/N 45036)

NOTE: A propane package is available (P/N 9458-0100) that includes a 36" tank pigtail, high pressure regulator, gas line strainer, gauge, remote solenoid valve in a pole mount enclosure, and a 4X4X8' post.

FOR NATURAL GAS INSTALLATION PROCEED TO STEP 5

3. *Install the copper "pigtail" to the propane tank. Each end of the pigtail is a reverse thread.
4. *Install the high pressure (red) regulator to the pigtail. Remember reverse thread on the pigtail connection.
5. Install the "Y" strainer downstream (but near) the high pressure regulator, or natural gas source.

6. *Install the remote gas valve downstream (but near) the "Y" strainer. Electrical connections from the remote gas valve are made to terminal posts TS1-10 (115vac) and NEUTRAL on the HAB unit. The valve must be mounted with the inlet and outlet horizontal, and the coil upwards.
7. Install adequate size gas pipe from the remote tank location to the main HAB unit. Check with local gas supplier for sizing recommendations.
8. The remaining gas line components are attached to the HAB unit, as shown on drawing R9500-0027. Remember to position the regulator vent fitting facing sideways so that moisture will not enter the regulator.
9. If you are having problems adjusting the gas pressure low enough, the spring in the low pressure regulator must be changed. To change the spring, complete the following steps:
 - a. Try adjusting the low pressure regulator for proper fuel pressure. If it can't be adjusted, follow instructions listed below for changing the regulator spring.
 - b. Turn power off and close manual gas valve.
 - c. Remove the plug on top of the regulator.
 - d. Turn the white plug inside the regulator counter-clockwise until it can be removed.
 - e. Replace the violet spring with the red spring provided in the gas accessory kit.
 - f. Replace the top plug.
 - g.
 1. Go to gas pressure menu to adjust.
 2. Turn the manual gas valve to "ON" position and turn power on.
 3. Place the AUTO/OFF/FORCE switch (SW1) in the "FORCE" position.
 5. Place the burner control select in the hi-only position.
 6. After the 30-second pre-purge period, the unit will ignite. Check the pressure gauge. Adjust the white

plug in regulator until the display reads 11" water column for propane or 7" water column for natural gas.
NOTE: Clockwise to increase pressure, counter-clockwise to decrease pressure.

7. Let the GHAB run for a 10 minute period.
 8. After the 10 minute period, take temperature readings at both point nozzles.
 9. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
 10. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1" w.c. at a time) until you reach the desired temperature.
- h. Replace the top plug.

* OPTIONAL ITEMS AVAILABLE FROM RAILWAY EQUIPMENT CO.

(INTENTIONALLY LEFT BLANK)

E. CHANGING THE GAS ORIFICE

1. This unit uses an orifice plate instead of individual orifices. The orifice plate contains the orifices for both propane and natural gas for both stages of operation.

CAUTION

2. Make sure the main circuit breaker is in the **OFF** position and the manual gas valve is closed before working on the HAB unit.
3. Remove the bottom intake cover from the HAB unit.
4. On the right hand side of the gas assembly you will see the orifice plate. The orifice plate has a tab facing out that says NG for natural gas or LP for propane. This will tell you how the unit is currently set up.
5. To change from one fuel to the other:
 - a. There are four bolts on each gas coupling plate. You need to fully remove the top two bolts on each coupling plate and you need to back out the bottom two bolts on each coupling plate 1/2 to 3/4 of an inch.
 - b. On the inlet manifold (left hand side of the gas assembly) you need to remove the two bolts securing the manifold to the outside of the GHAB.
 - c. You can now carefully slide the gas assembly to the left to free the orifice plate.
 - d. The orifice plate can be pulled away from the outlet manifold and up and out. NOTE: Take care removing the orifice plate so you don't damage the O-rings.
 - e. The orifice plate can now be flipped over for the other fuel and re-inserted in between the gas coupling and outlet manifold. NOTE: Take care replacing the orifice plate so you don't damage the O-rings.
 - f. Slide the gas assembly back to the right and insert the top bolts on the coupling plates.
 - g. Verify the tab facing out on the orifice plate is now the correct fuel.
 - h. Evenly tighten the eight bolts on the coupling plates.
 - i. Replace the bolts on the inlet manifold bracket (outside of GHAB).
 - j. Re-install the lower intake cover.
6. Turn on power and manual gas valve.
7. Test unit and check regulator adjustment and output temp.

F. ELECTRICAL CONNECTION

1. There are knockouts on the side and bottom of the control enclosure for incoming electrical wires.



CAUTION

THE 230VAC SUPPLY LINES SHOULD BE SIZED TO ALLOW FOR THE AC MOTOR START-UP CURRENT WHICH IS 78 AMPS. UNDERSIZED CONDUCTORS OR LONG WIRE RUNS COULD DAMAGE THE MOTOR.

2. **INCOMING POWER:** The incoming power should be connected directly to the main circuit breaker. The neutral should be connected to the neutral lug TS1-N. The neutral should be grounded at the source.
3. **GROUND:** The chassis ground TS1-G should be tied directly to earth ground.

SPECIAL NOTE: THE CONTROL CHASSIS AND THE REST OF THE MAIN HAB UNIT MUST BE CONNECTED TO GROUND/NEUTRAL. THE RUBBER PAD BETWEEN THE RAIL AND TIE PLATE ALONG WITH THE E-CLIP INSULATORS WILL INSULATE THE MAIN UNIT FROM THE TRACKS.

4. **CONTROL INPUT:** Remote operator control can be provided by a circuit closure applied between terminal posts TS1-1 and TS1-2.
5. **INDICATION:** Reply indication can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-3 and TS1-4 will provide a dry contact closure for indication when the unit is operating under remote control.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC indication is now present on post TS1-3 with common at terminal post TS1-6.
6. **FAIL:** Reply fail can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-5 and TS1-4 will provide a dry contact closure for fail when the unit is in a fault mode.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC fail is now present on post TS1-5 with common at terminal post TS1-6.
7. **DUCT WORK OVERTEMP SENSOR (P/N 9338-0355):**
 - a. On the tie duct remove the two bolts holding down the overtemp sensor cover nearest the HAB unit. Install the sensor onto the duct work using the two bolts that were removed.
 - b. Run conduit along duct work back to HAB enclosure; connect connector to enclosure knock out; tighten. (NOTE: Cut conduit to length if needed.)
 - c. Run wires from sensor into enclosure and plug connector into

OVERTEMP (RED) J10 located on the control module.

- d. Use five clamps (P/N 60030) to secure conduit to the side of duct work using existing screws.

**8. RAIL TEMP SENSOR (P/N 9228-0615)115# rail:
(P/N 9228-0616)136# rail**

- a. Attach the sensor to the outside web of the stock rail approximately four feet ahead of the point nozzle. Use spring clips to attach to rail.
- b. Run wires from sensor into enclosure and plug connector into RAIL TEMP (YELLOW) J11 located on the control module.

IV. CONTROL MODULE

A. DESCRIPTION

The hot air blower control module contains all of the elements and functions necessary for advanced snow melter operation. The unique dual-chip microcomputer has been programmed with logic and timing sequences to provide complete heater control as well as operational control and system interface. Some of the many features included in the control module are:

- Auto-Off-Local selector switch
- Adjustable air temperature setting
- Built-in snow detector (Requires Optional Snow Detector Head)
- Adjustable start-up delay sequence
- Adjustable run timer for timed or continuous operation
- Adjustable snow detect timer for use with optional snow detector
- Operator control and indication
- Remote fault reset
- Audible tone before blower start-up
- Input/output status indication lights:
 - Inputs:
 - Air temperature
 - Remote Control
 - Moisture Detector One or two snow detector(s) (Optional)
 - Airflow switch
 - Flame Sensor
 - Rail Temp Sensor
 - High Temp Sensor
 - Outputs:
 - Blower motor
 - Ignition spark
 - External Gas Valve
 - Hi Gas valve
 - Low Gas valve
 - Indication
 - Fail
- Flame safety control:
 - 10 second tone before blower turn on
 - Air flow proving
 - 30 second pre-purge before ignition
 - Direct spark ignition
 - 10 second maximum ignition period before lock-out
 - Rectification type flame rod sensor
 - Automatic retry on flame loss
 - 4 minute post-purge period after gas valve turn-off
 - Automatic reset
 - Fault if flame does not go out after gas valve is commanded off

B. SET-UP AND ADJUSTMENTS: To change settings and adjust times do the following:

Mode Up Push Button

Pushing the Mode Up push button (PB2) will cycle up through the menus. Each time you press the mode up push button you will advance one menu selection.

Mode Down Push Button

Pushing the Mode Down push button (PB3) will cycle down through the menus. Each time you press the mode down push button you will move down one menu selection.

Increase Values

The Increase Values push button (PB4) allows you to increase the values.
NOTE: Values will be saved.

Decrease Values

The Decrease Values push button (PB5) allows you to decrease the values.
NOTE: Values will be saved.

The following is the layout of the controller menu:

Controller Menu

The controller has 6 menus categories, they are:

1. Status
2. Fault History
3. Set Points
4. Factory Defaults

Menu Selection

To select the desired menu, press the Mode Up or Down button until *******MENU SELECT******* is displayed, on line 1, and then use the Increase or Decrease Value button to select the appropriate menu. Once the appropriate menu is selected, use the Mode Up or Down buttons to view the contents of the menu.

NOTE: Use the Increase or Decrease Values button to change setpoint values.

STATUS MENU

- 1. OUTSIDE TEMP AND PRESET VALUE**
Displays the current ambient temperature and temperature preset value. If ambient temperatures is below the preset value, the unit will start if requested.
- 2. MOTOR CURRENT AND MOTOR VOLTAGE**
Motor current displays the actual motor current in amps while motor is running. Motor voltage displays the actual motor voltage in volts while motor is running.
- 3. GAS PRESSURE AND DUCT PRESSURE**
Gas pressure is the actual differential pressure at the burner. The unit of measure is inches of water ("H2O). To view gas pressure, the burner should be burning. The correct setting should be 11"H2O for propane, be 7"H2O for natural gas. While adjusting, the burner should be in high only. Adjust regulator to change gas pressure value. Duct temperature is the actual duct temperature in degrees F or C.
- 4. FLAME CURRENT**
Flame current displays the actual flame current in micro amps while a flame is present.
- 5. RAIL TEMP AND DUCT TEMP**
Rail temperature is the actual rail temperature in degrees F or C. Duct temperature is the actual duct temperature in degrees F or C.
- 6. AC FREQUENCY**
Displays the frequency of the line voltage.
- 7. TOTAL GAS AND RESET GAS**
Total gas displays the calculated amount of gas that has been used. The unit of measure is gallons if propane is selected. The unit of measure is cubic feet if natural gas is selected. Reset gas is the same as total gas except it can be reset. To reset, press the decrease value button.
- 8. HOUR METER AND RESET HOUR**
Hour meter displays the total hours that GHAB has been running. Reset hour is the same as hour meter except it can be reset. To reset, press the decrease value button.
- 9. TANK LEVEL, BAT AND TEMP**
Tank level displays the actual level of propane tank in percent full (optional tank level monitor must be installed). Bat displays the battery level of the tank monitor. Temp displays the temperature in the battery monitor.

FAULT HISTORY MENU

NOTE: Some faults may not show in Fault History until there is an actual fault.
Press the decrease or increase value button to reset fault count.

- 1. FLAME LOSS AND FLAME ON**
Flame loss counter is total count of flame loss faults. Flame on counter is total count of flame on faults.
- 2. SAIL LOSS AND SAIL ON**
Sail loss counter is total count of sail loss faults. Sail on counter is total count of sail on faults.
- 3. MOTOR V FAULT AND OVERLOAD**
Motor volts low or high counter. Overloads counter is total motor overloads faults.
- 4. GAS VALVE LEAK AND PRESSURE FAULT**
Gas valve counter is total count of leaking gas valve faults. Gas pressure low or high counter.
- 5. DUCT PRESS FAULT AND VAP. PRESS LOW**
Duct pressure fault counter is total count of duct pressure faults. Vaporization low fault counter is total count of vaporization low faults.
- 6. MOTOR CURRENT AND COMM RESET**
Motor current fault is total count of motor current faults. Comm reset fault is total count of communication reset faults.
- 7. DAY COUNTER AND POWER UP**
Day counter is the number of days the unit has been powered up. Power up counter is the total number of times the control module has been turned on.
- 8. OVER TEMPS WARNING COUNTER**
Counts the total number of Over Temp warnings.
- 9. AUTO OVERTEMP RESET COUNTER**
Counts the total number of times the Over Temp was reset.

SET POINTS MENU

1. USER LEVEL

The options are BASIC and ADVANCED.

Basic – access to basic menus.

Advanced – access to advanced menus (requires password).

2. PASSWORD

A password is needed to access the advanced menus. To enter in the password, use the increase or decrease value buttons. Password 5 allows advanced menu items to be changed.

3. SELECT TEMPERATURE SETPOINT

The ambient temperature below which the unit will energize is set on this screen. When the outside temperature is below this setpoint, the unit will be allowed to operate if requested. The factory default is 38° F (3° C). The range is from 0° F to 100° F (-18° C to 38° C).

4. SELECT RUN TIMER VALUE

The run timer can be set from 0 to 1000 minutes. If zero is selected, the outputs will operate continuously, until control on is disabled. If another value is selected, the unit will run until the run timer counts down to zero, after which the unit will shut down and drop indication. The unit can be restarted by removing the contact closure between TB2-1 and 2, then reinstalling it. If Run Timer Pulse Mode is activated, the minimum run time value is 10 minutes. The factory default setpoint is 60 minutes.

5. RUN TIMER PULSE MODE

The choices are on or off, factory default is off. When on is selected, a pulse will start run time sequence and continue until run timer has timed out. When off is selected, run timer will time out as long as remote is on. When remote on is removed blower will stop.

6. SELECT SNOW TIMER VALUE

The snow timer can be set from 10 to 1000 minutes. The snow time starts counting down when the moisture detector no longer sees snow. The factory default setpoint is 60 minutes.

7. SELECT SNOW SENSOR SPEED

Snow sense speed sets the delay time after the moisture detector sees moisture and starts the snow cycle. The delay time can be set from 1 to 60 seconds. The moisture sensor must see moisture for entire time to start cycle.

8. SELECT SNOW INDICATION

The choices are OFF or ON. With snow indication off, indication will remain off during snow time if no faults are present. With snow indication on, indication will remain on during snow time if no faults are present.

9. SELECT START DELAY VALUE

The start delay timer can be set from 0 to 250 seconds in 10 second increments. It is used to delay the start of GHAB so when several blowers are at the same location they do not start at same time.

10. SELECT BURNER OPERATION

The choices are LOW, HIGH, AUTO, AUTO OFF.

Hi Only – 100% BTU output with or without Rail Sensor.

Low Only – 50% BTU output of Hi with or without the rail sensor.

Auto – Switches between high and low dependant on the rail & duct temperature sensor and setpoint. Note: If no rail sensor is connected, it will run at low (50% output). Units with only single stage installed, should select high only.

Auto Off – When rail temperature reaches the rail temp setpoint, the GHAB will shut down. When the rail temperature lowers to the ambient temperature setpoint, the GHAB will start again.

11. OPERATION MODE

The choices are NATURAL, PROPANE, COLD AIR, COLD AIR/PROPANE, COLD AIR/NATURAL.

NATURAL – The GHAB's burner is fueled by natural gas.

PROPANE – The GHAB's burner is fueled by propane.

COLD AIR – The GHAB will turn its blower on with air temperature. It will not use a burner.

COLD AIR/PROPANE –The GHAB will turn its blower on with air temperature. It will then turn its propane burner on with moisture or control.

COLD AIR/NATURAL –The GHAB will turn its blower on with air temperature. It will then turn its natural gas burner on with moisture or control.

12. SELECT MOTOR SIZE

The choices are:

2 HP 230V 1PH, 3 HP 230V 1PH, 5 HP 230V 1PH,
2 HP 460V 3PH, 3 HP 460V 3PH, 5 HP 460V 3PH,
2 HP 575V 3PH, 3 HP 575V 3PH, 5 HP 575V 3PH,
2 HP 3PH Drive, 3 HP 3PH Drive, 5 HP 3PH Drive
2 HP 230V 3PH, 3 HP 230V 3PH, 5 HP 230V 3PH.

- 13. RAIL TEMP SETPOINT**
This can be set from 0° F to 280° F (-18° C to 138° C).
- 14. DUCT TEMP SETPOINT**
This can be set from 150° F to 250° F (66° C to 121° C).
- 15. DUCT PRESSURE HIGH SETPOINT**
This can be set from 3" H2O to 30" H2O.
- 16. DUCT PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 5" H2O.
- 17. GAS PRESSURE HIGH SETPOINT**
This can be set from 7" H2O to 30" H2O.
- 18. GAS PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 10" H2O.
- 19. MOTOR CURRENT HIGH SETPOINT**
This can be set from 5 to 100 amps.
- 20. MOTOR CURRENT LOW SETPOINT**
This can be set from 0 to 10 amps.
- 21. MOTOR VOLTAGE HIGH SETPOINT**
This can be set from 250 to 650 volts.
- 22. MOTOR VOLTAGE LOW SETPOINT**
This can be set from 150 to 550 volts.
- 23. AC FREQUENCY HIGH SETPOINT**
This can be set from 0 to 100 Hz.
- 24. AC FREQUENCY LOW SET POINT**
This can be set from 0 to 100 Hz.
- 25. LOCAL WITH/WITHOUT AIR TEMPERATURE**
Sets the local feature to, or not to, be dependant on the air temperature.

26. OVERTEMP BYPASS

With overtemp bypass enable, the unit will not fault if the overtemp sensor is missing. This feature is only for use on units that have a two wire overtemp sensor. Current production units are equipped with a four wire overtemp sensor. **NOTE: BYPASSING THE OVERTEMP SENSOR MAY CAUSE HARMFUL OPERATING CONDITIONS.**

The following steps are required to bypass the overtemp sensor:

a) Display: MENU SELECT
SETPOINTS

b) Select: ADVANCED

c) Enter password: 10

d) Display screen: OVERTEMP BYPASS
DISABLED

e) Change to: ENABLED

27. SELECT F OR C

Will change the temperature scale to either Fahrenheit or Celsius.

28. AUTO OVERTEMP RESET

Auto overtemp reset will reset the overtemp once it has been triggered.

29. SELECT TANK SIZE

The choices are no tank sensor, tank heater, 250 gallon increments up to 5,000 gallons. No tank sensor should ALWAYS be selected UNLESS a tank sensor reporting to the module is installed. Note: Tank Size menu is only available if propane is selected.

30. TANK SERIAL #

Tank serial # is the tank level monitor's serial number. This is only used if a tank sensor reporting to the module is installed.

31. MACHINE SERIAL NUMBER

Machine serial # is the serial number of the whole GHAB unit.

32. SERIAL NUMBER/MAC

Shows the MAC address for the unit.

33. AMBIENT OFFSET

Used to calibrate the ambient temperature sensor.

- 34. **RAIL OFFSET**
Used to calibrate the rail temperature sensor.
- 35. **DUCT OFFSET**
Used to calibrate the duct temperature sensor.
- 36. **PROG REV AND DATE**
Shows the program revision and the date it was compiled.
- 37. **BOOTLOADER**
The choices are DO NOT RUN BOOTLOADER, START FACTORY DEFAULT BOOTLOADER and START NEW CODE.
 - DO NOT RUN BOOTLOADER** – Will not run the bootloader.
 - START FACTORY DEFAULT BOOTLOADER** – Will run the factory bootloader.
 - START NEW CODE** – Will download and run the new code.

FACTORY DEFAULTS MENU

Factory default is used to place all parameters back to factory default settings.

To restore to factory default:

In the menu selection, select FACTORY DEFAULTS and then press either the up or down mode button. Next press either the increase or decrease value button to restore to default.

AUTO/OFF/LOCAL SWITCH (SS1)

- a) **AUTO:** This position will allow operation by placing a circuit closure across terminal posts 1 and 2. It will also allow operation by an optional snow detector.
- b) **OFF:** If off, GHAB cannot be run from remote or snow detector.
- c) **LOCAL:** If LOCAL without air temp parameter is enabled, placing SS1 in the LOCAL position enables the snow melter regardless of outside air temperature. The snow melter will remain on until LOCAL is turned off. This is useful for hot weather testing.

C. LED STATUS INDICATING LIGHTS

1 AIR TEMPERATURE:

On when the ambient air temperature is below set point.

2 MOISTURE:

On when the optional snow detector sensing head(s) senses moisture.

3 CONTROL:

On when there is a circuit closure across terminal posts 1 and 2.

4 BLOWER:

On when the controller has turned on the output to the blower motor contactor.

5 AIRFLOW:

On when the sail switch in the air stream is sensing adequate airflow.

6 IGNITION:

On when the controller has enabled the output to the ignition transformer.

7. HIGH GAS VALVE:

On when the controller has enabled the output to the high gas valve.

8. LOW GAS VALVE:

On when the Controller has enabled the output to the Low Gas Valve.

9 FLAME:

On when the flame sensing determines that there is proper combustion.

10. INDICATION:

On when there is a circuit closure across terminal posts 1 and 2 and the unit is operating, or the air temperature is above the set point. Also may be on when there is a fault condition under snow detector.

11. FAIL:

This LED is on when ever a fault is present.

D. OPERATION

With switch SS1 in the “auto” position, the unit can be activated by applying a circuit closure between terminals TS1-1 and 2. If the outside temperature is above set point the unit will not start a snow melt sequence but will turn on the “indication” LED and provide a relay contact closure between TS1-3 and 4 to indicate to the remote station that the unit is operational.

If a circuit closure exists between TS1-1 and 2, and the air temperature is below set point. the unit will begin a snow melt sequence. The unit executes a 0 to 300 sec. time delay depending on the setting of the START DELAY TIMER. Then, a 10-sec. audible tone sounds as a warning that the blower motor is about to turn on.

The airflow switch is checked to see if it is closed. If it is, the blower will display SAIL SWITCH ON FAULT.

If the airflow switch is open the motor will turn on. After the blower motor is turned on, the airflow switch is monitored. It closes if airflow is normal. If it does not close within 10 sec. (or 30 sec. for an AC drive) after blower turn-on, the blower displays SAIL SWITCH OFF FAULT. When the airflow switch closes, a 30 second prepurge time will start. After the prepurge time is completed the gas valve opens, the ignition turns on and the burner is monitored for a normal flame condition. If a flame is not detected within 10 seconds, the gas valve is closed, the ignition spark is removed and the blower displays NO FLAME DETECTED FAULT.

If a normal flame condition is detected the “indication” contact closure is established between TS1-3 and 4. The unit will run for a period of time determined by the setting of the RUN TIMER. If the run timer is set at “0” the unit will continue to run until the circuit closure between TS1-1 and 2 is removed.

If the blower is equipped with the two stage gas valve option and the rail temp sensor is installed, then under normal operation when the rail reaches the preset temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the rail falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity.

If the blower is equipped with the two stage gas valve option and the duct temp sensor is installed, then under normal operation when the duct reaches the preset duct temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the duct falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity. If the duct temp sensor sees a temperature above 325 ° F (163° C) both gas valves will be disabled. This prevents over temps.

There is a burner control adjustment available in the control module adjustments that allow the burner to be set to high only, low only or automatic controlled by the rail temp sensor. If the two-stage option is not installed, the burner control switch should be set to high only. Refer to (SET UP AND ADJUSTMENTS) in Section IV 8.

SNOW DETECTOR OPERATION. If the unit is operating with one or two optional snow detector assemblies and moisture is detected by either (or both), a snow melt sequence will begin, provided that the air temperature is below the set point. The unit will start as described in Section IV Part B under (Select Snow Timer).

E. FAULT CONDITIONS

1. SAIL SWITCH ON FAULT:

During startup the processor checks the status of the airflow switch. If the airflow switch is closed or shorted the blower motor will turn on and the blower will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is closed it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for.

2. SAIL SWITCH OFF FAULT:

Sail switch off fault is set when blower is running and air flow switch is open. After the fault is set the blower motor will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is open it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the sail switch is free to move and if there are any obstructions in duct work.

3. NO FLAME DETECTED FAULT:

No flame detected fault is set when blower is running and air flow switch is closed with gas valve open. If no flame is detected within 10 seconds the fault will be set. After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the flame rod for proper operation. If no flame is present it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

4. FLAME DETECTED ON FAULT:

Flame detected on fault is set when blower is running and air flow switch is closed with gas valve closed. If flame is detected before gas valve is opened the fault will be set. After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the flame rod for proper operation. If flame is present with gas off it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

5. GAS VALVE FAILURE:

During the blower shutdown operation if the unit senses flame after the post-purge, the unit will not shutdown. Instead it will go into gas valve failure mode. In this mode the blower continues to run, the reply will also indicate a problem, and the buzzer will sound. The unit will lock out all other operations and will not be able to be reset except at the unit itself.

6. CHECK FUSE # 1 24 VDC POWER:

Fuse # 1 is tripped. Check the following circuits:

- a. Overtemp switch and wiring.
- b. Check TS1-2 +24 control on wiring.

7. CHECK FUSE # 2 IGNITION TRANSFORMER:

Fuse # 2 is tripped. Check the following circuits:

- a. Ignition transformer and wiring.

8. CHECK FUSE # 3 GAS VALVE / SAIL SWITCH:

Fuse # 3 is tripped. Check the following circuits:

- a. Check Sail switch and wiring.
- b. Check hi and low gas valve and wiring.
- c. Check external gas valve and wiring.

9. CHECK FUSE # 4 BLOWER MOTOR:

Fuse # 4 is tripped. Check the following circuits:

- a. Check blower motor contactor and wiring.

10. CHECK FUSE # 6 SNOW HEAD # 1:

Fuse # 6 is tripped. Check the following circuits:

- a. Check snow detector head # 1 and wiring.
- b. Check Gas pressure sensor and wiring.
- c. Check Duct pressure sensor and wiring.

11. CHECK FUSE # 7 SNOW HEAD # 2:

Fuse # 7 is tripped. Check the following circuits:

- a. Check snow detector head # 2 and wiring.

- b. Check Sail switch and wiring.

12. CHECK FUSE # 9 ANALOG 5VDC:

Fuse # 9 is tripped. Check the following circuits:

- a. Check 5V supply for pressure sensor.

13. CHECK FUSE # 10 PRESSURE/BAT CHARGER:

Fuse # 10 is tripped. Check the following circuits:

- a. Check pressure sensor.
- b. Check 24V supply for battery backup.

14. OVERTEMP FIX PROBLEM PRESS DECREASE:

Overtemp sensor has tripped. If the temperature inside the Tie duct exceeds 375 degrees F, it will cause the ductwork overtemp circuit to trip, shutting down the HAB system. Only pushing the decrease value push button will reset the unit, giving opportunity to check the cause of the overtemp condition.

15. OVERTEMP FIX PROBLEM PRESS DECREASE ___ MIN:

The overtemp sensor has tripped. The HAB system will shut down for some time period then it will reset the unit. NOTE: AUTO OVERTEMP RESET must be enable in order to see this fault.

16. OVERTEMP WARNING RESTART IN ___ SEC:

If the temperature is close to overtemp value, the unit will restart in a certain time period.

17. OVERTEMP MISSING INSTALL OVERTEMP:

Caused my missing overtemp sensor.

18. MOTOR VOLTAGE LOW:

Motor voltage low is caused by inadequate electrical service supply. During motor start up if motor voltage drops below 190 VAC, the motor will eventually be damaged. If this under-voltage occurs, an error will be set. Press decrease value button to clear the fault.

19. MOTOR VOLTAGE HIGH:

Motor voltage high is caused by high motor voltage. Can be caused by high voltage from the electric company.

20. MOTOR OVERLOAD, RESET OVERLOAD DEVICE:

High motor current will trip the motor overload on the control panel. This device is connected to the bottom of the motor contactor on the control panel. Reset by pressing the red button on the device. Check unit for high motor current, bad bearings, or obstructions in the blower wheel.

21. MOTOR CURRENT LOW:

Caused by low motor current.

22. MOTOR CURRENT HIGH:

Motor current high is caused when sensed current is 3 amps over motor name plate for 20 seconds. Check motor for high current, bad bearings, obstruction in blower wheel.

23. GAS PRESSURE LOW:

Gas pressure low is caused by supply gas pressure during operation dropping to a low level. Check gas delivery system.

24. GAS PRESSURE HIGH:

Gas pressure high is caused by high gas pressure going to the burner. Check gas delivery system. Adjust the regulator on the gas delivery system to lower the gas pressure.

25. DUCT PRESSURE LOW:

Duct pressure low is caused by not enough duct back pressure. Possible causes are missing flame cover or missing duct work.

26. DUCT PRESSURE HIGH:

Duct pressure high is caused by too much duct back pressure. Possible causes are duct work obstructions

27. PROPANE TANK LOW WARNING FILL TANK:

Propane tank low is caused by low propane tank level. Note propane tank level monitor must be installed and setup, for this warning to appear.

28. TANK VAPORIZATION PRESSURE LOW WARNING:

Tank vaporization pressure low warning is caused by low tank temperatures.

29. UTILITY POWER LOST:

Utility power lost is caused by no incoming AC voltage. Must have a battery backup in order to receive this fault.

V. SEASONAL MAINTENANCE

A. SPRING

1. Turn off gas source.
2. Turn off electric power at source.
3. Disconnect and remove the control module. Store in a clean, dry place.
4. Turn off manual gas valve.

B. FALL

1. Check all ductwork for clear airflow. Ensure that the point and track duct nozzle screens are not damaged and are completely covering the openings. Make sure that no debris or rodents have obstructed any area of the ductwork.
2. Inspect the track duct nozzles for proper operation.
3. Remove the flame duct cover. Check the burner. Make sure the spark igniter plug and flame rod are in good, clean condition. Check the wiring to make sure rodent or vibration have not damaged the insulation.
4. Check the airflow sail switch to make sure it is operating properly.
5. Replace the flame duct cover.
6. Install the control module and connect the wires.
7. Turn on the gas source.
8. Turn on the manual gas valve.
9. Turn on the electric power at source.
10. Perform the gas pressure regulator adjustment procedure as described on the following page of this manual.
11. Perform a flame failure test:
 - a) Place switch SS1 in the LOCAL position.
 - b) Turn off the manual gas valve.
 - c) Turn on the main circuit breaker.
 - d) After 40 seconds (plus any start delay period) the fault message NO FLAME DETECTED FAULT should be displayed. If the fault does not appear, the control module is faulty and should be replaced.
12. Check the flame current. Refer to Section IV, Control Module (B), SET-UP AND ADJUSTMENT 19.
13. Check the air temperature for proper setting.

VI. LOW PRESSURE REGULATOR ADJUSTMENT/OUTPUT TEMP TEST

- A. Place switch SS1 in the LOCAL position.
- B. Turn the manual gas valve to “ON” position and turn power on.
- C. Place the burner control in the hi-only position. Refer to Section IV SET-UP AND ADJUSTMENTS B8.
- D. After the 30-second pre-purge period, the unit will ignite. Check the gas pressure value. Adjust the white plug in regulator until the gauge reads 11” water column for propane or 7” water column for natural gas. NOTE:

Clockwise to increase pressure, counter-clockwise to decrease pressure.

- E. Let the GHAB run for a 10 minute period.
- F. After the 10 minute period, take temperature readings at both point nozzles.
- G. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
- H. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1" w.c. at a time) until you reach the desired temperature.
- I. Replace the top plug.
- J. Return all switches to their normal operating position.

VII. TROUBLESHOOTING

A. UNIT DOES NOT START

- 1. Check circuit breaker.
- 2. Check control fuse. The control fuse is an auto resettable type fuse. To check, turn the main circuit breaker off for one minute, then turn back on
- 3. Check for 18VAC between the following points:
TS1-6 and TS1-7
TS1-6 and TS1-8.
Change T1 control transformer if either measurement is incorrect.
- 4. Check for air temperature below set point.
- 5. Is the control module programmed for a start-up delay?
- 6. Monitor the fault display on the control module.
- 7. Turn the circuit breaker off, and then reset the motor overload relay. The motor overload relay is adjustable. It should be set for the motor name plate current.

B. UNIT DOES NOT MAINTAIN OPERATION

- 1. Monitor the flame current as described in section IV B. 19.
- 2. Check the fuel supply. Refer to Section VI.D.
- 3. Check 230VAC and 115VAC from either leg to the center tap neutral (with the unit running). It must be within +10% to -10%.
- 4. Check the burner. The burner must be clean and free of carbon.

5. The flame rod should be clean and secure. Refer to section IV.B.19. for flame current.
6. Check the wire from the flame rod to the control module for continuity. Pull the white plug connector on the lower right side of the control module. Use an Ohmmeter to measure continuity from the terminal of the flame rod to the white connector. The reading should be less than 1 ohm.

C. LOW HEAT LEVEL

1. Perform a regulator adjustment/output temp test refer to Section VI.
2. Check the fuel supply.
3. Make sure the burner is clean.
4. Make sure the orifice plate is installed for the fuel being used.
5. Check the low pressure regulator.
6. Check to see if the burner control is on low only or if it is in auto and the Rail Temp Sensor setting is forcing it to low output.

D. LOW AIRFLOW

1. Check for obstructions in all ductwork and the air intake.
2. If there is frost buildup on the air intake screen, move the screen to the “open” position.
3. Check the voltage and current levels on the blower motor.
4. Make sure knockouts on the track duct are pushed all the way back in the track duct.
5. Check the spacing between the inlet cone and the blower wheel. The gap should be less than 1/16 of an inch.

E. GAS VALVE



CHECK THE AREA TO BE SURE THERE ARE NO LINGERING GAS FUMES BEFORE DOING ANYTHING WHICH MAY CAUSE A SPARK!

1. Turn off gas to the blower.
2. Turn off power to the blower.
3. Check the gas valve for obstructions.

4. Check the gas valve for proper operation.

F. HIGH HEAT LEVEL

1. Check for proper orifice installation.
2. Perform the low pressure regulator and Temp Test found in Section VI.

VIII. SNOW DETECTOR

A. SNOW DETECTOR INSTALLATION

1. The snow detector sensing circuitry is contained within the control module. All that is required for snow detector operation is to connect the sensing head(s).
2. Either one or two sensing heads may be used.
3. Each sensing head has three lead wires; black, white, and green. Connect as follows:
 - a) green: one or both connected to TS1-6.
 - b) black #1: connected to TS1-7.
 - c) black #2: connected to TS1-8.
 - d) white: one or both connected to TS1-9.

NOTE: Refer to the diagrams when connecting wires for the sensing heads. It is important to properly connect the sensing head wires. Improper connection of the sensing head wires may result in damage to the control module and/or the sensing head.

4. To operate more than one HAB unit from a HAB unit that is controlled by a snow detector(s), connect terminal posts #6 together and terminal posts #9 together. (Do not connect terminal post #6 to terminal post #9.) When connecting snow detectors to more than one HAB unit, first connect one HAB. Then connect the snow detector to one more HAB. If the snow detector does not operate properly, exchange L1 and L2 on the newest HAB circuit breaker. NOTE: BE SURE L1 AND L2 ARE DE-ENERGIZED BEFORE EXCHANGING THEM. Continue to add HABs to the snow detector in the same manner until all the desired HABs are connected. DO NOT EXCEED 200' CABLE LENGTH (18 AWG WIRE).
5. The sensing heads should be mounted in a vertical position.

6. Experience has shown that positioning a snow detector sensing head in the switch area between the ties and between the switch point and the track duct is effective. A second sensing head is then placed away from the switch area, such as on a bungalow or pole.

B. SNOW DETECTOR OPERATION

NOTE: A snow detector sensing head only detects moisture. With temperature sensing capability, the HAB unit assumes moisture is due to snow when the air temperature is below set point.

All operating functions are similar to remote operation with the following exceptions:

1. **INDICATION:** During normal operation under snow detector control, the indication contact across terminal posts 3 and 4 will not be closed.
2. **TIMED OPERATION:** The snow detector has many different time scenarios. Refer to Section IV Part B to determine which scenario best meets the needs in your location.
3. **RUN TIMER:** During remote operation, if the snow detector senses moisture, the unit will operate according to the settings. The unit will then operate for the duration of the run timer setting.
4. **FAULT CONDITION:** A fault condition under snow detector control will cause the indication contact across terminal posts TS-3 and TS-4 to close. To reset the unit after a fault condition, momentarily apply a circuit closure between terminal posts TS-1 and TS-2 with Ss1 in the Auto position. The unit may now be operated either under remote control or snow detector control.

C. SNOW DETECTOR MAINTENANCE

The snow detector sensing head contains a small, self-regulating heater that will melt snow or ice into water. The sensing head relies on moisture to create a low resistance circuit path. The heater will also cause the moisture to evaporate within a short period. If the surface becomes non-conductive due to contamination by grease or oil, the sensing head will not operate. To ensure effective and dependable snow detector operation, it is important to inspect the sensing heads frequently and clean them thoroughly if necessary. Use a solution

of water and mild detergent or isopropyl alcohol to clean the sensing grid. Use a clean, dry cloth to wipe the grid. Make sure there is no residue left on the surface.

D. SNOW DETECTOR TROUBLESHOOTING

NOTE: A newly-installed snow detector sensing head should operate 15-20 minutes to allow the internal heater to reach normal operating temperature.

1. NO HEAT ON THE SENSING HEAD

- a. Check for voltage between terminal post 6 and 7, and between terminal post 6 and 8. It should be 18VAC (+2VAC). If not:
 - (1) Check the display on the control module.
 - (2) The control transformer may be defective.
 - (3) There may be a bad circuit connection.
- b. Remove the black and the green lead wires from the terminal posts. Check resistance between them. If resistance is greater than 10 ohms, the sensing head is defective and should be replaced.

2. DOES NOT DETECT MOISTURE

- a. Clean the snow detector as described in Section VIII.C. SNOW DETECTOR MAINTENANCE
- b. If unit still does not detect moisture, check the wiring connections between detector head and terminal posts.
- c. If unit still does not detect moisture, replace the control module with a known good control module. If still not operating properly, replace the sensing head.

NOTE: If a snow detector head becomes saturated with moisture, it can sometimes be restored to normal operation by removing it and “baking” it in a conventional oven for several hours. Do not exceed 150°F.

3. CONSTANT INDICATION OF MOISTURE DETECTION

- a. Clean the snow detector heads as described in section C, Snow Detector Maintenance.
- b. Remove white lead(s) from terminal post 9. If moisture indication is still on, the control module is defective and should be replaced.

IX. SPECIFICATIONS

VOLTAGE : 230VAC, 1PH 60 HZ, 30 Amp (3PH AC Drive)

MOTOR : 2 HP, 3450RPM, TEFC
14 Amp starting current
14 Amp running current

VOLTAGE : 208VAC, 3PH 60 HZ, 15 Amp

MOTOR : 2 HP, 3450RPM, TEFC
35 Amp starting current
6.2 Amp running current

VOLTAGE : 230VAC, 3PH 60 HZ, 15 Amp

MOTOR : 2HP, 3450RPM, TEFC
34 Amp starting current
5.8 Amp running current

VOLTAGE : 460 VAC, 3PH 60 HZ, 15 Amp

MOTOR : 2 HP, 3450RPM, TEFC
17.5 Amp starting current
2.9 Amp running current

VOLTAGE : 575 VAC, 3PH 60 HZ, 15 Amp

MOTOR : 2 HP, 3450RPM, TEFC
19.5 Amp starting current
2.1 Amp running current

AIRFLOW : 2000 CFM

COMBUSTION RATE : 400,000 BTU/HR
200,000 BTU/HR

FUEL : Propane or Natural Gas

FLOW RATE: Natural Gas: 400 CFH/200 CFH
Propane: 160 CFH/80 CFH
4.4 GPH/2.2 GPH

INDICATION CONTACTS: 30VDC 1A or 125VAC 300mA

X. DRAWINGS

BUNGALOW POSITIONING	960N36964
GHAB SWITCH LAYOUT	9509-0020
GHAB MAIN UNIT	9508-6117
TIE DUCT ASSEMBLY 136LB QUICK CHANGE	9278-4805
TIE DUCT ASSEMBLY 115LB QUICK CHANGE	9278-4605
POINT / TRACK ASSEMBLY RH	9508-4000
POINT / TRACK ASSEMBLY LH	9508-4001
NOZZLE TRACK DUCT ASSEMBLY	927490
ISOLATION KIT, TIE DUCT POINT NOZZLE	9278-0021
ISOLATION KIT, TIE DUCT TRACK NOZZLE	9278-0027
FLAME DUCT	9608-3124
HEAVY DUTY OFFSET DUCT	9278-3403
FLEX DUCT 2' ST INS W/MIXER	9528-4222
TRACK DUCT, 5' POINT	9278-0226
TRACK DUCT, 5' MID	9278-0227
TRACK DUCT, 10', MID	9278-1201
TRACK DUCT, 10', HEEL	9278-1202
SWITCH ROD DUCT 7'	9278-0270
TRACK DUCT SUPPORT BRACKET ASSEMBLY	92774
GHAB ELECT. PANEL LAYOUT 230V 1 PHASE	9508-0150
GHAB ELECT. PANEL LAYOUT 3 PHASE	9508-0125
GHAB ELECT. PANEL LAYOUT AC DRIVE	9508-0156
GHAB ELECT. SCHEMATIC 230V 1 PHASE	9504-0124
GHAB ELECT. SCHEMATIC 3 PHASE	9504-0125
GHAB ELECT. SCHEMATIC AC DRIVE	9504-0133
GAS PIPING, 2 STAGE	9608-0138
GHAB MENU FLOW CHART	

LIMITED WARRANTY

XI.

Railway Equipment Co., Inc. (“Railway”) warrants all of its products to be free from defects in material and workmanship when used under specified operating conditions and within specified limits. Railway’s warranty shall extend for a period of two (2) years from the date of shipment to the original purchaser.

This warranty is expressly in lieu of and excludes all other expressed or implied warranties, including but not limited to warranties of merchantability and fitness for a particular purpose.

Railway, its agents, or representatives shall in no circumstance be liable for any direct, indirect, special, penal, or consequential loss or damage of any nature resulting from the malfunction of the product.

Remedies under this warranty are expressly limited to repair or replacement of the product at the sole discretion of Railway.

Before returning any defective product to Railway, contact the factory at the address or telephone number at the bottom of this article for a Return Merchandise Authorization number and instructions as to how and where the return is to be shipped. Materials received without this authorization will be returned at the customer’s expense.

Products returned to Railway under warranty must be shipped freight prepaid, and return freight charges for repaired or replaced products, in or out of warranty, will be at customer’s expense.

Railway reserves the right to reject any warranty claim on a product that has been altered by the user or damaged in shipping due to inadequate packaging or mishandling by freight carrier.

By returning a product to Railway the owner grants permission to Railway to open and disassemble the product as required for evaluation. Railway has the sole responsibility for determining the cause and nature of failure, and Railway’s determination with regard thereto shall be final. Railway reserves the right to repair or replace any unit at its sole discretion.

A returned product that is found, upon inspection by Railway, to be operational within specification is subject to an inspection and testing fee, regardless of its warranty period.

Railway’s liability on any claim of any kind (including negligence) for any loss or damage arising out of or resulting from this agreement, or from the performance of breach thereof, of from the products or services furnished hereunder, shall in no case exceed the price of the specific product or service which gives rise to the claim. All such liability shall terminate upon the expiration of the warranty period of two (2) years, as hereinabove stated.

The furnishing of advice or other assistance without separate compensation therefor will not subject Railway to any liability, either in contract, warranty, tort (including negligence) or otherwise.

Any alteration or modification of the product, or addition on non-Railway components to the product, unless expressly permitted by Railway in its documentation, will void warranty coverage.

This warranty is non-transferable, and warranty coverage is limited to initial user only.


Installation and/or use of the product shall demonstrate acceptance of the terms of this warranty.

Each of the foregoing paragraphs in this article will apply to the full extent permitted by law. The invalidity, in whole or part, of any paragraph will not affect the remainder of such paragraph or any other paragraph.

RAILWAY EQUIPMENT CO.

P.O. Box 68 – Delano, Minnesota 55328 – USA – Tel. (763) 972-2200 Fax (763) 972-2900
E-Mail - mail@rwy.com


(INTENTIONALLY LEFT BLANK)



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS		RAILWAY EQUIPMENT CO. MINNEAPOLIS, MINNESOTA (763) 972-6200	
DESIGNER: GJONAS	DATE: 06/27/11	DRAWN BY: GJONAS	REV: K
CHECKED BY: GJONAS	DATE: 06/27/11	DATE: 06/27/11	SCALE: B
PROJECT: BUNGALOW, GHAB 2HP 240V 40' TRACK DUCT	PROJECT NO: 960N36964	SHEET: 2 OF 2	

© RAILWAY EQUIPMENT CO., 2011

REV.	Q.C.A.	BY	REVISION DESCRIPTION	DATE	APPROVED
A		RF	NEW PART	11/20/01	---
B	04-002B	RF	NEW TRACK DUCT SPLICE	06/06/05	---



© RAILWAY EQUIPMENT CO. 2001-2005
RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 972-3800

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS IN INCHES
 DECIMALS TO TWO PLACES
 FRACTIONS TO 16ths
 TOLERANCES UNLESS OTHERWISE SPECIFIED:
 FRACTIONS TO 16ths
 DECIMALS TO 0.005
 DIMENSIONS TO BE HONED TO NOT SCALE DRAWING


TITLE: HOT AIR BLOWER SWITCH LAYOUT
 DRAWN: TB/RF
 DATE: 10/23/00
 MATERIAL: N/A
 THE 1/8" HONED ALLOWANCE: N/A
 PWP NO.: 9509-0020
 SCALE: N/A
 DRAWING SIZE: B
 SHEET: 1 OF 1

PARTS LIST

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	26003	C	EA	1	INLET CONE, BLOWER
2	26006	E	EA	1	ASSY, BLOWER WHEEL
3	26035	-	EA	6	IMOUNT, RUBBER, M/M 1/4-20
4	26107	-	EA	1	NUT, 1/4-20, THUMB, NYLON
5	2631411112	-	EA	1	SCREW, #10-32 X 3/4 PAN SLT
6	2631851112	-	EA	4	BOLT, 3/8-16 X 3/4 HEX HEAD
7	2631851120	-	EA	8	BOLT, 3/8-16 X 1-1/4 HEX HEAD
8	2631861112	-	EA	8	BOLT, 3/8-16 X 3/4 CARRIAGE
9	2632-4101	-	EA	2	NUT, #10-32 HEX
10	2632-5101	-	EA	12	NUT, 1/4-20 HEX
11	2632-5901	-	EA	10	NUT, 1/4-20 CENTERLOCK
12	2632-8904	-	EA	16	NUT, 3/8-16 CENTERLOCK
13	2633-4210	-	EA	1	WASHER, #10 SPLITT LOCK
14	2633-4310	-	EA	2	WASHER, #10 EXT. STAR
15	2633-5110	-	EA	6	WASHER, 1/4 FLAT
16	2633-5119	-	EA	4	WASHER, 1/4 X 1.5 FENDER
17	2633-5211	-	EA	6	WASHER, 1/4 SPLITT LOCK
18	2633-8090	-	EA	4	RIVET, BUTTON HEAD PLATED STL
19	2633-8210	-	EA	4	WASHER, 3/8 SPLITT LOCK
20	2690-0307	-	EA	1	BUSHING, 7/8
21	29051	-	EA	51	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
22	32009	-	SHT	1	INSULATION, STYROFOAM
23	60002	-	EA	2	3/8 ROHEX
24	60169	-	EA	2	TY-RAP, 0.30 X 8
25	60185	-	EA	1	GASKET, 0.25 X 0.75 ADHESIVE BACK
26	6093-0100	-	EA	5	TY-RAP, 4IN 0.10 WIDTH
27	61000	-	EA	1	LI-BOLT, MRO BOLT #05
28	61001	-	EA	1	ELBOW, 3/4IN SCH 40 BLACK
29	61017	-	EA	1	NIPPLE, 3/4 X 7 SCH 40 BLACK
30	8040-0950	E	EA	1	NAMEPLATE, 950/951 GHAB
31	9278-3122	D	EA	1	DUCT, ADAPTOR, 11X12 TO 8X8
32	93358	A	EA	1	GASKET, 8 X 8 LIFT-OUT DUCT
33	93363	A	EA	1	BLOWER SHROUD
34	9338-0026	A	EA	1	ASSY, BUZZER
35	9338-9028	B	EA	1	ASSY, WIRED MOTOR 2HP 230V 1PH
36	95046	A	EA	1	MOTOR MOUNTING PLATE, HAB
37	9508-0038	A	EA	1	ASSY, GAS SENSOR EXT CABLE
38	9508-0039	A	EA	1	ASSY, DUCT SENSOR EXT CABLE
39	9508-0135	C	EA	1	BURNER, 6" VERTICAL
40	9508-0150	B	EA	1	ASSY, GHAB CONTROL, 2HP 1PH 240
41	9508-0430	A	EA	1	ASSY, WIRED IGNITION XHMR
42	9508-0431	B	EA	1	ASSY, HARNISS AIR FLOW SWITCH
43	9508-0495	A	EA	1	ASSY, FLAME WIRE
44	960131	A	EA	1	ENCLOSURE, HAB
45	96018	A	EA	1	COVER, UPPER INTAKE, GALV
46	96019	B	EA	1	2HP BASE, HAB, GALV, BUNGALOW
47	96020	B	EA	1	INTAKE BODY, 2HP BUNGALOW
48	960431	A	EA	1	SUPPORT, GAS LINE, 2ND STAGE
49	960600	A	EA	1	BLOWER OUTLET FLANGE
50	960602	C	EA	1	MOTOR MOUNTING PLATE BUNGALOW
51	9608-0023	C	EA	1	ASSEMBLY, IGNITION WIRE
52	9608-0138	B	EA	1	GHAB GAS PIPING W PRESS SENSOR
53	960801	A	EA	1	BUNGALOW ENCL MOUNTING PLATE
54	9609-0816	A	EA	1	LABEL, FAN ROTATION
55	9609-0830	A	EA	1	LABEL, GHAB WARNINGS
56	9609-0955	A	EA	1	LABEL, ID PLATE AGA/CSA
57	9609-0100	A	EA	1	LABEL, GHAB MENU
58	R960D-0103	B	EA	2	MANUAL, 960 BUNGALOW SINGNET

REVISION HISTORY

REV	ECO #	DESCRIPTION	DATE	BY
A	06-0032	NEW ASSEMBLY	1/18/07	RMJ
B	08-0006	UPDATED TRAV/ENCL/PANEL	6/23/08	WIS
C	10-0031	CHANGED ENCL/XHMR/BASE	12/16/10	MF
K	11-0014	UPDATED GHAB CONTROL	06/28/11	GJ



RAILWAY EQUIPMENT CO. 2011

RAILWAY EQUIPMENT CO.
MILWAUKEE, WISCONSIN (762) 972-5200

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS ARE ANGULAR FINISHES ARE AS SHOWN TOLERANCES ARE: FRACTIONS DECIMALS MILLIMETERS .0001 .001 .0001		DATE: 12/16/10		DRAWN: 9508-6117		REV: K	
PROJECT: N/A		SHEET: 1 OF 1		SCALE: 1/16		PARTS: B	
TITLE: ASSY, MAIN 2 HP GHAB		DRAWN: MF		CHECKED: MF		APPROVED: MF	

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS


REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS

Parts List					
ITEM	PART NUMBER	DESCRIPTION	REV	UOM	QTY

1	927279	ASSY, TUBE TIE DUCT 8 X 10	A	EA	4
2	927237	COVER PLATE, TEMP SENSOR	A	EA	2
3	2631951121	BOLT, 1/2-13 X 1.25, SS	B	EA	2
4	2633-9009	WASHER, 3/4 SPLIT LOCK	B	EA	2
5	2633-9210	WASHER, 3/8 SPLIT LOCK	-	EA	1
6	2631851114	BOLT, 3/8-16 X 1 HEX HEAD, SS	D	EA	2
7	26121	BOLT, 3/4-10 X 1 1/2 HEX SS	D	EA	1
8	93358	GASKET, 8 X 8 LIFT-OUT DUCT	-	EA	1
9	927267	COVER PLATE WITH LIFTING LUG	-	IN	720
10	2631851116	BOLT, 3/8-16 X 1 HEX CAP	-	EA	16
11	2632-8904	NUT, 3/8-16 CENTER LOCK	-	EA	2
12	927366	E-CLIP INSULATOR	A	EA	2

Parts List					
ITEM	PART NUMBER	DESCRIPTION	REV	UOM	QTY



13	927248	RAIL CLIP, TIE DUCT	A	EA	4
14	927603	COVER, OUTSIDE TRACK NOZZLE	A	EA	2
15	927355	TIE PLATE, 136# E-CLIP-PAD TYPE	B	EA	2
16	927367	PAD FOR E-CLIP RUBBER 136# TIE	B	EA	2
17	14151	WIRE BURLAPBAG CLOSING TIES 6"	-	EA	1
18	R8039-0901	CAUTION LABEL, TIE DUCT 136#	D	EA	1
19	R8039-0911	TAG, ACCESS PARTS FOR TIE DUCT	-	EA	1
20	14150	BAG, BURLAP 10" X 14" 100Z	-	EA	720
21	12425	TAP ROLL, 2" WIDE HEAVY	-	EA	16
22	2633-9020	WASHER, M12 SPLIT LOCK	-	EA	2
23	927602	COVER, POINT/TRACK NOZZLE	A	EA	2



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES		RAILWAY EQUIPMENT CO., 20016	
DECIMALS	ANGULAR	RAILWAY EQUIPMENT CO.	
1/16" = .0625	1/16" = .0625	DELI LVA, MARYSVILLE (C603) 9278-2200	
1/32" = .03125	1/32" = .03125	TITLE: TIE DUCT, 136# QUICK CHANGE	
1/64" = .015625	1/64" = .015625	(ASSEMBLY)	
DRAWN: WS		DWG NO: 9278-4805	REV: A
DATE: 10/23/06		SCALE: 1/8" = 1"	
MATERIAL: SEE B.O.M.		SHEET: 1 OF 1	
TOLERANCE: N/A		DRAWING: B	

Parts List				Parts List							
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927279	A	EA	1	ASSY. TUBE TIE DUCT 8 X 10	13	927368	A	EA	2	PAD FOR E-CUP RUBBER 115# TIE
2	927356	B	EA	2	TIE PLATE 115# E-CUP PAD TYPE	14	927366	A	EA	4	E-CUP INSULATOR
3	927237	A	EA	2	COVER PLATE, TEMP SENSOR	15	927248	A	EA	4	RAIL CLIP, TIE DUCT
4	2831951121	-	EA	16	BOLT, 1/2-13 X 1.25 SS	16	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
5	2833-9009	-	EA	4	WASHER, 3/4 SPLIT LOCK	17	2833-9020	-	EA	16	WASHER, M12 SPLIT LOCK
6	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK	18	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
7	2831651114	-	EA	4	BOLT, 3/8-16 X 1 HEX HEAD, SS	19	14151	-	EA	1	WIRE BURLAPBAG CLOSING TIES 6"
8	28121	-	EA	8	BOLT, 3/4-10 X 1 1/2 HEX SS	20	R8039-0900	D	EA	2	CAUTION LABEL, TIE DUCT 115#
9	93358	A	EA	2	GASKET, LIFTOUT DUCT	21	R8039-0910	D	EA	1	TAG, ACCESS PARTS FOR TIE DUCT
10	927267	A	EA	2	COVER PLATE WITH LIFTING LUG	22	14150	-	EA	1	BAG, BURLAP 10" X 14" 100Z
11	2831651116	-	EA	12	BOLT, 3/8-16 X 1 HEX CAP	23	12425	-	IN	720	TAPE ROLL 2" WIDE HEAVY
12	2832-8904	-	EA	12	NUT, 3/8-16 CENTERLOCK	24	927602	A	EA	2	COVER, POINT/TRACK NOZZLE

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/17/2006	WS



RAILWAY EQUIPMENT CO., 2006

RAILWAY EQUIPMENT CO.
 DELAWARE, MARYLAND (757) 972-8200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ANGULAR
 .XX + .015 FRACTIONS
 .000 NOT SHOWN UNLESS OTHERWISE SPECIFIED

DRAWN: WS
 DATE: 10/17/06
 WRT: SEE B.O.M.
 N/A

DWG NO: 9278-4605
 SCALE: 1/8" = 1"
 DWG SIZE: B
 SHEET 1 OF 1

TIE: TIE DUCT, 115# QUICK CHANGE
 (ASSEMBLY)


REV: A

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/24/2006	WS

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927600	B	EA	1	POINT/ID NOZZLE MOUNT PLATE RH
2	927701	A	EA	1	SCREEN POINT NOZZLE
3	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
4	92757	D	EA	1	GASKET, ISO. PT NOZZLE RED
5	92759	B	EA	1	GASKET, ISO. TR NOZZLE RED
6	93617	D	EA	1	POINT NOZZLE, 4 X 4 GALV
7	2632-9015	B	EA	8	WASHER, ISOLATING NOZZLE
8	28106	-	EA	8	SPACER, .38X.62X.375 ROUND
9	2633-9014	-	EA	4	WASHER, 5/8 FLAT SAE
10	2633-8110	-	EA	8	WASHER, 3/8 FLAT
11	2632-8210	-	EA	8	WASHER, 3/8 SPLIT LOCK
12	2632-8101	-	EA	8	NUT, 3/8-16 HEX
14	R9508-4000	A	EA	1	LABEL, QUICK NOZZLE ASSY RH
15	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY


REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/24/2006	WS

Parts List




CENTER POINT

1 1



14 1



15 1


15 1

5 3

1 1

4 1

2 1



11 8

10 8

7 8

8 8

11 8

10 8

7 8

8 8

12 8

9 4

8 8


8 8

RAILWAY EQUIPMENT CO. 2006
 RAILWAY EQUIPMENT CO.
 DEERING, MASSACHUSETTS (FAC) 952-2500
 TEL: 952-2500 FAX: 952-2500
 DRAWN BY: WS
 DATE: 10/24/06
 PART: 9508-4000
 TITLE: POINT/TRACK NOZZLE ASSY RH (ASSEMBLY)
 SCALE: 1/4
 SHEET 1 OF 1

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927706	B	EA	1	POINT/ID NOZZLE MOUNT PLATE LH
2	927701	A	EA	1	SCREEN, POINT NOZZLE
3	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
4	927757	D	EA	1	GASKET, ISO, PT NOZZLE RED
5	92759	B	EA	1	GASKET, ISO, TR NOZZLE RED
6	93817	D	EA	1	POINT NOZZLE, 4 X 4 GALV
7	2833-9015	B	EA	8	WASHER, INSULATING NOZZLE
8	28106	-	EA	8	SPACER, .38X.625X.375 ROUND
9	2833-9014	-	EA	4	WASHER, 5/16 FLAT SAE
10	2833-8110	-	EA	8	WASHER, 3/8 FLAT SAE
11	2833-8210	-	EA	8	WASHER, 3/8 SPLIT LOCK
12	2833-8101	-	EA	8	NUT, 3/8-16 HEX NUT
13	60195	-	FT	1.687	GASKET, .28 X 1.0 ADHESIVE BK
14	R9508-4001	A	EA	1	LABEL, QUICK NOZZLE ASSY LH
15	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

Parts List

REVISION HISTORY			
REV	ECO	DESCRIPTION	DATE
A	06-0024	NEW PART	10/19/2006



RAILWAY EQUIPMENT CO. - 2006

RAILWAY EQUIPMENT CO.
 DELAWARE, DELAWARE
 (763) 922-2200

DATE: 10/19/06
 TIME: 10:00 AM
 DRAWN: WS
 CHECKED: WS
 PART: SEE B.O.M.
 REV: N/A



9508-4001
 (ASSEMBLY)

SCALE: 1/4" = 1" SHEET 1 OF 1

ITEM	PART NUMBER	QTY	DESCRIPTION
1	927488	EA	NOZZLE, TRACK DUCT, NO DAMPER
2	92745	EA	HOLDOWN STRAP, T, DUCT
5	92742	EA	SPRING, TRACK DUCT SUPPORT
4	92743	B	CLIP, HOLDOWN SPRING
7	60195	FT	GASKET, .25 X 1.0 ADHESIVE BK


REV	ECO	DESCRIPTION	DATE	BY
A	06-0028	NEW PART	11/30/2006	RMJ

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0028	NEW PART	11/30/2006	RMJ





PLACE P/N:60195 ON LEDGE (FRONT & BACK) BEFORE INSTALLING DUCT

PLACE P/N:60195 UNDER STRAP FOR TRANSPORTATION.



PACKOUT VIEW
SCALE 1 / 4



© RAILWAY EQUIPMENT CO. 2006


RAILWAY EQUIPMENT CO.
 BELLEVUE, MINNESOTA 55004-2200
 TEL: 763-572-2700
 FAX: 763-572-2701
 WWW.RAILWAYEQUIPMENT.COM

ISSUE: RMJ
 DATE: 11/30/06
 MFG: N/A
 REV: A

NOZZLE, TRACK DUCT ASSY



DWG NO: 927490
 SCALE: 1/2
 SHEET 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	2831891114	EA	4	BOLT, HEX HD 3/8-16 x 1" SS
2	2833-8110	EA	4	WASHER, FLAT 3/8"
3	2833-9015B	EA	4	WASHER, INSULATOR
4	28106	EA	4	SPACER, ROUND, .39 X .825 X .375
5	92757D	EA	1	GASKET, POINT NOZZLE
6	2833-9014	EA	4	WASHER, 5/8 FLAT PLATED
7	14046	EA	1	BAG, ZIPTOP 9x12 4mil
8	2833-8210	EA	4	WASHER, SPLIT LOCK 3/8"
9	927701A	EA	1	SCREEN, POINT NOZZLE



POINT NOZZLE SHOWN FOR REF. ONLY

TIE DUCT



REV	EDA	REV	REVISION DESCRIPTION	DATE	APPROVED
B	---	TB	ADD 927701	10/19/00	---
C	06-0028	RJ	CORNERS CUT OFF ON DUCT	11/29/06	---

© RAILWAY EQUIPMENT CO. 1997-2002

RAILWAY EQUIPMENT CO.
 DELANO, MINNESOTA (763) 978-3200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO BE FRACTIONS
 UNLESS NOTED OTHERWISE
 DO NOT SCALE DRAWINGS

DRAWN: EFK
 DATE: 04/11/97

MATERIAL: N/A
 TIE DUCT ALLOWANCE: N/A

TITLE: ISOLATION KIT ASSEMBLY
 POINT NOZZLE
 TIE DUCT




DWG NO.: 9278-0021
 SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1

REV: C

Parts List

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	14045	-	EA	1	BAG, 12 X 15 4MIL ZIPTOP
2	2831311104	-	EA	2	SCREW, #8-32 X 1/4 PAN SLT
3	2831441108	-	EA	2	SCREW, #10-32 X 1/2 PAN SLT
4	2831651120	-	EA	12	BOLT, 3/8-16 X 1-1/4 HEX HEAD
5	2832-8101	-	EA	12	NUT, 3/8-16 HEX
6	2833-8210	-	EA	12	WASHER, 3/8 SPLIT LOCK
7	29019	-	EA	12	BOLT, 1/4-20 X 1.3 SHOULDER
8	29051	-	EA	29	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
9	32002	-	SOFT	12.5	INSULATION, FIBERGLASS
10	60002	-	EA	1	3/8 ROMEX
11	6093-0102	-	EA	2	TY-RAP
12	9338-0072	-	EA	1	ASSY. DUCT PRESSURE SENSOR
13	93333	-	EA	1	GASKET, 11X12, HIGH TEMP
14	950165	-	EA	1	PYREX VIEWING WINDOW BRACKET
15	950167	-	EA	1	GASKET, PYREX VIEWING WINDOW
16	950168	-	EA	1	PYREX VIEWING WINDOW
17	950178	-	EA	1	FLAME DUCT 11 X 12, BUNGALOW
18	9509-0032	-	EA	1	AIR FLOW SWITCH 950/951/980
19	950819	-	EA	1	QUICK ACCESS CVR W/WNDW
20	9528-0074	-	EA	1	GASKET KIT, 9X9 9HP DUCTWORK
21	952817	-	EA	1	PLATE, SML SWITCH & PRESSURE
22	980163	-	EA	1	INSUL BTM BUNGALOW, 11X12 DUCT
23	980164	-	EA	1	INSUL TOP, BUNG 11 X 12 DUCT

REVISION HISTORY				
RE	ECO #	DESCRIPTION	DATE	BY
			7/18/2011	



© RAILWAY EQUIPMENT CO., 2011

RAILWAY EQUIPMENT CO.




MINNEAPOLIS, MINNESOTA (763) 972-6200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DIMENSIONS ARE ANGULAR
 UNLESS OTHERWISE SPECIFIED
 TOLERANCES ARE:
 FRACTIONS DECIMALS
 .0001 .0005 .0010 .0015 .0020 .0030 .0050 .0100 .0150 .0300 .0500 .1000 .1500 .3000 .5000 .7500 1.0000

DATE: 07/18/11
 DRAWN BY: GJONAS
 TITLE: DUCT, FLAME 11X12 BUNGALOW
 DWG NO: 9608-3126
 SCALE: 1" = 1'-0"
 SHEET: 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	952226	EA	1	INSUL COVER, OFFSET DUCT
2	29019	EA	8	SHOULDER BOLT 1/4-20 X 1.3
3	952224	EA	1	DUCT, OFFSET, WITH HEAVY BASE
4	32002	SQ.FT.	6	INSULATION FIBERGLASS
5	9526-0074	EA	1	GASKET KIT, 6X9 SHP FLEX
6	6093-0102	EA	1	TY-RAP




REV	DATE	BY	DESCRIPTION	APP'D
A	08/07/05	RF	NEW PART	



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS		© RAILWAY EQUIPMENT CO. 2005	
DRAWING SHALL BE MADE TO THE FOLLOWING TOLERANCES UNLESS OTHERWISE SPECIFIED: DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS DIMENSIONS IN INCHES ARE IN PARENTHESES DIMENSIONS IN MILLIMETERS ARE IN PARENTHESES DIMENSIONS IN INCHES ARE IN PARENTHESES DIMENSIONS IN MILLIMETERS ARE IN PARENTHESES		RAILWAY EQUIPMENT CO. DELAHO, MINNESOTA (763) 975-5800	
DRAWN	RF	TITLE	OFFSET DUCT, 2' REINFORCED, LIFTOUT ASSEMBLY / B.O.M.
DATE	08/07/05	DWG NO.	9528-3404
MATERIAL	N/A	SCALE	1/4" = 1'-0"
DESIGNER	N/A	DRAWING SIZE	B
DATE	08/07/05	REV	A
SCALE	1/4"	SHEET	1 OF 1

PARTS LIST					
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	952388	A	EA	1	FLEX WRAP, BOTTOM 2'
2	952389	A	EA	1	FLEX WRAP, BOTTOM 2'
3	29051	-	EA	6	BOLT, 1/4-20 X 1/2 HWX 1/2 HD
4	952391	A	EA	1	FLEX DUCT, TRANSITION WELDMENT
5	952392	A	EA	1	FLEX DUCT, TRANSITION WELDMENT
6	952394	A	EA	1	RUBBER TUBE 10" ID 11" LONG
7	9528-0074	B	EA	1	GASKET KIT, 9X9 5HP DUCTWORK
8	927237	A	EA	1	COVER PLATE, TEMP SENSOR
9	28105	-	EA	2	CLAMP, HOSE SST 18 INCH
10	R9528-4222	A	EA	1	LABEL, FLEX DUCT TO BLOWER

REVISION HISTORY			
REV	ECO #	DESCRIPTION	DATE
A	08-0003	NEW PART	6/23/10



© RAILWAY EQUIPMENT CO., 2009




RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-6200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE ANGULAR
 .0005" MINIMUM TOLERANCE
 .0010" MAXIMUM TOLERANCE
 .0005" MINIMUM TOLERANCE

DATE: 06/22/2010
 DRAWN: ELS
 CHECKED: ELS
 TITLE: FLEX DUCT 2ST INS W/MIXER
 9 X 9 RED RUBBER
 (ASSEMBLY / B. O. M.)
 PART NUMBER: 9528-4222
 REV: A
 SCALE: 1" = 4" PARTS: B SHEET 1 OF 1

REV.	QTY.	BY	REVISION DESCRIPTION	DATE	APPROVED
A	05-007	RF	NEW SPLICE SYSTEM	05/24/05	----
B	05-007	RO	NEW SUPPORT ASSEM DESIGN	10/27/05	----

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927443	EA	1	TRACK DUCT BASE 5'
2	92740	EA	1	END PLATE, TRACK DUCT
3	92730	EA	1	TRACK DUCT COVER 5'
4	92774	EA	1	TRACK DUCT SUPPORT BRACKET
5	92785	EA	1	DEFLECTOR, TRACK DUCT, SMALL
6	29051	EA	9	BOLT, 1/4"-20X1/2" W/ 1/2" HEX HEAD
7	6093-0100	EA	1	TY-RAP, 4" .10 WIDTH



FULL SCALE





UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO 2 PLACES
 FRACTIONS ARE TO 1/32
 DIMENSIONS TO 3/16 AND 1/8
 DO NOT SCALE DRAWING

DRAWN: RPF
 DATE: 05/24/05
 MATERIAL: SEE PRINT
 TITLE: TRACK DUCT
 5' POINT LTD
 ASSEMBLY / B.O.M.




SCALE: 1/4" = 1'-0"
 SHEET: 1 OF 1

© RAILWAY EQUIPMENT CO. 2005
RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 972-3300

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92735	EA	1	TRACK DUCT BASE 5'
2	92730	EA	1	TRACK DUCT COVER 5'
3	927441	EA	1	CENTER COVER, E.Z. SPLICE
4	927442	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	92774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/ 2" HEX HEAD
8	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH



REV.	DATE	BY	DESCRIPTION	DATE	APPROVED
A	05-07-05	RF	NEW SPLICE SYSTEM	05/24/05	---
B	05-07-05	RO	NEW SUPPORT ASSM DESIGN	10/27/05	---



FULL SCALE

© RAILWAY EQUIPMENT CO. 2005

RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 978-2800







UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO BE ROUNDED UP
 TO THE NEXT HIGHER DECIMAL
 DO NOT SCALE DRAWINGS

DRAWN: RPF
 DATE: 05/24/05
 MATERIAL: SEE PRINT
 TITLE: TRACK DUCT
 5' MID
 ASSEMBLY / B.O.M.



DWG NO.: 9278-0227
 SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1
 REV: B

REV.	E.O.A.	BY	REVISION DESCRIPTION	DATE	APPROVED
J		TB	REMOVE 92744, 28080, 28081	05/26/99	----
K	02-0046	RF	REPLACE 29016 W/29051	08/29/02	----
L	05-0017	RF	NEW SPLICE SYSTEM	05/18/05	----
M	05-0047	RO	NEW SUPPORT ASSEM. DESIGN	10/27/05	----

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927538	EA	1	TRACK DUCT BASE 10'
2	92741	EA	1	TRACK DUCT COVER 10'
3	92741	EA	1	CENTER COVER, E.Z. SPLICE
4	92742	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	92774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
8	6093-0100	EA	1	TY-RAP, 4" .10 WIDTH



1/8 SCALE



FULL SCALE




UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS ARE TO FACE UNLESS
NOTED OTHERWISE
DIMENSIONS ARE TO CENTER UNLESS
NOTED OTHERWISE
DIMENSIONS ARE TO CENTER UNLESS
NOTED OTHERWISE
DO NOT SCALE DRAWING

DRAWN: RPF
DATE: 02/15/93
MATERIAL: SEE PRINT
REV: M
SCALE: 1/4" DRAWING SIZE
SHEET: 1 OF 1

© RAILWAY EQUIPMENT CO. 1993-2005
RAILWAY EQUIPMENT CO.
DUBLINO, MINNESOTA (763) 972-3300

TITLE: TRACK DUCT
10' MID
ASSEMBLY / B.O.M.
DWG. NO.: 9278-1201
REV: M

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927538	EA	1	TRACK DUCT BASE 10'
2	92740	EA	1	END PLATE, TRACK DUCT
3	92741	EA	1	TRACK DUCT COVER 10'
4	927441	EA	1	CENTER COVER, E.Z. SPLICE
5	927442	EA	2	END COVER, E.Z. SPLICE
6	927450	EA	1	BASE, E.Z. SPLICE
7	92774	EA	1	TRACK DUCT SUPPORT BRACKET
8	92785	EA	1	DEFLECTOR, TRACK DUCT, SMALL
9	28051	EA	9	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
10	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH



1/8" SCALE

1/2" SCALE

REV.	EDA.	REV.	REVISION DESCRIPTION	DATE	APPROVED
J	02-06	TB	UPDATE TRACK DUCT SUPPORT	05/26/99	---
K	02-06	RF	REPLACE 29016 W/29051	08/29/02	---
L	05-07	RF	NEW SPLICE SYSTEM	05/18/05	---
M	05-07	RO	NEW SUPPORT ASSM DESIGN	10/27/05	---

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS
DIMENSIONS IN BRACKETS ARE AS SHOWN
DO NOT SCALE DRAWINGS

DRAWN: RPF
DATE: 02/15/93

MATERIAL: SEE PRINT
REV: M






SCALE: 1/4" DRAWING SIZE B SHEET 1 OF 1

© RAILWAY EQUIPMENT CO. 1993-2005
RAILWAY EQUIPMENT CO.
DELANO, MINNESOTA (763) 978-2800

TITLE: TRACK DUCT
10' HEEL
ASSEMBLY / B.O.M.

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	9278-0207	EA	1	TRACK DUCT 7' HEEL
2	9278-0027	EA	1	ISO KIT, TR NOZZLE, LARGE
3	927490	EA	1	NOZZLE, TRACK DUCT
4	41023	EA	1	BOX, TRACK DUCT KIT

REV.	Q.C.A.	BY	REVISION DESCRIPTION	DATE	APPROVED
A	02-0027	RF	NEW PART	07/03/02	----
B	03-0023	RF	UPDATE NOZZLE	07/29/03	----
C	05-0017	RF	NEW SPLICE DESIGN	05/25/05	----
D	05-0047	RO	NEW TRACK DUCT NOZZLE	11/10/05	----
E	06-0024	RJ	NEW TRACK DUCT NOZZLE	02/02/07	----







UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO 3 PLACES
 FRACTIONS ARE TO 16 PLACES
 DIMENSIONS TO BE SHOWN AS FRACTIONS
 UNLESS OTHERWISE SPECIFIED
 DO NOT SCALE DRAWING

DRAWN: RPF
 DATE: 07/03/02
 MATERIAL: N/A
 THE FOLLOWING ALLOWANCES:

© RAILWAY EQUIPMENT CO. 2002-2005
RAILWAY EQUIPMENT CO.
 DELAWARE, MINNESOTA (763) 972-3300

TITLE: TRACK DUCT KIT, 7' LARGE NOZZLE
 PWT NO.: 9278-0270
 SCALE: N/A DRAWING SIZE: B SHEET 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92745	EA	1	HOLDDOWN STRAP, TRACK DUCT
2	92750	EA	1	TRACK DUCT SUPPORT BASE
3	92751	EA	1	TRACK DUCT SPRING BRKT
4	92742	EA	2	SPRING, TRACK DUCT SUPPORT BRKT
5	92743	EA	2	SPRING, TRACK DUCT SUPPORT BRKT
6	283151110	EA	2	1/4-20 X 5/8 HEX BOLT #5 HARD
7	2832-5901	EA	2	1/4-20 CENTERLOCK NUT
8	2833-8110	EA	2	3/8 FLAT WASHER
9	28049	EA	2	LAG BOLT 3/8 X 2.5
10	14042	EA	1	BAG, ZIPLOCK 4 X 6 X .002
11	14045	EA	1	BAG, ZIPLOCK 12 X 15 X .004



REV	DATE	BY	REVISION DESCRIPTION	DATE	APPROVED
D	6/21/91	EFK	REDESIGN FOR SPRING MOUNT.		
E	9/25/92	EFK	CHG. P/N 927135 REV/B TO 927139 REV/C		
F	7/8/94	EFK	CHG. P/N 92742 REV/A TO 92742 REV/B		
G	5.26.99	TB	ADD ITEMS 10 THRU 15		
H	4.11.01	TB	#92743B WAS 92743A		
J	05/18/05	RF	NEW SPLICE SYSTEM		
K	10/27/05	RO	SHORTENED 92750-551		


FORM NO.	DATE	REV	DESCRIPTION
92774	6/21/91	1	TRACK DUCT SUPPORT BRKT SUB-ASSEMBLY

© RAILWAY EQUIPMENT CO. 1990-2005
RAILWAY EQUIPMENT CO.
 RAILWAY ASSOCIATES
 (704) 978-8800
 TRACK DUCT
 SUPPORT BRKT
 SUB-ASSEMBLY
 92774

REVISION HISTORY			
REV	ECO #	DESCRIPTION	DATE
A	09-0012	NEW PART	9/10/09
B	11-0014	NEW MODULE	06/22/11

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	21016	-	EA	1	CONNECTOR, HOUSING, 10 POS
2	21017	-	EA	1	STRAIN RELIEF, 10 POS
3	21020	-	EA	2	CONNECTOR, HOUSING, 2 POS
4	21021	-	EA	2	STRAIN RELIEF, 2 POS
5	21023	-	EA	1	STRAIN RELIEF, 3 POS
6	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA
7	28029	-	EA	1	TERMINAL ASSY, 1 X 12 POS
8	28090	-	EA	1	CAP, TERMINAL POST INSULATING
9	28091	-	EA	1	SHIELD, TERMINAL POST INSULATE
10	2831211106	-	EA	1	SCREW, #6-32 X 3/8 PAN SLT
11	2831311106	-	EA	9	SCREW, #8-32 X 3/8 PAN SLT
12	2831411106	-	EA	9	SCREW, #10-32 X 3/8 PAN SLT
13	2831411110	-	EA	3	SCREW, #10-32 X 5/8 PAN SLT
14	2833-3110	-	EA	1	WASHER, #8 FLAT SAE
15	2833-4310	-	EA	2	CONTACTOR, 3POLE, 115V COIL
16	45124	-	EA	1	OVERLOAD RELAY, 240V 2HP MOTOR
17	45181	-	EA	1	CIR BRKR, 30A 240V 2POLE
18	51203	-	EA	1	BRACKET, GE CIRCUIT BREAKER
19	51204	-	EA	1	LUG, FORK #10 22-18GA NYLON
20	6031-0103	-	EA	11	LUG, RING 1/4 22-18GA NYLON
21	6032-0110	-	EA	3	LUG, RING #10 16-14GA NYLON
22	6032-0111	-	EA	3	LUG, RING 1/4 16-14GA NYLON
23	6032-0112	-	EA	3	LUG, PUSH-ON F .250 22-18GA
24	6034-0102	-	EA	1	CABLE TIE MOUNTS
25	6090-0102	-	IN	18	WIRE DUCT, 1.5IN X 3IN
26	6093-0004	-	IN	18	WIRE DUCT, COVER 1.5 IN
27	6093-0303	-	EA	31	WIRE, 10GA BLACK 600V 105C
28	681001	-	EA	36	WIRE, 18GA GREEN - HOOK UP
29	681601	-	EA	44	WIRE, 300V 105C BLACK
30	681832	-	EA	24	WIRE, 18GA THINWALL WHITE 300V
31	681833	-	EA	41	WIRE, 18GA THINWALL RED 300V
32	681834	-	EA	86	WIRE, 18GA THINWALL BROWN 300V
33	681835	-	EA	130	WIRE, 18GA THINWALL BLUE 300V
34	681836	-	EA	1	TRANSFORMER, CONTROL MODULE
35	9338-0015	C	EA	1	CONTROL MODULE, GHAB W/ DISP
36	9338-0320	J	EA	1	SURGE ARRESTOR ASSY, 240V 1PH
37	9338-0325	B	EA	1	PANEL, ELECTRIC HAB
38	95075	B	EA	1	ASSY, CURRENT COIL 100A AC
39	9508-0037	A	EA	1	ASSY, CURRENT COIL 100A AC
40	R9330-0021	B	EA	1	LABEL, TERM POST SNO NET

PARTS LIST



VIEW A-A
SCALE 1 / 4

RAILWAY EQUIPMENT CO. 2011
RAILWAY EQUIPMENT CO.
 1101 MARKET STREET
 PHILADELPHIA, PENNSYLVANIA 19106
 TEL: 215-581-1000 FAX: 215-581-1001
 WWW: WWW.RAILWAYEQUIPMENT.COM


DATE: 09/10/2009
 DRAWN: EJS
 CHECKED: N/A
 APPROVED: N/A

PROJECT: 9508-0150
 SHEET: 1 OF 1

ASSY, GHAB CONTROL 2HP 1PH 240
 (ASSEMBLY / B. O. M.)

PARTS LIST

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	
1	21016	-	EA	1	CONNECTOR, HOUSING, 10 POS	
2	21017	-	EA	1	STRAIN RELIEF, 10 POS	
3	21020	-	EA	2	CONNECTOR, HOUSING, 2 POS	
4	21021	-	EA	2	STRAIN RELIEF, 2 POS	
5	21023	-	EA	1	STRAIN RELIEF, 3 POS	
6	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA	
7	28029	-	EA	1	TERMINAL ASSY, 1 X 12 POS	
8	28090	-	EA	1	CAP, TERMINAL POST INSULATING	
9	28091	-	EA	1	SHIELD, TERMINAL POST INSULATE	
10	2831211106	-	EA	3	SCREW, #6-32 X 3/8 PAN SLT	
11	2831311106	-	EA	13	SCREW, #8-32 X 3/8 PAN SLT	
12	2831411106	-	EA	13	SCREW, #10-32 X 3/8 PAN SLT	
13	2831411110	-	EA	3	SCREW, #10-32 X 5/8 PAN SLT	
14	2833-3110	-	EA	1	WASHER, #8 FLAT SAE	
15	2833-4310	-	EA	1	WASHER, #10 EXT STAR	
16	45124	-	EA	1	CONTACTOR, 3POLE, 115V COIL	
17	45136	-	EA	1	AUXILIARY CONTACT MONC	
18	45188	-	EA	1	OVERLOAD RELAY, 1.8 - 2.7 AMPS	
19	5111-0601	-	EA	2	FUSE, 500V 1AMP SLO-BLO	
20	5122-0400	-	EA	1	CIR BRKR, 15A 600V 3 POLE	
21	5122-0400	-	EA	1	FUSEBLOCK, 600V, 30A, 2 POLE	
22	5122-0401	-	EA	2	FUSEBLOCK COVER	
23	56058	-	EA	1	TRANS, 575 MAX P-115S 300VA	
24	6031-0101	-	EA	1	LUG, FORK #6 16-14GA NYLON	
25	6031-0102	-	EA	2	LUG, FORK #6 22-18GA NYLON	
26	6031-0103	-	EA	1	LUG, FORK #10 22-18GA NYLON	
27	6032-0110	-	EA	11	LUG, RING 1/4 22-18GA NYLON	
28	6032-0111	-	EA	3	LUG, RING #10 16-14 GA NYLON	
29	6032-0112	-	EA	4	LUG, RING 1/4 16-14GA NYLON	
30	6034-0101	-	EA	4	LUG, PUSH-ON F, 250 16-14GA	
31	6034-0102	-	EA	3	LUG, PUSH-ON F, 250 22-18GA	
32	6090-0102	-	EA	1	CABLE TIE MOUNTS	
33	6093-0004	-	IN	18	WIRE DUCT, 1.5IN X 3IN	
34	6093-0100	-	EA	32	TY-RAP, 4IN 0.10 WIDTH	
35	6093-0303	-	IN	18	WIRE DUCT, COVER 1.5 IN	
36	681401	-	IN	18	WIRE, 14 GA BLACK 600V 105C	
37	681601	-	IN	24	WIRE, 16 GA GREEN - HOOK UP	
38	681831	-	IN	80	WIRE, 18 GA 600V THINWALL BLACK	
39	681833	-	IN	23	WIRE, 18 GA THINWALL WHITE 600V	
40	681834	-	IN	50	WIRE, 18 GA THINWALL RED 600V	
41	681835	-	IN	112	WIRE, 18 GA THINWALL BROWN 600V	
42	681836	-	IN	140	WIRE, 18 GA THINWALL BLUE 600V	
43	9338-0015	-	EA	1	TRANSFORMER, CONTROL MODULE	
44	9338-0320	-	J	EA	1	CONTROL MODULE, GHAB W/ DSP
45	9338-0326	-	B	EA	1	SURGE ARRESTOR ASSY, 600V 3PH
46	95075	-	B	EA	1	PANEL, ELECTRIC HAB
47	9509-0037	-	A	EA	1	ASSY, CURRENT COIL, 100A AC
48	R3330-0021	-	B	EA	1	LABEL, TERM POST SMD NET



REVISION HISTORY

REV	ECO	BY	DESCRIPTION	DATE	APPROVED
A	06-0020	WS	NEW PART	8/30/06	-
B	-	RJ	REV/PRT# 9338-0115	10/28/2006	-
C	07-0013	RMJ	UPDATE TO MODULE	6/7/2007	-
D	08-0008	WS	NEW TRANSFORMERS / NEW COM. BOX	3/31/08	-
K	11-0014	GJ	NEW MODULE / NEW PANEL	07/12/11	-

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DIMENSIONS ARE IN MILLIMETERS
 DECIMALS ARE ANGULAR
 FRACTIONS ARE ANGULAR
 DIMENSIONS ARE TO UNLESS OTHERWISE SPECIFIED

DATE: 8/30/06
 DRAWN: WAS
 CHECKED: WAS
 TITLE: ASSY, GHAB CONTROL 3PH 575V (ASSEMBLY)
 DWG NO: 9508-0125
 DATE: 8/30/06
 SCALE: 1/4
 SHEET: 1 OF 1

RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-5290




APPROVED: K

REV	ECO #	DESCRIPTION	DATE	BY
A	10-0012	NEW PART	7/23/10	ES
B	11-0014	UPDATED MODULE	06/29/11	GJ

REV	ECO #	DESCRIPTION	DATE	BY
A	10-0012	NEW PART	7/23/10	ES
B	11-0014	UPDATED MODULE	06/29/11	GJ

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	21016	-	EA	1	CONNECTOR, HOUSING, 10 POS
2	21017	-	EA	1	STRAIN RELIEF, 10 POS
3	21020	-	EA	2	CONNECTOR, HOUSING, 2 POS
4	21021	-	EA	2	STRAIN RELIEF, 2 POS
5	21023	-	EA	1	STRAIN RELIEF, 3 POS
6	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA
7	28029	-	EA	1	TERMINAL ASSY, 1 X 12 POS
8	28090	-	EA	1	CAP, TERMINAL POST INSULATING
9	28091	-	EA	1	SHIELD, TERMINAL POST INSULATE
10	2831211106	-	EA	1	SCREW, #6-32 X 3/8 PAN SLT
11	2831281103	-	EA	2	SCREW, #6-32 X 3/16 FLSTR SLT
12	2831311106	-	EA	8	SCREW, #8-32 X 3/8 PAN SLT
13	2831411106	-	EA	9	SCREW, #10-32 X 1/2 PAN SLT
14	2831411108	-	EA	4	SCREW, #10-32 X 1/2 PAN SLT
15	2831411110	-	EA	3	SCREW, #10-32 X 5/8 PAN SLT
16	2831541132	-	EA	2	SCREW, 1/4-20 X 2 RND SLT
17	2832-5101	-	EA	6	NUT, 1/4-20 HEX
18	2833-2210	-	EA	2	WASHER, #6 SPLIT LOCK
19	2833-3110	-	EA	1	WASHER, #8 FLAT SAE
20	2833-4310	-	EA	2	WASHER, #10 EXT. STAR
21	2833-5110	-	EA	2	WASHER, 1/4 FLAT
22	2833-5211	-	EA	6	WASHER, 1/4 SPLIT LOCK
23	45124	-	EA	1	CONTACTOR, 3POLE, 115V COIL
24	51203	-	EA	1	CIR BRKR, 30A 240V 2POLE
25	51204	-	EA	1	BRACKET, GE CIRCUIT BREAKER
26	5300-0203	-	EA	1	HEATER, STRIP 115V 125W
27	53080	-	EA	1	SENSOR, AIR TEMP
28	60023	-	FT	5	WIRE, 5000V 18GA BLACK
29	60172	-	EA	2	LUG, RING #10 22-18GA HI-TEMP
30	6031-0103	-	EA	1	LUG, FORK #10 22-18GA NYLON
31	6032-0110	-	EA	12	LUG, RING 1/4 22-18GA NYLON
32	6032-0111	-	EA	3	LUG, RING #10 16-14GA NYLON
33	6032-0112	-	EA	3	LUG, RING 1/4 16-14GA NYLON
34	6034-0102	-	EA	3	LUG, PUSH-ON F.250 22-18GA
35	6090-0102	-	EA	1	CABLE TIE MOUNTS
36	6093-0004	-	IN	14	WIRE DUCT, 1.5IN X 3IN
37	6093-0303	-	IN	14	WIRE DUCT, COVER 1.5 IN
38	61086	-	EA	1	DRIVE AC 2 HP 230V 1PH INPUT
39	681001	-	IN	31	WIRE, 10GA BLACK 600V 105C
40	681601	-	IN	24	WIRE, 16GA GREEN-HOOK UP
41	681832	-	IN	44	WIRE, 18GA 300V 105C BLACK
42	681833	-	IN	24	WIRE, 18GA THINWALL WHITE 300V
43	681834	-	IN	41	WIRE, 18GA THINWALL RED 300V
44	681835	-	IN	86	WIRE, 18GA THINWALL BROWN 300V
45	681836	-	IN	130	WIRE, 18GA THINWALL BLUE 300V
46	8039-0813	A	EA	1	LABEL, HOT DO NOT TOUCH
47	9220-0029	A	EA	1	COVER, HEAT SHIELD
48	9338-0015	C	EA	1	TRANSFORMER, CONTROL MODULE
49	9338-0320	J	EA	1	CONTROL MODULE, GHAB W/ DISP
50	9338-0325	B	EA	1	SURGE ARRESTOR ASSY, 240V 1PH
51	95075	B	EA	1	PANEL, ELECTRIC HAB
52	9508-0037	A	EA	1	ASSY, CURRENT COIL 100A AC
53	R9330-0021	B	EA	1	LABEL, TERM POST SNO NET

PARTS LIST




UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS ARE IN MILLIMETERS
TOLERANCES UNLESS OTHERWISE SPECIFIED:
FRACTIONS DECIMALS
XX .XX .010
XXX .XXX .005
XXX .XXX .0025
XXX .XXX .0015
XXX .XXX .0010
XXX .XXX .0005
XXX .XXX .00025

RAILWAY EQUIPMENT CO. 2011
RAILWAY EQUIPMENT CO.
MINNEAPOLIS, MINNESOTA (763) 972-5200


TITLE: GHAB CONTROL 2HP 240V AC DRIVE
(ASSEMBLY / B. O. M.)

DATE: 07/23/2010
DRAWN: J/A
CHECKED: N/A
DESIGNED: N/A
SCALE: 1:4
PAGE: B
SHEET 1 OF 1

REV.	DATE	BY	DESCRIPTION	APPROVED
B	2/24/09	AB	REVISION B	
C	7/7/09	ES	ADDED 208/230VAC NEW MODULE	
D	07/05/11	GD		



REV	DATE	BY	DESCRIPTION	DATE	APPROVED
A	09-07/09	JB	NEW DRAWING	09/27/09	
C	11-07/14	CB	NEW MODULE	07/09/11	






UNLESS OTHERWISE SPECIFIED:	
DIMENSIONS ARE IN INCHES	
DECIMALS ARE IN THOUSANDS	
FRACTIONS ARE IN SIXTEENTHS	
ANGLES ARE IN DEGREES	
DO NOT SCALE DRAWINGS	
DRAWN BY: JB	
DATE: 05/27/2009	
WANT: N/A	
TEND: ALLOWANCE:	
SCALE: NONE	DWG SIZE: B
SHEET 1 OF 1	

RAILWAY EQUIPMENT CO. 2011	
RAILWAY EQUIPMENT CO.	
MINNEAPOLIS, MINNESOTA (763) 972-8200	
TITLE: GAS HOT AIR BLOWER	
2HP 240V 1 PHASE AC 3 PHASE DRIVE	
SCHEMATIC / CONNECTION DIAGRAM	
DWG NO: 9504-0133	REV: B

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	21023	-	EA	1	STRAIN RELIEF, 3 POS
2	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA
3	2831551134	-	EA	8	BOLT, 1/4-20 X 1-3/4 HEX HEAD SS
4	2833-5115	-	EA	8	WASHER, 1/4 FLAT SS
5	2833-5241	-	EA	8	WASHER, 1/4 SPLIT LOCK SS
6	29051	-	EA	2	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
7	45035	-	EA	2	VALVE, K3A552, 0-3PSI GAS
8	60002	-	EA	3	3/8 ROMEX
9	60011	-	EA	1	CONNECTOR, CORD, 1/2INCH STRT
10	60035	-	EA	2	BUSHING, 1/2 IN PLASTIC INSUL
11	60160	-	EA	1	CONDUIT, LOCK NUT 1/2 IN
12	60197	-	EA	1	FLEX HOSE 3/4 X 18 - 5/8 OD
13	60225	-	EA	1	TEE, 3/4 X 3/4 X 3/4 SCH 40
14	60231	-	EA	4	O-RING, BUNA-N, 3/16 WIDE
15	60234	-	EA	1	TEE, 3/4 X 3/4 X 1/4 SCH 40 BLK
16	60241	-	IN	60	CABLE, 4 COND 18GA PVC 600V
17	6092-0201	-	EA	5	LUG, WIRE JOINT NYLON
18	6093-0100	-	EA	2	TY-RAP, 4IN 0.10 WIDTH
19	61000	-	EA	2	U-BOLT, MRO BOLT #65
20	61001	-	EA	2	ELBOW, 3/4IN SCH 40 BLACK
21	61011	-	EA	4	NIPPLE, 3/4 X 1.5 SCH 40 BLACK
22	61013	-	EA	1	NIPPLE, 3/4 X 3 SCH 40 BLACK
23	61017	-	EA	1	NIPPLE, 3/4 X 7 SCH 40 BLACK
24	61021	-	EA	1	NIPPLE, 3/4 X 2.5 SCH 40 BLACK
25	61057	-	EA	1	NIPPLE, 3/4 X 3.5 SCH 40 BLACK
26	61074	-	EA	1	NIPPLE, 3/4 X 15 SCH 40 BLACK
27	681820	-	FT	1.5	CORD, STRAIGHT 18/2 SJTOW
28	933431	A	EA	2	SUPPORT GAS LINE TWO-STAGE
29	933611	A	EA	1	OUTLET MANIFOLD, GAS LINE
30	933612	D	EA	2	COUPLING PLATE 3/4 NPT
31	933620	C	EA	1	UNIVERSAL ORIFICE PLATE
32	9338-0043	A	EA	2	SNUBBER ASSY, GAS VALVE
33	9338-0070	A	EA	1	ASSY, PRESSURE SENSOR

REV	ECO	DESCRIPTION	DATE	BY
A	--	NEW PART	8/10/2006	RMJ
B	10-0031	REMOVED CONDUIT	01/10/11	MF



DETAIL A
SCALE 2 / 3


NOTE:
1. USE LOCTITE 401 SEALANT TO INSTALL THE FOUR O-RINGS INTO THE OUTLET MANIFOLD AND THE COUPLING PLATES. DO NOT USE LOCTITE BETWEEN THE O-RINGS AND THE ORIFICE PLATE.
2. WATCH THE GAS FLOW DIRECTION WHEN INSTALLING THE GAS VALVES.

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESIS ARE IN MILLIMETERS
XX.XX = 0.02 FRACTIONS
XX.XXX = 0.001 FRACTIONS
DO NOT SCALE DRAWINGS

RAILWAY EQUIPMENT CO. 2011
RAILWAY EQUIPMENT CO.
MAYNARD, MINNESOTA (763) 972-2290

TITLE: GHAB GAS PIPING W PRESS SENSOR
DATE: 08/10/06
DWG NO: 9608-0138
SHEET: 1/4
SCALE: B
ASSY/BOM
REV: B
SHEET 1 OF 1

GHAB MENU



OPERATING MANUAL

MODEL NO. 963 BUNGALOW

GAS FIRED HOT AIR BLOWER

TRACK SWITCH SNOW MELTER

WITH STEEL TIE DUCT

MANUFACTURED

BY

RAILWAY EQUIPMENT COMPANY

525 NINTH STREET SOUTH

DELANO, MINNESOTA 55328

TEL. 763-972-2200

FAX. 763-972-2900

E-Mail:

Support: Techsupport@rwy.com

Sales: Order@rwy.com



CAUTION

GENERAL HAZARD WARNING

FAILURE TO COMPLY WITH THE PRECAUTIONS AND INSTRUCTIONS PROVIDED WITH THIS HEATER, CAN RESULT IN DEATH, SERIOUS INJURY AND PROPERTY LOSS OR DAMAGE FROM HAZARDS OF FIRE, EXPLOSION, BURN, ASPHYXIATION, CARBON MONOXIDE POISONING, AND/OR ELECTRICAL SHOCK.

ONLY PERSONS WHO CAN UNDERSTAND AND FOLLOW THESE INSTRUCTIONS SHOULD USE OR SERVICE THIS HEATER.

IF YOU NEED ASSISTANCE OR HEATER INFORMATION, SUCH AS INSTRUCTION MANUALS, LABELS, ETC., CONTACT THE MANUFACTURER.



CAUTION

WARNING: FIRE, BURN, INHALATION, AND EXPLOSION HAZARD.

KEEP SOLID COMBUSTIBLES, SUCH AS BUILDING MATERIALS, PAPER OR CARDBOARD, A SAFE DISTANCE AWAY FROM THE HEATER AS RECOMMENDED BY THE INSTRUCTIONS. NEVER USE THE HEATER IN SPACES WHICH DO OR MAY CONTAIN VOLATILE OR AIRBORNE COMBUSTIBLES, OR PRODUCTS SUCH AS GASOLINE, SOLVENTS, PAINT THINNER, DUST PARTICLES OR UNKNOWN CHEMICALS.



CAUTION

NOT FOR HOME OR RECREATIONAL VEHICLE USE

The heater is designed and approved for use as a construction heater under ANSI Z83.7

We cannot anticipate every use which may be made of our heaters.

CHECK WITH LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT APPLICATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

PLEASE READ THIS INSTRUCTION MANUAL ENTIRELY BEFORE HANDLING THIS MATERIAL OR ATTEMPTING TO INSTALL, OPERATE OR SERVICE THIS HOT AIR BLOWER SYSTEM.

PLEASE READ THE WARNINGS AND CAUTIONS LISTED BELOW.



SHEET METAL EDGES MAY BE VERY SHARP AND CAN CAUSE SEVERE CUTS OR LACERATIONS. PROTECTIVE GLOVES AND CLOTHING SHOULD BE WORN. USE CAUTION WHEN HANDLING ALL SHEET METAL COMPONENTS.



THIS HOT AIR BLOWER TRACK SWITCH SNOWMELTER SYSTEM CAN BE OPERATED REMOTELY OR BY A SNOW DETECTOR SYSTEM. THEREFORE, OPERATION MAY BEGIN UNEXPECTEDLY. USE CAUTION WHEN IN THE AREA.



SYSTEM OPERATES WITH VARIOUS VOLTAGE LEVELS UP TO 600VAC. CONTACT WITH ELECTRICITY CAN BE HAZARDOUS OR LETHAL. MAKE SURE THAT THE MAIN CIRCUIT BREAKER IS TURNED OFF BEFORE ATTEMPTING TO SERVICE THIS SYSTEM. EVEN WITH CIRCUIT BREAKER OFF LINE VOLTAGE IS PRESENT AT THE TOP CIRCUIT BREAKER CONNECTIONS.



THIS SYSTEM CONTAINS A HIGH SPEED AIR FAN WHICH ROTATES AT UP TO 3600RPM AND CREATES FORCEFUL SUCTION WHEN OPERATING. DO NOT OPERATE THE BLOWER SYSTEM IF ANY OF THE DUCTWORK COMPONENTS HAVE BEEN REMOVED.



THIS SYSTEM OPERATES WITH NATURAL GAS OR PROPANE. BOTH ARE GASES WHICH ARE FLAMMABLE AND EXPLOSIVE. USE EXTREME CAUTION WHEN WORKING IN THE AREA. AVOID ANY OPEN FLAME, SPARKS OR OTHER SOURCE OF IGNITION.



THE OUTLET AIR TEMPERATURE FROM THIS GAS SNOW MELTER SYSTEM SHOULD NOT EXCEED 375°F FROM ANY NOZZLE OR DUCT. **DO NOT OPERATE THIS BLOWER SYSTEM IF THE OUTLET TEMPERATURE EXCEEDS 375°F.** AN ACCURATE THERMOMETER SHOULD BE USED TO REGULARLY CHECK THE OUTLET AIR TEMPERATURE. IF THE OUTLET TEMPERATURE EXCEEDS 375°F, CHECK TO MAKE SURE THAT THE FLOW OF AIR IS NOT RESTRICTED AT ANY POINT, THAT THE BLOWER/MOTOR ARE OPERATING PROPERLY, THAT THE CORRECT ORIFICE IS USED FOR THE TYPE OF FUEL USED, AND THAT THE REGULATOR(S) ARE PROPERLY ADJUSTED FOR THE FUEL BEING USED. CONSULT RAILWAY EQUIPMENT COMPANY IF YOU ARE UNABLE TO OPERATE THIS GAS SNOW MELTER SYSTEM BELOW 375°F.

A HIGH TEMPERATURE LIMIT SYSTEM HAS BEEN INCORPORATED INTO ALL RAILWAY EQUIPMENT COMPANY GAS SNOW MELTER SYSTEMS BEGINNING IN 1999. RAILWAY EQUIPMENT COMPANY ALSO HAS A HIGH TEMPERATURE LIMIT MODIFICATION KIT THAT CAN BE ADDED TO GAS SNOW MELTER SYSTEMS MANUFACTURED PRIOR TO 1999. IT IS RECOMMENDED THAT THIS HIGH TEMPERATURE LIMIT SYSTEM BE INSTALLED AND USED. CONSULT RAILWAY EQUIPMENT TO ORDER THE HIGH TEMPERATURE MODIFICATION KIT, OR IF YOU NEED ASSISTANCE REGARDING THE HIGH TEMPERATURE LIMIT SYSTEM.

THIS SNOW MELTER SYSTEM HAS BEEN DESIGNED TO PROVIDE DEPENDABLE EFFECTIVE OPERATION IN ALL WEATHER CONDITIONS WITHOUT SWITCH COVERS. SWITCH COVERS MAY CAUSE HIGHER AIR TEMPERATURES. IF SWITCH COVERS ARE USED, YOU MUST DETERMINE A SAFE OPERATING AIR TEMPERATURE AND ADJUST BURNER PARAMETERS ACCORDINGLY. ADJUSTMENT OF BURNER PARAMETERS MAY NEGATIVELY AFFECT BURNER PERFORMANCE AND COMBUSTION CHARACTERISTICS TO THE EXTENT THAT THE BURNER MAY BE UNABLE TO MAINTAIN COMBUSTION. CONSULT RAILWAY EQUIPMENT COMPANY REGARDING BURNER OPERATING PARAMETERS.

TWO (2) COMPLETE INSTRUCTION MANUALS HAVE BEEN INCLUDED WITH THIS SNOW MELTER SYSTEM. PLEASE KEEP ONE OF THE MANUALS WITH THE SYSTEM AFTER INSTALLATION. ANYONE OPERATING OR SERVICING THIS SNOW MELTER SYSTEM SHOULD READ THE MANUAL ENTIRELY BEFORE PROCEEDING.

IF YOU HAVE ANY QUESTIONS CONCERNING THE MANUFACTURE, DESIGN, FUNCTION, INSTALLATION, OPERATION OR MAINTENANCE, CONTACT RAILWAY EQUIPMENT COMPANY BEFORE PROCEEDING.


TABLE OF CONTENTS

I.	GENERAL INFORMATION	8
A.	MODEL NUMBER DESCRIPTION	8
B.	STANDARD FEATURES	8
II.	COMPONENT DESCRIPTION	10
A.	MAIN HAB UNIT	10
B.	STANDARD DUCTWORK	11
C.	OPTIONAL DUCTWORK	12
III.	INSTALLATION	14
A.	TIE DUCT	14
B.	BUNGALOW PLACEMENT	15
C.	POINT NOZZLES AND TRACK DUCTS	16
D.	GAS CONNECTION	17
E.	CHANGING THE GAS ORIFICE	20
F.	ELECTRICAL CONNECTION	21
IV.	CONTROL MODULE	23
A.	DESCRIPTION	23
B.	SET-UP AND ADJUSTMENTS	24
C.	LED STATUS INDICATING LIGHTS	31
D.	OPERATION	33
E.	FAULT CONDITIONS	34
V.	SEASONAL MAINTENANCE	39
VI.	LOW PRESSURE REGULATOR ADJUSTMENT	40
VII.	TROUBLESHOOTING	41
A.	UNIT DOES NOT START	41
B.	UNIT DOES NOT MAINTAIN OPERATIONS	41
C.	LOW HEAT LEVEL	41
D.	LOW AIRFLOW	42
E.	GAS VALVE	42
F.	HIGH HEAT LEVEL	42
VIII.	SNOW DETECTOR	43
A.	INSTALLATION	43
B.	OPERATION	44
C.	MAINTENANCE	44
D.	TROUBLESHOOTING	45

IX.	SPECIFICATIONS	46
X.	DRAWINGS	47
XI.	LIMITED WARRANTY	48

I. GENERAL INFORMATION

A. MODEL NUMBER DESCRIPTION



B. STANDARD FEATURES OF 950/951 SERIES TRACK SWITCH HOT AIR BLOWER

1. GHAB complies with AREMA 12.6.10.
2. Gas fired operation, allows for both propane and natural gas (convertible in the field)
3. Two stage operation (400,000 / 200,000 BTU) that allows savings on fuel costs.
4. 2 H.P. direct drive motor, totally enclosed fan cooled, 230VAC 60Hz, single phase.
5. High efficiency, quiet operation , 2000 CFM blower.
6. Remote operation via contact closure (low voltage, low current) with timed shut off.
7. Built-in snow detector system (requires Snow Detector assembly option).
8. Auto-Off-Force switch.
9. High temperature limit thermostat/shut off.
10. Adjustable air temperature control.
11. Adjustable rail temperature control.
12. Reply indication via GHAB contact closure.
13. Fail indication via GHAB contact closure.
14. Main circuit breaker.
15. Audible tone before blower startup
16. Weathertight gasketed control enclosure

17. Status indicating lights for all control functions
18. Start delay timer for sequential startup
19. Run timer for timed operation
20. Selectable "Transparent" snow detector operation
21. Snow detect timer
22. All ductwork and nozzles are thermally and electrically isolated from tracks
23. Quick-release track duct
24. Blower motor starter with overload protection
25. Remote auxiliary gas valve (115vac) supplied connection
26. Gas line accessories:
 - A. Manual gas valve
 - B. Gas line strainer
 - C. Low pressure regulator
 - D. Flexible gas line connection pipe
27. Elevated air intake
28. Adjustable delay for start up (10 Sec. -5 Min.)
29. Complete flame safeguard control:
 - A. Pre-ignition air purge.
 - B. Air flow proving switch
 - C. Direct spark ignition
 - D. Flame proving sensor
 - E. Post shut off air purge 4 Min.
 - F. Automatic shut off on loss of flame or air flow
 - G. Leaky gas valve
 - H. Automatic retry on flame loss
 - I. Automatic reset on flame safeguard control
 - J. All flame safeguard controls CSA listed.
30. All components mounted and wired within main unit – no external wiring required except for remote control, indications and optional snow detectors.
31. Galvanized case constructed of 14-gauge steel, high temperature baked enamel finish.
32. Convenient panel access to high efficiency burner, flame sensor and spark igniter.
33. Galvanized steel adjustable mounting foundations.
34. Standard ductwork: 1.5' flame duct with 2.5' straight insulated flexible duct and heavy duty insulated offset duct connects to main tie duct electrically insulated between rails, 24 inch (minimum) switch point nozzles.

The following items are recommended for use with propane gas service:

Tank "pigtail" with POL/POL fittings (P/N 45038-12" or 60127-36")
High pressure regulator (P/N 45103)
Gas line strainer (P/N 45040)
Remote solenoid valve (P/N 45036) OR
Complete Propane Package (P/N 9458-0100)

II. COMPONENT DESCRIPTION

A. MAIN HOT AIR BLOWER (HAB) UNIT

- 1. MAIN CIRCUIT BREAKER:** Provides main over-current protection and manual on-off control of electrical power.
- 2. MOTOR CONTACTOR:** Provides automatic blower motor control, with high current contacts.
- 3. MOTOR OVERLOAD RELAY:** Protects the blower motor from an over-current condition.
- 4. CONTROL MODULE:** Provides complete control of operation. See separate description and details, section IV.
- 5. CONTROL TRANSFORMER:** Provides control power for the control module and other control components. The multi-tapped secondary provides, 36VAC CT and 17VAC CT. The primary has 115VAC input plus a 230VAC step-up winding and 12.6 VAC CT windings.
- 6. IGNITION TRANSFORMER:** Provides 10000VAC to the spark igniter during the ignition sequence.
- 7. AIRFLOW SWITCH:** Located in the flame duct, the sail switch indicates proper airflow before and during burner operation. The differential setting is determined by elevation.
- 8. BURNER:** Contains the actual flame. Also holds the spark igniter and the flame-sensing rod.
- 9. PROPANE/NATURAL GAS ORIFICE PLATE:** Controls the rate of flow of gas to the burner.
- 10. SPARK IGNITER:** The spark plug type igniter provides spark for the burner. The spark igniter is momentary - sparks only until the flame has been established.

11. **FLAME DETECTION ROD:** The flame detection rod monitors the flame at the burner nozzle using the rectification principle. This provides a low-level signal to the control module if a proper flame exists.
12. **AIR TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the ambient air temperature.
13. **RAIL TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the actual rail temperature.
14. **GAS VALVE:** This is an electric solenoid valve which controls the flow of gas for burner operation. It is controlled directly from the control module.
15. **BLOWER MOTOR:** The 5HP 3450RPM motor is totally enclosed and fan cooled.
16. **BLOWER:** The high efficiency blower wheel provides up to 3600CFM airflow. It is dynamically balanced for smooth and quiet operation.
17. **BUZZER:** The buzzer will sound a 10-second tone immediately before the motor contactor is energized.

B. STANDARD DUCTWORK

1. **HEAT DUCT:** The first section of ductwork attached to the main HAB unit. This duct contains the burner, air flow switch, spark igniter and the duct pressure sensor.
2. **FLEX DUCT:** Connects the heat duct to the offset duct. It is a section of flexible duct, 30" long, enclosed in an insulated sheet metal wrapper.
3. **HEAVY DUTY OFFSET DUCT:** Connects the flex duct to the tie outlet duct. This duct provides an 8" offset and encloses the air mixer.
4. **TIE OUTLET DUCT:** The outlet duct extends under the rails in place of a tie and directs the airflow to the point nozzles and track ducts. The rail attaches to the duct using tie plates and E clips. The tie plates are electrically insulated from the rail using an insulating kit. There are six openings in the top for point nozzles and track duct nozzles. Refer to drawing 9528-4805 and 963N32902 for the duct layout.
5. **TRACK DUCTS:** These ducts rest on brackets on the ties and the outlet duct. They are installed over the track duct nozzles. The track ducts consist of a 5' point, a 5' mid, and 10' sections to complete the desired length.

6. **TRACK DUCT NOZZLE:** Attaches to the inner two rectangular openings on the top of the outlet duct. Directs airflow down the length of the switch through the track ducts.
7. **TRACK DUCT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0027 for proper installation.
8. **QUICK CHANGE NOZZLE PLATE:** This plate allows for quick removal or installation of nozzles to the tie duct, by simply loosening of four bolts the nozzle assembly can be removed or installed.
9. **TRACK DUCT SUPPORT BRACKET:** These brackets are used to secure the track duct in position. Refer to drawing 92774.
10. **SWITCH POINT NOZZLE:** These nozzles direct heated air down the switch point. They are mounted on the outlet duct. They can be adjusted for proper airflow direction. Nozzles may be shortened by up to 10” for proper fit.
11. **POINT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0021 for proper installation.

C. OPTIONAL DUCTWORK

1. **EXTENSION DUCTS:** Extension ducts of various lengths are available to meet specific requirements. These are insulated and enclosed in a metal wrapper. Make sure the duct is mounted in the correct orientation, as there is an access opening underneath the insulating wrapper cover. If additional duct extensions are required, this assembly can be added between the outlet duct and the offset duct.
2. **7’ TRACK DUCT:** These track ducts are seven feet long. They are often mounted outside of the track near the switch machine. A kit is available (P/N 9278-0270) that includes a 7’ track duct, a track duct nozzle and a track duct isolation kit.

OTHER DUCTWORK ASSEMBLIES ARE AVAILABLE. CONSULT THE FACTORY FOR SPECIAL DUCTWORK NEEDS.

(INTENTIONALLY LEFT BLANK)

III. INSTALLATION

INSTALLATION SHOULD BE DONE IN THIS ORDER:

- A. TIE DUCT OUTLET DUCT/OFFSET DUCT
- B. MAIN HAB UNIT/FLEX DUCT
- C. POINT NOZZLES AND TRACK DUCTS
- D. GAS
- E. CHANGING THE GAS ORIFICE
- F. ELECTRICAL

**PLEASE READ THROUGH THE ENTIRE
INSTRUCTIONS BEFORE BEGINNING INSTALLATION.**

A. TIE DUCT

1. Remove the appropriate tie. Choose the tie that will result in the point nozzles being as close to the switch point as possible without interfering with normal switch operation. The distance from the center of the tie duct to the end of the point nozzles is 33". If necessary, up to 10" may be cut off each point nozzle.
2. Remove sufficient ballast to provide at least 14" clearance from the bottom of the rails.
3. Carefully slip the tie duct under the rails and position it so that the rails are directly above the tie plates. Ensure that the tie duct is centered between the adjacent ties.
4. Place a rubber pad on the tie plate, then using a suitable lever, raise one end of the tie duct until the rail lies correctly on the pad on the tie plate. Place two e-clip insulators, one on each side of rail, in place and then fasten the rail to the tie plate using two of the four 927248 rail clips. Use a heavy hammer or maul to drive the clips securely into place.
5. While keeping the tie duct supported in place, firmly pack ballast under the tie duct from the rail out to the end.
6. Repeat steps 4 and 5 for the other end of the tie duct.
7.
 - a. Remove the end flange plate nearest the HAB by loosening the six retainer bolts.
 - b. Install the two-foot heavy duty offset duct (P/N 9278-3403) to the tie duct using hardware and gasket supplied with the offset duct.
8. Firmly repack ballast under the entire tie duct.

B. BUNGALOW PLACEMENT

1. Attach the 2' flex duct (P/N 9528-5222) to the flame duct using the bolt and gasket kit from the flame duct.
2. Attach the 2' offset duct (P/N 9528-3103) to the flex duct on the flame duct, using the bolt kit from the offset duct.
3. Position the bungalow to line up with the 2' heavy duty offset duct and the 2' flame duct (Refer to Drawing #963N32902).
4. Connect the heavy duty offset duct to the offset duct using the bolts and gasket provided with the offset duct, and level the bungalow.
5. Adjustable Air Intake. To start the GHAB in a new location, set the intake screen in the closed position. If there proves to be a moisture problem where frost builds up on the intake screen, the screen can be set in the open position to improve the air intake to the GHAB.
6. The airflow switch differential setting is factory set on "D" which is for elevations below 2000 ft. If your location is set at a higher elevation, this differential setting will need to be adjusted. Adjust per the following instructions:
 - a) Remove the galvanized cover over the airflow switch.
 - b) Remove the cover from the airflow switch.
 - c) Adjust the differential wheel on the base of the airflow switch as follows:

Below 2000 ft elevation, set Airflow Differential Wheel to "D"

Below 4000 ft elevation, set Airflow Differential Wheel to "C"

Below 6000 ft elevation, set Airflow Differential Wheel to "B"

Above 6000 ft elevation, set Airflow Differential Wheel to "A"

C. POINT NOZZLES AND TRACK DUCTS

REFER TO DRAWING 963N32902 FOR TRACK DUCT AND POINT NOZZLE POSITIONS.

1. Attach switch point nozzles to the openings in the outlet duct. Position nozzles for proper airflow direction. Instructions are included in the isolation kit (P/N 9278-0021) used with the point nozzles.
2. Attach track duct nozzles to the outlet duct, observing airflow direction. Refer to instructions included with the isolation kit (P/N 9278-0027).
3. Assemble the individual track duct sections into two complete track duct sections. The mid and heel sections contain splices wrapped around the outside of the duct. Unhook the clips to remove the three cover pieces. The bottom can now be removed from the duct.

To assemble the splice:

- a. Center the bottom splice piece on the seam between the two track ducts.
 - b. Connect the center cover piece over the seam. (NOTE: The center cover piece has slots to contain the bolts on the track duct).
 - c. Finally connect the two end cover pieces.
4. Lay the track ducts on the rail ties alongside where they will be installed.
 5. Refer to the drawing 92774. Place the track duct support brackets in position on the ties so that one is near the heel end and one near each joint. Use the lag bolts to fasten the brackets in place. Lay the track duct on the bracket bases. Place the hold-down straps over the track ducts. Attach the hold-down strap to the track duct support brackets by inserting the spring clip into the strap.
 6. Push in the square knockouts in the track ducts where airflow is desired. The knockout should be pushed in and bent completely so that no portion of the knockout obstructs the airflow in the duct. Knockout tabs that are not bent back completely will obstruct the airflow as it moves through the track duct resulting in reduced air pressure and airflow further along the track duct.
 7. Inspect the track duct nozzles for proper operation. The damper plate should rotate without binding. Ensure that the damper plate is in the proper position, then tighten the locking nut. Ensure that the damper plate is locked firmly in place.

D. GAS CONNECTION



When tightening gas line fittings or components to the HAB unit be sure that you do not rotate the pipe that enters the blower unit. This could cause the gas control valve inside the blower unit to rotate also. Please reference the label attached just above the pipe that enters the blower unit.

1. The following items are available as optional items
 - * High pressure regulator (P/N 45103)
 - * 36" Gas tank "pigtail" (P/N 60127)
 - * 12" Gas tank "pigtail" (P/N 45038)
 - * Remote gas valve (P/N 45036)

NOTE: A propane package is available (P/N 9458-0100) that includes a 36" tank pigtail, high pressure regulator, gas line strainer, gauge, remote solenoid valve in a pole mount enclosure, and a 4X4X8' post.

FOR NATURAL GAS INSTALLATION PROCEED TO STEP 5

2. *Install the copper "pigtail" to the propane tank. Each end of the pigtail is a reverse thread.
3. *Install the high pressure (red) regulator to the pigtail. Remember reverse thread on the pigtail connection.
4. Install the "Y" strainer downstream (but near) the high pressure regulator, or natural gas source.
5. *Install the remote gas valve downstream (but near) the "Y" strainer. Electrical connections from the remote gas valve are made to terminal posts TS1-10 (115vac) and NEUTRAL on the HAB unit. The valve must be mounted with the inlet and outlet horizontal, and the coil upwards.
6. Install adequate size gas pipe from the remote tank location to the main HAB unit. Check with local gas supplier for sizing recommendations.
7. The remaining gas line components are attached to the HAB unit, as shown on drawing R9500-0027. Remember to position the regulator vent fitting facing sideways so that moisture will not enter the regulator.
8. If you are having problems adjusting the gas pressure low enough, the spring in the low pressure regulator must be changed. To change the spring, complete the following steps:
 - a. Try adjusting the low pressure regulator for proper fuel pressure. If it can't be adjusted, follow instructions listed below for changing the regulator spring.
 - b. Turn power off and close manual gas valve.

- c. Remove the plug on top of the regulator.
- d. Turn the white plug inside the regulator counter-clockwise until it can be removed.
- e. Replace the violet spring with the red spring provided in the gas accessory kit.
- f. Replace the top plug.
- g. Go to gas pressure menu to adjust.
- h. Turn the manual gas valve to “ON” position and turn power on.
- i. Place the AUTO/OFF/FORCE switch (SW1) in the “FORCE” position.
- j. Place the burner control select in the hi-only position.
- k. After the 30-second pre-purge period, the unit will ignite. Check the gas pressure display. Adjust the white plug in regulator until the display reads 11” water column for propane or 7” water column for natural gas. NOTE: Clockwise to increase pressure, counter-clockwise to decrease pressure.
- l. Let the GHAB run for a 10 minute period.
- m. After the 10 minute period, take temperature readings at both point nozzles.
- n. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
- o. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1” w.c. at a time) until you reach the desired temperature.
- p. Replace the top plug.

* OPTIONAL ITEMS AVAILABLE FROM RAILWAY EQUIPMENT CO.

(INTENTIONALLY LEFT BLANK)

E. CHANGING THE GAS ORIFICE

1. This unit uses an orifice plate instead of individual orifices. The orifice plate contains the orifices for both propane and natural gas for both stages of operation.

CAUTION

2. Make sure the main circuit breaker is in the OFF position and the manual gas valve is closed before working on the HAB unit.
3. Remove the bottom intake cover from the HAB unit.
4. On the right hand side of the gas assembly you will see the orifice plate. The orifice plate has a tab facing out that says NG for natural gas or LP for propane. This will tell you how the unit is currently set up.
5. To change from one fuel to the other:
 - a. There are four bolts on each gas coupling plate. You need to fully remove the top two bolts on each coupling plate and you need to back out the bottom two bolts on each coupling plate 1/2 to 3/4 of an inch.
 - b. On the inlet manifold (left hand side of the gas assembly) you need to remove the two bolts securing the manifold to the outside of the GHAB.
 - c. You can now carefully slide the gas assembly to the left to free the orifice plate.
 - d. The orifice plate can be pulled away from the outlet manifold and up and out. NOTE: Take care removing the orifice plate so you don't damage the O-rings.
 - e. The orifice plate can now be flipped over for the other fuel and re-inserted in between the gas coupling and outlet manifold. NOTE: Take care replacing the orifice plate so you don't damage the O-rings.
 - f. Slide the gas assembly back to the right and insert the top bolts on the coupling plates.
 - g. Verify the tab facing out on the orifice plate is now the correct fuel.
 - h. Evenly tighten the eight bolts on the coupling plates.
 - i. Replace the bolts on the inlet manifold bracket (outside of GHAB).
 - j. Re-install the lower intake cover.
6. Turn on power and manual gas valve.
7. Test unit and check regulator adjustment and output temp.

F. ELECTRICAL CONNECTION

1. Power conductors should be brought into the large LB box on the side of the bungalow.



CAUTION

THE 230VAC SUPPLY LINES SHOULD BE SIZED TO ALLOW FOR THE AC MOTOR START-UP CURRENT WHICH IS 128 AMPS. UNDERSIZED CONDUCTORS AND OR LONG WIRE RUNS WILL DAMAGE THE MOTOR.

2. **INCOMING POWER:** The incoming power should be connected directly to the lugs in the main breaker box. The neutral should be connected to the neutral bus. The neutral should be grounded at the source.
3. **GROUND:** The breaker box ground should be tied directly to earth ground.

SPECIAL NOTE: THE CONTROL CHASSIS AND THE REST OF THE MAIN HAB UNIT MUST BE CONNECTED TO GROUND/NEUTRAL. THE RUBBER PAD BETWEEN THE RAIL AND TIE PLATE ALONG WITH THE E-CLIP INSULATORS WILL INSULATE THE MAIN UNIT FROM THE TRACKS.

4. **CONTROL INPUT:** Remote operator control can be provided by a circuit closure applied between terminal posts TS1-1 and TS1-2.
5. **INDICATION:** Reply indication can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-3 and TS1-4 will provide a dry contact closure for indication when the unit is operating under remote control.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC indication is now present on post TS1-3 with common at terminal post TS1-6.
6. **FAIL:** Reply fail can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-5 and TS1-4 will provide a dry contact closure for fail when the unit is in a fault mode.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC fail is now present on post TS1-5 with common at terminal post TS1-6.

7. DUCT WORK OVERTEMP SENSOR (P/N 9338-0356):

- a. On the flex duct, remove the two bolts holding down the overtemp sensor cover. Install the sensor into the duct using the two bolts that were removed.
- b. Run conduit along duct work back to HAB enclosure; attach connector to enclosure knock out; tighten. (NOTE: Cut conduit to length if needed.)
- c. Run wires from sensor into enclosure and plug connector into OVERTEMP (RED) J10 located on the control module.
- d. Use five clamps (P/N 60030) to secure conduit to the side of duct work using existing screws.

8. RAIL TEMP SENSOR (P/N 9508-0416)

- a. Attach the magnetic sensor to the bottom of the stock rail approximately four feet ahead of the point nozzle.
- b. Run wires from sensor into enclosure and plug connector into RAIL TEMP (YELLOW) J11 located on the control module.

IV. CONTROL MODULE

A. DESCRIPTION

The hot air blower control module contains all of the elements and functions necessary for advanced snow melter operation. The unique dual-chip microcomputer has been programmed with logic and timing sequences to provide complete heater control as well as operational control and system interface. Some of the many features included in the control module are:

- Auto-Off-Local selector switch
- Adjustable air temperature setting
- Built-in snow detector (Requires Optional Snow Detector Head)
- Adjustable start-up delay sequence
- Adjustable run timer for timed or continuous operation
- Adjustable snow detect timer for use with optional snow detector
- Operator control and indication
- Remote fault reset
- Audible tone before blower start-up
- Input/output status indication lights:

Inputs:

- Air temperature
- Remote Control
- Moisture Detector One or two snow detector(s) (Optional)
- Airflow switch
- Flame Sensor
- Rail Temp Sensor
- High Temp Sensor

Outputs:

- Blower motor
- Ignition spark
- External Gas Valve
- Hi Gas valve
- Low Gas valve
- Indication
- Fail

Flame safety control:

- 10 second tone before blower turn on
- Air flow proving
- 30 second pre-purge before ignition
- Direct spark ignition
- 10 second maximum ignition period before lock-out
- Rectification type flame rod sensor
- Automatic retry on flame loss
- 4 minute post-purge period after gas valve turn-off

Automatic reset

Fault if flame does not go out after gas valve is commanded off

- B. SET-UP AND ADJUSTMENTS:** To change settings and adjust times do the following:

Mode Up Push Button

Pushing the Mode Up push button (PB2) will cycle up through the menus. Each time you press the mode up push button you will advance one menu selection.

Mode Down Push Button

Pushing the Mode Down push button (PB3) will cycle down through the menus. Each time you press the mode down push button you will move down one menu selection.

Increase Values

The Increase Values push button (PB4) allows you to increase the values.

NOTE: Values will be saved.

Decrease Values

The Decrease Values push button (PB5) allows you to decrease the values.

NOTE: Values will be saved.

The following is the layout of the controller menu:

Controller Menu

The controller has 6 menus categories, they are:

1. Status
2. Fault History
3. Set Points
4. Factory Defaults

Menu Selection

To select the desired menu, press the Mode Up or Down button until *****MENU SELECT***** is displayed, on line 1, and then use the Increase or Decrease Value button to select the appropriate menu. Once the appropriate menu is selected, use the Mode Up or Down buttons to view the contents of the menu.

NOTE: Use the Increase or Decrease Values button to change setpoint values.

STATUS MENU

- 1. OUTSIDE TEMP AND PRESET VALUE**
Displays the current ambient temperature and temperature preset value. If ambient temperatures is below the preset value, the unit will start if requested.
- 2. MOTOR CURRENT AND MOTOR VOLTAGE**
Motor current displays the actual motor current in amps while motor is running. Motor voltage displays the actual motor voltage in volts while motor is running.
- 3. GAS PRESSURE AND DUCT PRESSURE**
Gas pressure is the actual differential pressure at the burner. The unit of measure is inches of water ("H₂O). To view gas pressure, the burner should be burning. The correct setting should be 11"H₂O for propane, be 7"H₂O for natural gas. While adjusting, the burner should be in high only. Adjust regulator to change gas pressure value. Duct temperature is the actual duct temperature in degrees F or C.
- 4. FLAME CURRENT**
Flame current displays the actual flame current in micro amps while a flame is present.
- 5. RAIL TEMP AND DUCT TEMP**
Rail temperature is the actual rail temperature in degrees F or C. Duct temperature is the actual duct temperature in degrees F or C.
- 6. AC FREQUENCY**
Displays the frequency of the line voltage.
- 7. TOTAL GAS AND RESET GAS**
Total gas displays the calculated amount of gas that has been used. The unit of measure is gallons if propane is selected. The unit of measure is cubic feet if natural gas is selected. Reset gas is the same as total gas except it can be reset. To reset, press the decrease value button.
- 8. HOUR METER AND RESET HOUR**
Hour meter displays the total hours that GHAB has been running. Reset hour is the same as hour meter except it can be reset. To reset, press the decrease value button.
- 9. TANK LEVEL, BAT AND TEMP**
Tank level displays the actual level of propane tank in percent full (optional tank level monitor must be installed). Bat displays the battery level of the tank monitor. Temp displays the temperature in the battery monitor.

FAULT HISTORY MENU

NOTE: Some faults may not show in Fault History until there is an actual fault.
Press the decrease or increase value button to reset fault count.

- 1. FLAME LOSS AND FLAME ON**
Flame loss counter is total count of flame loss faults. Flame on counter is total count of flame on faults.
- 2. SAIL LOSS AND SAIL ON**
Sail loss counter is total count of sail loss faults. Sail on counter is total count of sail on faults.
- 3. MOTOR V FAULT AND OVERLOAD**
Motor volts low or high counter. Overloads counter is total motor overloads faults.
- 4. GAS VALVE LEAK AND PRESSURE FAULT**
Gas valve counter is total count of leaking gas valve faults. Gas pressure low or high counter.
- 5. DUCT PRESS FAULT AND VAP. PRESS LOW**
Duct pressure fault counter is total count of duct pressure faults. Vaporization low fault counter is total count of vaporization low faults.
- 6. MOTOR CURRENT AND COMM RESET**
Motor current fault is total count of motor current faults. Comm reset fault is total count of communication reset faults.
- 7. DAY COUNTER AND POWER UP**
Day counter is the number of days the unit has been powered up. Power up counter is the total number of times the control module has been turned on.
- 8. OVER TEMPS WARNING COUNTER**
Counts the total number of Over Temp warnings.
- 9. AUTO OVERTEMP RESET COUNTER**
Counts the total number of times the Over Temp was reset.

SET POINTS MENU

1. USER LEVEL

The options are BASIC and ADVANCED.

Basic – access to basic menus.

Advanced – access to advanced menus (requires password).

2. PASSWORD

A password is needed to access the advanced menus. To enter in the password, use the increase or decrease value buttons. Password 5 allows advanced menu items to be changed.

3. SELECT TEMPERATURE SETPOINT

The ambient temperature below which the unit will energize is set on this screen. When the outside temperature is below this setpoint, the unit will be allowed to operate if requested. The factory default is 38° F (3° C). The range is from 0° F to 100° F (-18° C to 38° C).

4. SELECT RUN TIMER VALUE

The run timer can be set from 0 to 1000 minutes. If zero is selected, the outputs will operate continuously, until control on is disabled. If another value is selected, the unit will run until the run timer counts down to zero, after which the unit will shut down and drop indication. The unit can be restarted by removing the contact closure between TB2-1 and 2, then reinstalling it. If Run Timer Pulse Mode is activated, the minimum run time value is 10 minutes. The factory default setpoint is 60 minutes.

5. RUN TIMER PULSE MODE

The choices are on or off, factory default is off. When on is selected, a pulse will start run time sequence and continue until run timer has timed out. When off is selected, run timer will time out as long as remote is on. When remote on is removed blower will stop.

6. SELECT SNOW TIMER VALUE

The snow timer can be set from 10 to 1000 minutes. The snow time starts counting down when the moisture detector no longer sees snow. The factory default setpoint is 60 minutes.

7. SELECT SNOW SENSOR SPEED

Snow sense speed sets the delay time after the moisture detector sees moisture and starts the snow cycle. The delay time can be set from 1 to 60 seconds. The moisture sensor must see moisture for entire time to start cycle.

8. SELECT SNOW INDICATION

The choices are OFF or ON. With snow indication off, indication will remain off during snow time if no faults are present. With snow indication on, indication will remain on during snow time if no faults are present.

9. SELECT START DELAY VALUE

The start delay timer can be set from 0 to 250 seconds in 10 second increments. It is used to delay the start of GHAB so when several blowers are at the same location they do not start at same time.

10. SELECT BURNER OPERATION

The choices are LOW, HIGH, AUTO, AUTO OFF.

Hi Only – 100% BTU output with or without Rail Sensor.

Low Only – 50% BTU output of Hi with or without the rail sensor.

Auto – Switches between high and low dependant on the rail & duct temperature sensor and setpoint. Note: If no rail sensor is connected, it will run at low (50% output). Units with only single stage installed, should select high only.

Auto Off – When rail temperature reaches the rail temp setpoint, the GHAB will shut down. When the rail temperature lowers to the ambient temperature setpoint, the GHAB will start again.

11. OPERATION MODE

The choices are NATURAL, PROPANE, COLD AIR, COLD AIR/PROPANE, COLD AIR/NATURAL.

NATURAL – The GHAB’s burner is fueled by natural gas.

PROPANE – The GHAB’s burner is fueled by propane.

COLD AIR – The GHAB will turn its blower on with air temperature. It will not use a burner.

COLD AIR/PROPANE –The GHAB will turn its blower on with air temperature. It will then turn its propane burner on with moisture or control.

COLD AIR/NATURAL –The GHAB will turn its blower on with air temperature. It will then turn its natural gas burner on with moisture or control.

12. SELECT MOTOR SIZE

The choices are:

2 HP 230V 1PH, 3 HP 230V 1PH, 5 HP 230V 1PH,

2 HP 460V 3PH, 3 HP 460V 3PH, 5 HP 460V 3PH,

2 HP 575V 3PH, 3 HP 575V 3PH, 5 HP 575V 3PH,

2 HP 3PH Drive, 3 HP 3PH Drive, 5 HP 3PH Drive

2 HP 230V 3PH, 3 HP 230V 3PH, 5 HP 230V 3PH.

13. RAIL TEMP SETPOINT

This can be set from 0° F to 280° F (-18° C to 138° C).

- 14. DUCT TEMP SETPOINT**
This can be set from 150° F to 250° F (66° C to 121° C).
- 15. DUCT PRESSURE HIGH SETPOINT**
This can be set from 3" H2O to 30" H2O.
- 16. DUCT PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 5" H2O.
- 17. GAS PRESSURE HIGH SETPOINT**
This can be set from 7" H2O to 30" H2O.
- 18. GAS PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 10" H2O.
- 19. MOTOR CURRENT HIGH SETPOINT**
This can be set from 5 to 100 amps.
- 20. MOTOR CURRENT LOW SETPOINT**
This can be set from 0 to 10 amps.
- 21. MOTOR VOLTAGE HIGH SETPOINT**
This can be set from 250 to 650 volts.
- 22. MOTOR VOLTAGE LOW SETPOINT**
This can be set from 150 to 550 volts.
- 23. AC FREQUENCY HIGH SETPOINT**
This can be set from 0 to 100 Hz.
- 24. AC FREQUENCY LOW SET POINT**
This can be set from 0 to 100 Hz.
- 25. LOCAL WITH/WITHOUT AIR TEMPERATURE**
Sets the local feature to, or not to, be dependant on the air temperature.
- 26. OVERTEMP BYPASS**
With overtemp bypass enable, the unit will not fault if the overtemp sensor is missing. This feature is only for use on units that have a two wire overtemp sensor. Current production units are equipped with a four wire overtemp sensor. **NOTE: BYPASSING THE OVERTEMP SENSOR MAY CAUSE HARMFUL OPERATING CONDITIONS.**
The following steps are required to bypass the overtemp sensor:

- a) Display: MENU SELECT
SETPOINTS
- b) Select: ADVANCED
- c) Enter password: 10
- d) Display screen: OVERTEMP BYPASS
DISABLED
- e) Change to: ENABLED

- 27. SELECT F OR C**
Will change the temperature scale to either Fahrenheit or Celsius.
- 28. AUTO OVERTEMP RESET**
Auto overtemp reset will reset the overtemp once it has been triggered.
- 29. SELECT TANK SIZE**
The choices are no tank sensor, tank heater, 250 gallon increments up to 5,000 gallons. No tank sensor should ALWAYS be selected UNLESS a tank sensor reporting to the module is installed. Note: Tank Size menu is only available if propane is selected.
- 30. TANK SERIAL #**
Tank serial # is the tank level monitor's serial number. This is only used if a tank sensor reporting to the module is installed.
- 31. MACHINE SERIAL NUMBER**
Machine serial # is the serial number of the whole GHAB unit.
- 32. SERIAL NUMBER/MAC**
Shows the MAC address for the unit.
- 33. AMBIENT OFFSET**
Used to calibrate the ambient temperature sensor.
- 34. RAIL OFFSET**
Used to calibrate the rail temperature sensor.
- 35. DUCT OFFSET**
Used to calibrate the duct temperature sensor.
- 36. PROG REV AND DATE**
Shows the program revision and the date it was compiled.

37. BOOTLOADER

The choices are DO NOT RUN BOOTLOADER, START FACTORY DEFAULT BOOTLOADER and START NEW CODE.

DO NOT RUN BOOTLOADER – Will not run the bootloader.

START FACTORY DEFAULT BOOTLOADER – Will run the factory bootloader.

START NEW CODE – Will download and run the new code.

FACTORY DEFAULTS MENU

Factory default is used to place all parameters back to factory default settings.

To restore to factory default:

In the menu selection, select FACTORY DEFAULTS and then press either the up or down mode button. Next press either the increase or decrease value button to restore to default.

AUTO/OFF/LOCAL SWITCH (SS1)

- a) **AUTO:** This position will allow operation by placing a circuit closure across terminal posts 1 and 2. It will also allow operation by an optional snow detector.
- b) **OFF:** If off, GHAB cannot be run from remote or snow detector.
- c) **LOCAL:** If LOCAL without air temp parameter is enabled, placing SS1 in the LOCAL position enables the snow melter regardless of outside air temperature. The snow melter will remain on until LOCAL is turned off. This is useful for hot weather testing.

C. LED STATUS INDICATING LIGHTS

1 AIR TEMPERATURE:

On when the ambient air temperature is below set point.

2 MOISTURE:

On when the optional snow detector sensing head(s) senses moisture.

- 3 **CONTROL:**
On when there is a circuit closure across terminal posts 1 and 2.
- 4 **BLOWER:**
On when the controller has turned on the output to the blower motor contactor.
- 5 **AIRFLOW:**
On when the sail switch in the air stream is sensing adequate airflow.
- 6 **IGNITION:**
On when the controller has enabled the output to the ignition transformer.
7. **HIGH GAS VALVE:**
On when the controller has enabled the output to the high gas valve.
8. **LOW GAS VALVE:**
On when the Controller has enabled the output to the Low Gas Valve.
- 9 **FLAME:**
On when the flame sensing determines that there is proper combustion.
10. **INDICATION:**
On when there is a circuit closure across terminal posts 1 and 2 and the unit is operating, or the air temperature is above the set point. Also may be on when there is a fault condition under snow detector.
11. **FAIL:**
This LED is on when ever a fault is present.

D. OPERATION

With switch SS1 in the “auto” position, the unit can be activated by applying a circuit closure between terminals TS1-1 and 2. If the outside temperature is above set point the unit will not start a snow melt sequence but will turn on the “indication” LED and provide a relay contact closure between TS1-3 and 4 to indicate to the remote station that the unit is operational.

If a circuit closure exists between TS1-1 and 2, and the air temperature is below set point, the unit will begin a snow melt sequence. The unit executes a 0 to 300 sec. time delay depending on the setting of the START DELAY TIMER. Then, a 10-sec. audible tone sounds as a warning that the blower motor is about to turn on.

The airflow switch is checked to see if it is closed. If it is, the blower will display SAIL SWITCH ON FAULT.

If the airflow switch is open the motor will turn on. After the blower motor is turned on, the airflow switch is monitored. It closes if airflow is normal. If it does not close within 10 sec. (or 30 sec. for an AC drive) after blower turn-on, the blower displays SAIL SWITCH OFF FAULT. When the airflow switch closes, a 30 second prepurge time will start. After the prepurge time is completed the gas valve opens, the ignition turns on and the burner is monitored for a normal flame condition. If a flame is not detected within 10 seconds, the gas valve is closed, the ignition spark is removed and the blower displays NO FLAME DETECTED FAULT.

If a normal flame condition is detected the “indication” contact closure is established between TS1-3 and 4. The unit will run for a period of time determined by the setting of the RUN TIMER. If the run timer is set at “0” the unit will continue to run until the circuit closure between TS1-1 and 2 is removed.

If the blower is equipped with the two stage gas valve option and the rail temp sensor is installed, then under normal operation when the rail reaches the preset temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the rail falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity.

If the blower is equipped with the two stage gas valve option and the duct temp sensor is installed, then under normal operation when the duct reaches the preset duct temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the duct falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity. If the duct temp sensor sees a temperature above 325 ° F (163° C) both gas valves will be disabled. This prevents over temps.

There is a burner control adjustment available in the control module adjustments that allow the burner to be set to high only, low only or automatic controlled by the rail temp sensor. If the two-stage option is not installed, the burner control switch should be set to high only. Refer to (SET UP AND ADJUSTMENTS) in Section IV 8.

SNOW DETECTOR OPERATION. If the unit is operating with one or two optional snow detector assemblies and moisture is detected by either (or both), a snow melt sequence will begin, provided that the air temperature is below the set point. The unit will start as described in Section IV Part B under (Select Snow Timer).

E. FAULT CONDITIONS

1. SAIL SWITCH ON FAULT:

During startup the processor checks the status of the airflow switch. If the airflow switch is closed or shorted the blower motor will turn on and the blower will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is closed it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for.

2. SAIL SWITCH OFF FAULT:

Sail switch off fault is set when blower is running and air flow switch is open. After the fault is set the blower motor will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is open it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the sail switch is free to move and if there are any obstructions in duct work.

3. NO FLAME DETECTED FAULT:

No flame detected fault is set when blower is running and air flow switch is closed with gas valve open. If no flame is detected within 10 seconds the fault will be set. After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the flame rod for proper operation. If no flame is present it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

4. FLAME DETECTED ON FAULT:

Flame detected on fault is set when blower is running and air flow switch is closed with gas valve closed. If flame is detected before gas valve is opened the fault will be set.

After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the flame rod for proper operation. If flame is present with gas off it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

5. GAS VALVE FAILURE:

During the blower shutdown operation if the unit senses flame after the post-purge, the unit will not shutdown. Instead it will go into gas valve failure mode. In this mode the blower continues to run, the reply will also indicate a problem, and the buzzer will sound. The unit will lock out all other operations and will not be able to be reset except at the unit itself.

6. CHECK FUSE # 1 24 VDC POWER:

Fuse # 1 is tripped. Check the following circuits:

- a. Overtemp switch and wiring.
- b. Check TS1-2 +24 control on wiring.

7. CHECK FUSE # 2 IGNITION TRANSFORMER:

Fuse # 2 is tripped. Check the following circuits:

- a. Ignition transformer and wiring.

8. CHECK FUSE # 3 GAS VALVE / SAIL SWITCH:

Fuse # 3 is tripped. Check the following circuits:

- a. Check Sail switch and wiring.
- b. Check hi and low gas valve and wiring.
- c. Check external gas valve and wiring.

9. CHECK FUSE # 4 BLOWER MOTOR:

Fuse # 4 is tripped. Check the following circuits:

- a. Check blower motor contactor and wiring.

10. CHECK FUSE # 6 SNOW HEAD # 1:

Fuse # 6 is tripped. Check the following circuits:

- a. Check snow detector head # 1 and wiring.
- b. Check Gas pressure sensor and wiring.
- c. Check Duct pressure sensor and wiring.

11. CHECK FUSE # 7 SNOW HEAD # 2:

Fuse # 7 is tripped. Check the following circuits:

- a. Check snow detector head # 2 and wiring.
- b. Check Sail switch and wiring.

12. CHECK FUSE # 9 ANALOG 5VDC:

Fuse # 9 is tripped. Check the following circuits:

- a. Check 5V supply for pressure sensor.

13. CHECK FUSE # 10 PRESSURE/BAT CHARGER:

Fuse # 10 is tripped. Check the following circuits:

- a. Check pressure sensor.
- b. Check 24V supply for battery backup.

14. OVERTEMP FIX PROBLEM PRESS DECREASE:

Overtemp sensor has tripped. If the temperature inside the Tie duct exceeds 375 degrees F, it will cause the ductwork overtemp circuit to trip, shutting down the HAB system. Only pushing the decrease value push button will reset the unit, giving opportunity to check the cause of the overtemp condition.

15. OVERTEMP FIX PROBLEMPRESS DECREASE ___ MIN:

The overtemp sensor has tripped. The HAB system will shut down for some time period then it will reset the unit. NOTE: AUTO OVERTEMP RESET must be enable in order to see this fault.

16. OVERTEMP WARNING RESTART IN ___ SEC:

If the temperature is close to overtemp value, the unit will restart in a certain time period.

17. OVERTEMP MISSING INSTALL OVERTEMP:

Caused my missing overtemp sensor.

18. MOTOR VOLTAGE LOW:

Motor voltage low is caused by inadequate electrical service supply. During motor start up if motor voltage drops below 190 VAC, the motor will eventually be damaged. If this under-voltage occurs, an error will be set. Press decrease value button to clear the fault.

19. MOTOR VOLTAGE HIGH:

Motor voltage high is caused by high motor voltage. Can be caused by high voltage from the electric company.

20. MOTOR OVERLOAD, RESET OVERLOAD DEVICE:

High motor current will trip the motor overload on the control panel. This device is connected to the bottom of the motor contactor on the control panel. Reset by pressing the red button on the device. Check unit for high motor current, bad bearings, or obstructions in the blower wheel.

21. MOTOR CURRENT LOW:

Caused by low motor current.

22. MOTOR CURRENT HIGH:

Motor current high is caused when sensed current is 3 amps over motor name plate for 20 seconds. Check motor for high current, bad bearings, obstruction in blower wheel.

23. GAS PRESSURE LOW:

Gas pressure low is caused by supply gas pressure during operation dropping to a low level. Check gas delivery system.

24. GAS PRESSURE HIGH:

Gas pressure high is caused by high gas pressure going to the burner. Check gas delivery system. Adjust the regulator on the gas delivery system to lower the gas pressure.

25. DUCT PRESSURE LOW:

Duct pressure low is caused by not enough duct back pressure. Possible causes are missing flame cover or missing duct work.

26. DUCT PRESSURE HIGH:

Duct pressure high is caused by too much duct back pressure. Possible causes are duct work obstructions

27. PROPANE TANK LOW WARNING FILL TANK:

Propane tank low is caused by low propane tank level. Note propane tank level monitor must be installed and setup, for this warning to appear.

28. TANK VAPORIZATION PRESSURE LOW WARNING:

Tank vaporization pressure low warning is caused by low tank temperatures.

29. UTILITY POWER LOST:

Utility power lost is caused by no incoming AC voltage. Must have a battery backup in order to receive this fault.

(INTENTIONALLY LEFT BLANK)

V. SEASONAL MAINTENANCE

A. SPRING:

1. Turn off gas source.
2. Turn off electric power at source.
3. Disconnect and remove the control module. Store in a clean, dry place.
4. Turn off manual gas valve.

B. FALL

1. Check all ductwork for clear airflow. Ensure that the point and track duct nozzle screens are not damaged and are completely covering the openings. Make sure that no debris or rodents have obstructed any area of the ductwork.
2. Inspect the track duct nozzles for proper operation. The damper plate should rotate without binding. Ensure that the damper plate is in the proper position, then tighten the set screws and locking nut. Ensure that the damper plate is locked firmly in place.
3. Remove the flame duct cover. Check the burner. Make sure the spark igniter plug and flame rod are in good, clean condition. Check the wiring to make sure rodent or vibration have not damaged the insulation.
4. Check the airflow sail switch to make sure it is operating properly.
5. Replace the flame duct cover.
6. Install the control module and connect the wires.
7. Turn on the gas source.
8. Turn on the manual gas valve.
9. Turn on the electric power at source.
10. Perform the gas pressure regulator adjustment procedure as described on the following page of this manual.
11. Perform a flame failure test:
 - a) Place switch SS1 in the FORCE position.
 - b) Turn off the manual gas valve.
 - c) Turn on the main circuit breaker.
 - d) After 40 seconds (plus any start delay period) the fault message NO FLAME DETECTED FAULT should be displayed. If the fault does not appear, the control module is faulty and should be replaced.
12. Check the flame current. Refer to Section IV, Control Module (B), SET-UP AND ADJUSTMENT 18A.
13. Check the air temperature for proper setting.

VI. LOW PRESSURE REGULATOR ADJUSTMENT/OUTPUT TEMP TEST

- A. Place switch SS1 in the FORCE position.
- B. Turn the manual gas valve to “ON” position and turn power on.
- C. Place the burner control in the hi-only position. Refer to Section IV SET-UP AND ADJUSTMENTS b. 7.
- D. After the 30-second pre-purge period, the unit will ignite. Check the gas pressure value. Adjust the white plug in regulator until the gauge reads 11” water column for propane or 7” water column for natural gas. NOTE: Clockwise to increase pressure, counter-clockwise to decrease pressure.
- E. Let the GHAB run for a 10 minute period.
- F. After the 10 minute period, take temperature readings at both point nozzles.
- G. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
- H. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1” w.c. at a time) until you reach the desired temperature.
- I. Replace the top plug.
- J. Return all switches to their normal operating position.

VII. TROUBLESHOOTING

A. UNIT DOES NOT START

1. Check circuit breaker.
2. Check control fuse. The control fuse is an auto resettable type fuse. To check, turn the main circuit breaker off for one minute, then turn back on
3. Check for 18VAC between the following points:
TS1-6 and TS1-7
TS1-6 and TS1-8.
Change T1 control transformer if either measurement is incorrect.
4. Check for air temperature below set point.
5. Is the control module programmed for a start-up delay?
6. Monitor the fault display on the control module.
7. Turn the circuit breaker off, then reset the motor overload relay. The motor overload relay is adjustable. It should be set for the motor name plate current.
8. Push the RESET Button (PB1).

B. UNIT DOES NOT MAINTAIN OPERATION

1. Monitor the flame current as described in section IV B. 18.
2. Check the fuel supply. Refer to Section VID.
3. Check 230VAC and 115VAC from either leg to the center tap neutral (with the unit running). It must be within +10% to -10%.
4. Check the burner. The burner must be clean and free of carbon.
5. The flame rod should be clean and secure. Refer to section D for flame current test.
6. Check the wire from the flame rod to the control module for continuity. Pull the white plug connector on the lower right side of the control module. Use an Ohmmeter to measure continuity from the terminal of the flame rod to the white connector. The reading should be less than 1 ohm.

C. LOW HEAT LEVEL

1. Perform a regulator adjustment/output temp test refer to Section 5.
2. Check the fuel supply.
3. Make sure the burner is clean.
4. Make sure the orifice plate is installed for the fuel being used.
5. Check the low pressure regulator.
6. Check to see if the burner control is on low only or if it is in auto and the Rail Temp Sensor setting is forcing it to low output.

D. LOW AIRFLOW

1. Check for obstructions in all ductwork and the air intake.
2. If there is frost buildup on the air intake screen, move the screen to the “open” position.
3. Check the voltage and current levels on the blower motor.
4. Make sure knockouts on the track duct are pushed all the way back in the track duct.
5. Check the spacing between the inlet cone and the blower wheel. The gap should be less than 1/16 of an inch.

E. GAS VALVE



CHECK THE AREA TO BE SURE THERE ARE NO LINGERING GAS FUMES BEFORE DOING ANYTHING WHICH MAY CAUSE A SPARK!

1. Turn off gas to the blower.
2. Turn off power to the blower.
3. Check the gas valve for obstructions.
4. Check the gas valve for proper operation.

F. HIGH HEAT LEVEL

1. Check for proper orifice installation.
2. Perform the low pressure regulator and Temp Test found in Section VI.

VIII. SNOW DETECTOR

A. SNOW DETECTOR INSTALLATION

1. The snow detector sensing circuitry is contained within the control module. All that is required for snow detector operation is to connect the sensing head(s).
2. Either one or two sensing heads may be used.
3. Each sensing head has three lead wires; black, white, and green. Connect as follows:
 - a) green: one or both connected to TS1-6.
 - b) black #1: connected to TS1-7.
 - c) black #2: connected to TS1-8.
 - d) white: one or both connected to TS1-9.

NOTE: Refer to the diagrams when connecting wires for the sensing heads. It is important to properly connect the sensing head wires. Improper connection of the sensing head wires may result in damage to the control module and/or the sensing head.

4. To operate more than one HAB unit from a HAB unit that is controlled by a snow detector(s), connect terminal posts #6 together and terminal posts #9 together. (Do not connect terminal post #6 to terminal post #9.) When connecting snow detectors to more than one HAB unit, first connect one HAB. Then connect the snow detector to one more HAB. If the snow detector does not operate properly, exchange L1 and L2 on the newest HAB circuit breaker. NOTE: BE SURE L1 AND L2 ARE DE-ENERGIZED BEFORE EXCHANGING THEM. Continue to add HABs to the snow detector in the same manner until all the desired HABs are connected. DO NOT EXCEED 200' CABLE LENGTH (18 AWG WIRE).
5. The sensing heads should be mounted in a vertical position.
6. Experience has shown that positioning a snow detector sensing head in the switch area between the ties and between the switch point and the track duct is effective. A second sensing head is then placed away from the switch area, such as on a bungalow or pole.

B. SNOW DETECTOR OPERATION

NOTE: A snow detector sensing head only detects moisture. With temperature sensing capability, the HAB unit assumes moisture is due to snow when the air temperature is below set point.

All operating functions are similar to remote operation with the following exceptions:

1. **INDICATION:** During normal operation under snow detector control, the indication contact across terminal posts 3 and 4 will not be closed.
2. **TIMED OPERATION:** The snow detector has many different time scenarios . Refer to Section IV Part B to determine which scenario best meets the needs in your location.
3. **RUN TIMER:** During remote operation, if the snow detector senses moisture, the unit will operate according to the settings. The unit will then operate for the duration of the run timer setting.
4. **FAULT CONDITION:** A fault condition under snow detector control will cause the indication contact across terminal posts TS-3 and TS-4 to close. To reset the unit after a fault condition, momentarily apply a circuit closure between terminal posts TS-1 and TS-2 with Ss1 in the Auto position. The unit may now be operated either under remote control or snow detector control.

C. SNOW DETECTOR MAINTENANCE

The snow detector sensing head contains a small, self-regulating heater that will melt snow or ice into water. The sensing head relies on moisture to create a low resistance circuit path. The heater will also cause the moisture to evaporate within a short period. If the surface becomes non-conductive due to contamination by grease or oil, the sensing head will not operate. To ensure effective and dependable snow detector operation, it is important to inspect the sensing heads frequently and clean them thoroughly if necessary.. Use a solution of water and mild detergent or isopropyl alcohol to clean the sensing grid. Use a clean, dry cloth to wipe the grid. Make sure there is no residue left on the surface.

D. SNOW DETECTOR TROUBLESHOOTING

NOTE: A newly-installed snow detector sensing head should operate 15-20 minutes to allow the internal heater to reach normal operating temperature.

1. NO HEAT ON THE SENSING HEAD

- a. Check for voltage between terminal post 6 and 7, and between terminal post 6 and 8. It should be 18VAC ± 2VAC. If not:
 - (1) Check the display on the control module.
 - (2) The control transformer may be defective.
 - (3) There may be a bad circuit connection.
- b. Remove the black and the green lead wires from the terminal posts. Check resistance between them. If resistance is greater than 10 ohms, the sensing head is defective and should be replaced.

2. DOES NOT DETECT MOISTURE

- a. Clean the snow detector as described above.
- b. If unit still does not detect moisture, check the wiring connections between detector head and terminal posts.
- c. If unit still does not detect moisture, replace the control module with a known good control module. If still not operating properly, replace the sensing head.

NOTE: If a snow detector head becomes saturated with moisture, it can sometimes be restored to normal operation by removing it and “baking” it in a conventional oven for several hours. Do not exceed 150 °F.

3. CONSTANT INDICATION OF MOISTURE DETECTION

- a. Clean and adjust the snow detector heads as described in section C, Snow Detector Maintenance.
- b. Remove white lead(s) from terminal post 9. If moisture indication is still on, the control module is defective and should be replaced.

IX. SPECIFICATIONS

VOLTAGE : 230VAC, 1PH 60 HZ, 50 Amp,
With 115VAC/115VAC center tap
neutral

MOTOR : 5 HP, 3450RPM, TEFC
128 Amp starting current
19.5 Amp running current

VOLTAGE : 230 VAC, 1PH 60HZ 50 AMP
(3PH AC DRIVE)

MOTOR : 5 HP, 3450RPM, TEFC
80 Amp starting current
19.5 Amp running current

VOLTAGE : 460/575 VAC, 3PH 60HZ 15 AMP

MOTOR : 5 HP, 3450RPM, TEFC
46 Amp starting current
4.8 Amp running current

AIRFLOW : 3600 CFM

COMBUSTION RATE : 1,000,000 BTU/HR
420,000 BTU/HR

FUEL : Propane or Natural Gas

FLOW RATE: Natural Gas: 1,0400 CFH/420 CFH
Propane: 400 CFH/168 CFH
11 GPH/4.6 GPH

INDICATION CONTACTS: 30VDC 1A or 125VAC 300mA

X. DRAWINGS

BUNGALOW POSITIONING	963N32902
GHAB SWITCH LAYOUT	9529-0020
BUNGALOW MAIN UNIT	9638-0501
GHAB MAIN UNIT	9538-6115
TIE DUCT ASSEMBLY 136LB E-CLIP	9528-4805
TIE DUCT ASSEMBLY 115LB E-CLIP	9528-4605
POINT / TRACK ASSEMBLY RH	9508-4000
POINT / TRACK ASSEMBLY LH	9508-4001
TRACK DUCT ASSEMBLY LH	9508-4002
TRACK DUCT ASSEMBLY RH	9508-4003
NOZZLE TRACK DUCT ASSEMBLY	927490
ISOLATION KIT, TIE DUCT POINT NOZZLE	9278-0021
ISOLATION KIT, TIE DUCT TRACK NOZZLE	9278-0027
DUCT, FLAME 11 X 12	9608-3126
HEAVY DUTY OFFSET DUCT	9528-3404
2' INSULATED FLEX DUCT W/MIXER	9528-4222
TRACK DUCT, 5' POINT	9278-0226
TRACK DUCT, 5' MID	9278-0227
TRACK DUCT, 10', MID	9278-1201
TRACK DUCT, 10', HEEL	9278-1202
SWITCH ROD DUCT 7'	9278-0270
TRACK DUCT SUPPORT BRACKET ASSEMBLY	92774
GHAB ELECT. PANEL LAYOUT 1 PHASE	9528-0150
GHAB ELECT. PANEL LAYOUT AC DRIVE	9538-0156
GHAB ELECT. SCHEMATIC 1 PHASE	9524-0223
GHAB ELECT. SCHEMATIC AC DRIVE	9534-0156
GHAB ELECT SCHEMATIC 3 PHASE	9504-0125
GAS PIPING, 2 STAGE	9638-0138
BURNER ASSEMBLY	9528-0135
GHAB MENU FLOW CHART	

LIMITED WARRANTY

XI.

Railway Equipment Co., Inc. (“Railway”) warrants all of its products to be free from defects in material and workmanship when used under specified operating conditions and within specified limits. Railway’s warranty shall extend for a period of two (2) years from the date of shipment to the original purchaser.

This warranty is expressly in lieu of and excludes all other expressed or implied warranties, including but not limited to warranties of merchantability and fitness for a particular purpose.

Railway, its agents, or representatives shall in no circumstance be liable for any direct, indirect, special, penal, or consequential loss or damage of any nature resulting from the malfunction of the product.

Remedies under this warranty are expressly limited to repair or replacement of the product at the sole discretion of Railway.

Before returning any defective product to Railway, contact the factory at the address or telephone number at the bottom of this article for a Return Merchandise Authorization number and instructions as to how and where the return is to be shipped. Materials received without this authorization will be returned at the customer’s expense.

Products returned to Railway under warranty must be shipped freight prepaid, and return freight charges for repaired or replaced products, in or out of warranty, will be at customer’s expense.

Railway reserves the right to reject any warranty claim on a product that has been altered by the user or damaged in shipping due to inadequate packaging or mishandling by freight carrier.

By returning a product to Railway the owner grants permission to Railway to open and disassemble the product as required for evaluation. Railway has the sole responsibility for determining the cause and nature of failure, and Railway’s determination with regard thereto shall be final. Railway reserves the right to repair or replace any unit at its sole discretion.

A returned product that is found, upon inspection by Railway, to be operational within specification is subject to an inspection and testing fee, regardless of its warranty period.

Railway's liability on any claim of any kind (including negligence) for any loss or damage arising out of or resulting from this agreement, or from the performance of breach thereof, of from the products or services furnished hereunder, shall in no case exceed the price of the specific product or service which gives rise to the claim. All such liability shall terminate upon the expiration of the warranty period of two (2) years, as hereinabove stated.

The furnishing of advice or other assistance without separate compensation therefor will not subject Railway to any liability, either in contract, warranty, tort (including negligence) or otherwise.

Any alteration or modification of the product, or addition on non-Railway components to the product, unless expressly permitted by Railway in its documentation, will void warranty coverage.

This warranty is non-transferable, and warranty coverage is limited to initial user only.

Installation and/or use of the product shall demonstrate acceptance of the terms of this warranty.

Each of the foregoing paragraphs in this article will apply to the full extent permitted by law. The invalidity, in whole or part, of any paragraph will not affect the remainder of such paragraph or any other paragraph.

RAILWAY EQUIPMENT CO.

P.O. Box 68 – Delano, Minnesota 55328 USA

Tel. (763) 972-2200 Fax (763) 972-2900

E-Mail - mail@rwy.com


(INTENTIONALLY LEFT BLANK)

REV	ECO #	DESCRIPTION	DATE	BY
A	10-0026	NEW PART	9/24/10	MF
B	10-0031	NEW FLEX DUCT	01/07/11	MF
K	11-0014	NEW MODULE/THERMOCOUPPLERS	07/08/11	GJ

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	9258-0021	A	EA	1	SNOW DETECTOR
2	9278-0232	B	EA	4	TRACK DUCT 20"
3	9368-0106	E	EA	1	DUCT ISOLATOR KIT, 9 X 9
4	9508-4000	A	EA	1	POINT/TRACK NOZZLE ASSY RH
5	9508-4001	A	EA	1	POINT/TRACK NOZZLE ASSY LH
6	9508-4002	A	EA	1	OUTSIDE TRACK NOZZLE ASSY LH
7	9508-4003	A	EA	1	OUTSIDE TRACK NOZZLE ASSY RH
8	9528-3404	A	EA	1	DUCT, OFFSET, 2' HD NO MIXER
9	9528-4805	A	EA	1	TIE DUCT, 136# QUICK CHANGE
10	9528-5222	A	EA	1	FLEX DUCT 2'ST INS W/MIXER
11	9638-0501	K	EA	1	ASSY, BUNGALOW W/ 5HP 240V GHAB



REV	ECO #	DESCRIPTION	DATE	BY
A	10-0026	NEW PART	9/24/10	MF
B	10-0031	NEW FLEX DUCT	01/07/11	MF
K	11-0014	NEW MODULE/THERMOCOUPPLERS	07/08/11	GJ

RAILS SHOWN FOR REFERENCE ONLY



VIEW A-A
SCALE 1 / 32

SNOW DETECTOR
NOT TO SCALE




WIDTH OF FLEX DUCT
MUST BE 24.0 INCHES
WHEN INSTALLED

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESIS ARE IN MILLIMETERS
TOLERANCES UNLESS OTHERWISE SPECIFIED:
FRACTIONS DECIMALS
XXX .0010 .0010 .0010
XXX .0010 .0010 .0010
XXX .0010 .0010 .0010
XXX .0010 .0010 .0010
XXX .0010 .0010 .0010

RAILWAY EQUIPMENT CO. 2011
RAILWAY EQUIPMENT CO.
MINNEAPOLIS, MINNESOTA (763) 972-5200

TITLE BUNGALOW, GHAB, 136# TIE DUCT
(ASSEMBLY / B. O. M.)

DATE 08/02/2010
DRAWN/EJS
CHECKED/ALC
SCALE 1:25
SHEET 1 OF 2



DETAIL B
SCALE 1 / 16



SNOW DETECTOR

POINT SNOW DETECTOR
(OPTIONAL ITEM)

DETAIL D
SCALE 1 / 16



© RAILWAY EQUIPMENT CO., 2011

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS ARE DECIMAL INCHES
X.XX • 0.010 FRACTIONS
X.XXX • 0.001 FRACTIONS
X.XXXX • 0.0001 FRACTIONS

RAILWAY EQUIPMENT CO.
MINNEAPOLIS, MINNESOTA (763) 972-6200

THE BUNGALOW, GHAB, 136# THE DUCT


DATE: 07/12/11

DRAWING NO: 963N32902

REVISION: B SHEET 2 OF 2

REVISION: K

REV.	DATE	BY	DESCRIPTION	DATE	APPROVED
B	00-0044	TB	ADD OUTBOARD TRACK DUCT (2)	11/22/00	----
C	00-0059	TB	NEW TIE DUCT DESIGN	05/10/01	----
D	03-0033	IW	OFFSET/MXR/OVRTMP/TIE PLT	07/01/03	----
E	04-0024	RF	UPDATE FLEX DUCT	07/15/04	----
F	05-0017	IW	NEW TRACK DUCT SPLICE	05/17/05	----



© RAILWAY EQUIPMENT CO. 2000-2004
RAILWAY EQUIPMENT CO.
 DELRANO, MINNESOTA (763) 972-3300

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS IN INCHES
 TOLERANCES:
 FRACTIONS DECIMALS
 1/16" 0.0625 0.0015
 1/8" 0.1250 0.0020
 3/16" 0.1875 0.0030
 1/4" 0.2500 0.0040
 5/16" 0.3125 0.0050
 3/8" 0.3750 0.0060
 1/2" 0.5000 0.0080
 5/8" 0.6250 0.0100
 3/4" 0.7500 0.0120
 7/8" 0.8750 0.0150
 1" 1.0000 0.0200
 DO NOT SCALE DRAWING

DRAWN TB
 DATE 11/17/00
 MATERIAL N/A
 TIE & BOND ALLOWANCE N/A

TITLE
 HOT AIR BLOWER
 SWITCH LAYOUT



REV. NO. 9529-0020
 SCALE N/A DRAWING SIZE B SHEET 1 OF 1

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	14042	A	EA	1	BAG, 4 X 6 002 ZIP TOPS
2	14165	-	EA	4	LATCH FOR SCREENS
3	2831551142	-	EA	2	BOLT, 1/4-20 X 3 HEX HEAD
4	2831851116	-	EA	11	BOLT, 3/8-16 X 1 HEX CAP
5	2831851120	-	EA	12	BOLT, 3/8-16 X 1-1/4 HEX HEAD
6	2832-5101	-	EA	2	NUT, 1/4-20 HEX
7	2832-5901	-	EA	30	NUT, 1/4-20 CENTERLOCK
8	2832-8101	-	EA	21	NUT, 3/8-16 HEX
9	2833-5129	-	EA	4	WASHER, 1/4 X 1.5 FENDER
10	2833-5211	-	EA	2	WASHER, 1/4 SPLIT LOCK
11	2833-8110	-	EA	10	WASHER, 3/8 FLAT
12	2833-8210	-	EA	21	WASHER, 3/8 SPLIT LOCK
13	29017	-	EA	10	BOLT, #8-32 X 3/8 WASHER HEAD
14	29032	-	EA	7	BOLT, 1/4-20 X 3/4 HEX SLOTT
15	29051	-	EA	65	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
16	45017	-	EA	1	BALL VALVE, 3/4, BRASS
17	45039	-	EA	1	REGULATOR, LOW PRESSURE
18	60114	-	EA	1	UNION, 3/8 SCH 40 BLK
19	60118	-	EA	1	REDUCER, 1 TO 3/8 SCH 40 BLK
20	60128	-	EA	1	NIPPLE, 3/8 X 2 SCH 40 BLACK
21	60154	-	EA	22	GASKET, 1/2X1 ADHESIVE
22	60185	-	EA	14	GASKET, 0.25 X 0.75 ADHESIVE BACK
23	60190	-	EA	1	HOSE, 3/8X24 SS BRAIDED
24	60236	-	EA	1	FITTING, COMPRESSION 1/4X1/4
25	60237	-	EA	2	NIPPLE, 3/4 X 1.5 SCH 40 BLACK
26	61011	-	EA	2	NIPPLE, 1 X 2 IN SCH 40 BLACK
27	61025	-	EA	1	REDUCER, 1 TO 3/4 SCH 40 BLACK
28	61035	-	EA	1	FLEXHOSE, 1 X 24-1.25 IN OD
29	61052	-	EA	2	ELBOW, 1IN SCH 40 BLACK
30	61058	-	EA	2	TUBING, 1/4INCH O.D., COPPER
31	61065	-	EA	24	GASKET, 11X12, HIGH TEMP
32	93833	-	EA	1	ASSY, HI TEMP SENSOR SHORT
33	9508-0356	-	EA	1	RAIL TEMP SNRS TIC MAGNETIC
34	9508-0416	-	EA	1	DUCT, OFFSET, 2' LIFT-OUT
35	9528-3103	-	EA	1	ASSY, FLAME DUCT, 18X12X4'
36	9528-3209	-	EA	1	MAIN GHAB, HIGH, SHP
37	9528-8115	-	EA	2	TRIM, OUTLET TOP
38	960615	-	EA	2	TRIM, OUTLET BOTTOM
39	960616	-	EA	2	TRIM, OUTLET SIDE
40	960617	-	EA	1	ASSY, TEMPERATURE SENSOR
41	960631	-	EA	1	BUNGALOW, 25HP GHAB, 6 X 6
42	9608-0405	-	EA	1	ASSY, ELEC BUNGALOW 230 PHH
43	9638-1000	-	EA	1	ASSY, ELEC BUNGALOW 230 PHH
44	9638-1100	-	EA	1	ASSY, ELEC BUNGALOW 230 PHH

Parts List

RE	ECO #	DESCRIPTION	DATE	BY
K	11-0014	NEW MODULE/THERMOCOUPERS	7/8/2011	GJ

REVISION HISTORY



SECTION A-A
SCALE 1:24

© RAILWAY EQUIPMENT CO., 2011

RAILWAY EQUIPMENT CO.

WYOMING, MINNESOTA

(763) 975-2200

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN MILLIMETERS
FRACTIONS
DECIMALS
TOLERANCES
DRAWN: GJ/DVMS

TITLE: ASSY, BUNGALOW W SHP 240V GHAB

DATE: 07/08/11

DWG NO: 9638-0501K

REV: K

SCALE: 1" = 1"


SHEET 1 OF 1

REV: K

REV	ECO	DESCRIPTION	DATE	BY
A	06-0015	NEW PART	8/25/2006	RMJ
B	06-0031	UPDATE GAS & CONTROLS	12/18/06	RH
C	08-0006	UPDATE TRANS/PANEL/MOD	4/8/08	WS
D	---	BOM ENTERED/UPDATED	06/23/10	IW
E	10-0031	UPDATED ENCL/ADDED QUICK CHANGE	12/22/10	MF
K	11-0014	UPDATED MODULE	07/08/11	GJ

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
61	963806	A	EA	1	SUPPORT, GAS 5HP BUNGALOW
62	963807	A	EA	3	SUPPORT, GAS LINE, 5 HP
63	963808	A	EA	1	CAP, INTAKE INSIDE 5HP
64	R8039-0816	A	EA	1	LABEL, FAN ROTATION
65	R8039-0630	A	EA	1	LABEL, GHAB WARNINGS
66	R8039-0955	A	EA	1	LABEL, ID PLATE AGA/CSA
67	R9500-0100	A	EA	1	MANUAL, 960 BUNGALOW 5HP
68	R9630-0105	C	EA	2	MANUAL, 960 BUNGALOW 5HP 230V

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	26015	A	EA	1	BLOWER WHEEL, 1350 WITH HUB
2	26016	A	EA	1	INLET CONE, 1350 90%
3	28035	-	EA	6	MOUNT, RUBBER, M/M, 1/4-20
4	28107	-	EA	1	NUT, 1/4-20 THUMB, NYLON
5	2831-9003	-	EA	3	BOLT, 1/4-20 X 1 CARRIAGE
6	2831-141108	-	EA	1	SCREW, #10-32 X 1/2 PAN SLT
7	2831-141112	-	EA	1	SCREW, #10-32 X 3/4 PAN SLT
8	2831-155110	-	EA	4	BOLT, 1/4-20 X 5/8 HEX HEAD
9	2831-165116	-	EA	12	BOLT, 3/8-16 X 1 HEX CAP
10	2831-166112	-	EA	23	BOLT, 3/8 X 0.75 CARRIAGE
11	2832-4101	-	EA	3	NUT, #10-32 HEX
12	2832-5101	-	EA	8	NUT, 1/4-20 HEX
13	2832-5801	-	EA	11	NUT, 1/4-20 CENTERLOCK
14	2832-6101	-	EA	14	NUT, 3/8-16 HEX
15	2832-8904	-	EA	32	NUT, 3/8-16 CENTERLOCK
16	2833-4210	-	EA	1	WASHER, #10 SPLIT LOCK
17	2833-4310	-	EA	4	WASHER, #10 EXT. STAR
18	2833-5110	-	EA	12	WASHER, 1/4 FLAT
19	2833-5211	-	EA	10	WASHER, 1/4 SPLIT LOCK
20	2833-6040	-	EA	4	RIVET, BUTTON HEAD PLATED STL
21	2833-8110	-	EA	4	WASHER, 3/8 FLAT
22	2833-8119	-	EA	8	WASHER, 3/8" X 1-1/2 FENDER
23	2833-8210	-	EA	14	WASHER, 3/8 SPLIT LOCK
24	29016	-	EA	2	BOLT, 1/4-20 X 1/2 HEX SLOT
25	29051	-	EA	70	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
26	60002	-	EA	1	3/8 ROMEX
27	60169	-	EA	2	TY-RAP 0.30 X 8
28	60185	A	FT	8	GASKET, .25 X 0.75 ADHESIVE BACK
29	60195	-	FT	6	GASKET, .25 X 1.0 ADHESIVE BK
30	6083-0100	-	EA	5	TY-RAP, 4IN 0.10 WIDTH
31	61032	-	EA	1	NIPPLE, 1 X 3 IN SCH 40 BLACK
32	61037	-	EA	1	NIPPLE, 1 X 17 SCH 40 BLACK
33	61058	-	EA	2	ELBOW, 1IN SCH 40 BLACK
34	61070	-	EA	4	U-BOLT, MRO BOLT #65
35	8040-0952	C	EA	1	NAMEPLATE, 952/953 GHAB
36	92919	A	EA	8	WASHER, 1/4 EXT. STAR
37	9338-0026	A	EA	1	ASSY, BUZZER
38	9508-0038	A	EA	1	ASSY, GAS SENSOR EXT CABLE
39	9508-0039	A	EA	1	ASSY, DUCT SENSOR EXT CABLE
40	9508-0430	A	EA	1	ASSY, WIRED IGNITION XFMR
41	9508-0431	B	EA	1	ASSY, HARNESS AIR FLOW SWITCH
42	9508-0495	B	EA	1	ASSY, FLAME WIRE
43	95201	C	EA	1	BASE, MOTOR, 184T, GHAB
44	95202	A	EA	1	PLATE, MOTOR BASE, 184T GHAB
45	952127	C	EA	1	STUD PLATE
46	9528-0135	B	EA	1	BURNER, 12IN
47	9528-0150	B	EA	1	ASSY, GHAB PANEL, 5HP 230V 1PH
48	9538-0048	A	EA	1	ASSEMBLY, IGNITION WIRE
49	960131	A	EA	1	ENCLOSURE, HAB
50	960632	B	EA	1	BLOWER, AIR CUT FLANGE 3/5HP
51	960801	A	EA	1	BUNGALOW ENCL MOUNTING PLATE
52	96346	A	EA	1	MOTOR MOUNTING PLATE, HAB
53	9638-0028	B	EA	1	ASSY, WIRED MOTOR, 5HP/230V/1PH
54	9638-0136	B	EA	1	ASSY, GHAB PIPING 5HP BUNGALOW
55	963800	B	EA	1	BLOWER OUTLET FLANGE 5HP
56	963801	B	EA	1	INTAKE BODY, 5HP BUNGALOW
57	963802	B	EA	1	PC, MOTOR BODY, HIGH 5HP
58	963803	B	EA	1	BLOWER SHROUD 3/5HP
59	963804	B	EA	1	BASE, GHAB, 5HP
60	963805	A	EA	1	DEFLECTOR, INTAKE 5HP, GHAB



DETAIL A
SCALE 1 / 2

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
FRACTIONS SHALL BE IN 16THS
TOLERANCES UNLESS OTHERWISE SPECIFIED:
FRACTIONS .XX, .02
DECIMALS .XX, .02
DIMENSIONS ARE IN INCHES
DRAWING: RMJ

RAILWAY EQUIPMENT CO. 2011
MINNEAPOLIS, MINNESOTA (763) 972-2200

TITLE: MAIN GHAB, HIGH, 5HP BUNGALOW ASSY & BOM

DATE: 08/25/06

DWG NO: 9538-6115


SCALE: 1/16

LONG SIZE: B

SHEET 1 OF 1

Parts List				Parts List							
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927237	A	EA	2	COVER PLATE, TEMP SENSOR	14	927367	B	EA	2	E-CLIP INSULATOR PAD THE PLATE 136#
2	2833-9009	-	EA	8	WASHER, 3/4 SPLIT LOCK	15	14151	-	EA	1	WIRE BURL APBAG CLOSING TIES 6"
3	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK	16	R8039-0904	D	EA	2	CAUTION LABEL, THE DUCT 136#
4	2831851114	-	EA	4	BOLT, 3/8-16 X 1 HEX HEAD, SS	17	R8039-0914	D	EA	1	TAG, ACCESS PARTS FOR THE DUCT
5	28121	-	EA	8	BOLT, 3/4-10 X 1 1/2 HEX, SS	18	9528-4109	B	EA	1	FLANGE ADAPTER KIT, 9x9 DUCT
6	2831851116	-	EA	16	BOLT, 3/8-16 X 1 HEX CAP	19	14153	-	EA	1	BAG, WOVEN YELLOW 23.5 X 48
7	2832-8904	-	EA	16	NUT, 3/8-16 CENTERLOCK	20	12425	-	IN	720	TAPE ROLL, 2" WIDE HEAVY
8	927366	A	EA	4	E-CLIP INSULATOR	21	2833-9020	-	EA	16	WASHER, M12 SPLIT LOCK
9	927248	A	EA	4	RAIL CLIP, THE DUCT	22	927602	A	EA	2	COVER, POINT/TRACK NOZZLE
10	952266	A	EA	1	ASSY, THE DUCT QUICK CHANGE	23	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
11	95234	C	EA	2	GASKET, 5HP THE DUCT	24	2831951121	-	EA	12	BOLT, 1/2-13 X 1.25 HEX, SS
12	952267	A	EA	2	COVER PLATE WITH LIFTING LUG	25	2831951123	-	EA	4	BOLT, 1/2-13 X 1.75 HEX, SS
13	927385	B	EA	2	THE PLATE 136# E-CLIP-PAD TYPE						

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS



UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS TO 0.005
 ANGULAR DIMENSIONS TO 0.1°
 FRACTIONS TO 1/32"
 HOLE DIMENSIONS TO 0.0015"
 UNLESS OTHERWISE SPECIFIED

RAILWAY EQUIPMENT CO.
 DEPT. 100, WILMINGTON, (703) 972-8200

TITLE: THE DUCT, 136# QUICK CHANGE
 (ASSEMBLY)


DATE: 10/23/06
 DRAWN: WJS
 WRT: SEE B.O.M.
 N/A

DWG NO: 9528-4805
 SCALE: 1/8"
 DWG SIZE: B
 SHEET 1 OF 1
 REV: A

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS

Parts List					Parts List						
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927356	B	EA	2	TIE PLATE 115# E-CLIP PAD TYPE	14	95234	C	EA	2	GASKET, SHP TIE DUCT
2	927237	A	EA	2	COVER PLATE, TEMP SENSOR	15	952267	A	EA	2	COVER PLATE WITH LIFTING LUG
3	28331951121	-	EA	12	BOLT, 1/2-13 X 1.25 HEX SS	16	14151	-	EA	1	WIRE BURLAPBAG CLOSING TIES 6"
4	2833-9009	-	EA	8	WASHER, 3/4 SPLIT LOCK	17	R8039-0905	D	EA	2	CAUTION LABEL, TIE DUCT 115#
5	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK	18	R8039-0915	D	EA	1	TAG, ACCESS PARTS FOR TIE DUCT
6	28331851114	-	EA	4	BOLT, 3/8-16 X 1 HEX HEAD, SS	19	9528-4109	B	EA	1	FLANGE ADAPTOR KIT, 9X9 DUCT
7	28121	-	EA	8	BOLT, 3/4-10 X 1 1/2 HEX SS	20	14153	-	EA	1	BAG, WOVEN YELLOW 23.5 X 48
8	28331851116	-	EA	16	BOLT, 3/8-16 X 1 HEX CAP	21	12425	-	IN	720	TAPE ROLL 2" WIDE HEAVY
9	2832-8904	-	EA	16	NUT, 3/8-16 CENTER LOCK	22	2833-9020	-	EA	16	WASHER, M12 SPLIT LOCK
10	927368	A	EA	2	PAD FOR E-CLIP RUBBER 115# TIE	23	927602	A	EA	2	COVER, POINT/TRACK NOZZLE
11	927366	A	EA	4	E-CLIP INSULATOR	24	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
12	927248	A	EA	4	RAIL CLIP, TIE DUCT	25	28331951123	-	EA	4	BOLT, 1/2-13 X 1.75 SS HEX
13	952266	A	EA	1	ASSY, TIE DUCT QUICK CHANGE						



UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS TO TWO PLACES
 FRACTIONS TO 16THS
 HOLE DIMENSIONS TO 100% TOLERANCE DRAWINGS




RAILWAY EQUIPMENT CO., 2006
RAILWAY EQUIPMENT CO.
 10221 LINDEN, MISSISSAUGA, ONTARIO L4Y 1V7
 TITLE: **TIE DUCT, 115# QUICK CHANGE**
 DRAWN: **WS**
 DATE: **10/23/06**
 DWG NO: **9528-4605**
 REV: **A**
 SCALE: **1/8**
 SHEET: **1** OF **1**

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927800	B	EA	1	POINT/TD NOZZLE MOUNT PLATE RH
2	927701	A	EA	1	SCREEN POINT NOZZLE
3	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
4	927757	D	EA	1	GASKET ISO PT NOZZLE RED
5	927759	B	EA	1	GASKET ISO TR NOZZLE RED
6	93617	D	EA	1	POINT NOZZLE 4 X 4 GALV
7	2833-9015	B	EA	8	WASHER ISOLATING NOZZLE
8	28106	-	EA	8	SPACER .38X.625X.375 ROUND
9	2833-9014	-	EA	4	WASHER 5/8 FLAT SAE
10	2833-8110	-	EA	8	WASHER 3/8 FLAT
11	2833-8210	-	EA	8	WASHER 3/8 SPLIT LOCK
12	2833-8101	-	EA	8	NUT 3/8-16 HEX
14	R9308-4000	A	EA	1	LABEL QUICK NOZZLE ASSY RH
15	927490	A	EA	1	NOZZLE TRACK DUCT ASSY



Parts List

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/24/2006	WS

REVISION HISTORY



CENTER POINT



© RAILWAY EQUIPMENT CO. 2006

RAILWAY EQUIPMENT CO.
 DELAWARE UNIVERSITY (763) 972-4200


UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS TO TWO PLACES
 FRACTIONS TO SIXTEENTHS
 ANGULAR TO NEAREST MINUTE
 HOLE DRILLING TO NEAREST THIRDS
 UNLESS OTHERWISE SPECIFIED

DATE: 10/24/06
 DRAWN: WS
 TITLE: POINT/TRACK NOZZLE ASSY RH (ASSEMBLY)
 PART: 9508-4000
 SCALE: 1/4" = 1" DRAWN BY: WS
 CHECKED BY: A

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/19/2006	WS

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927606	B	EA	1	POINT/ID NOZZLE MOUNT PLATE LH
2	927701	A	EA	1	SCREEN, POINT NOZZLE
3	927702	A	EA	1	SCREEN, TRACK DUCT NOZZLE L/R
4	92757	D	EA	1	GASKET, ISO, PT NOZZLE RED
5	92759	B	EA	1	GASKET, ISO, TR NOZZLE RED
6	93617	D	EA	1	POINT NOZZLE, 4 X 4 GALV
7	2833-9015	B	EA	8	WASHER, ISOLATING NOZZLE
8	28106	-	EA	8	SPACER, .38X.625X.375 ROUND
9	2833-9014	-	EA	4	WASHER, 5/8 FLAT SAE
10	2833-8110	-	EA	8	WASHER, 3/8 FLAT
11	2833-8210	-	EA	8	WASHER, 3/8 SPLIT LOCK
12	2832-8101	-	EA	8	NUT, 3/8-16 HEX NUT
13	60195	-	FT	1.667	GASKET, .25 X 1.0 ADHESIVE BK
14	R9508-4001	A	EA	1	LABEL, QUICK NOZZLE ASSY LH
15	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

Parts List



UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO TWO PLACES
 FRACTIONS ARE TO EIGHTH PLACES
 DIMENSIONS TO BE HIDDEN BY OTHER DIMENSIONS
 DO NOT SCALE DRAWINGS

DRAWN: WS

DATE: 10/19/06

REV: SEE B.O.M.

SCALE: N/A

RAILWAY EQUIPMENT CO. 2006

RAILWAY EQUIPMENT CO.
 DELAWARE, MINNESOTA (763) 972-2200

TITLE: POINT/TRACK NOZZLE ASSY LH
 (ASSEMBLY)

DWG NO: 9508-4001

REV: A





SCALE: 1/4" = 1"

SHEET: 1 OF 1

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	92759	B	EA	1	GASKET, ISO, TR NOZZLE RED
2	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
3	28106	EA	EA	1	SPACER, .38X.625X.375 ROUND
4	2833-9015	B	EA	4	WASHER, INSULATING NOZZLE
5	2833-8110	-	EA	4	WASHER, 3/8 FLAT
6	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK
7	2832-8101	-	EA	4	NUT, 3/8-16 HEX
8	927604	B	EA	1	TRACK DUCT NOZZLE MOUNT PLATE
9	60195	-	FT	1.667	GASKET, 25 X 1.0 ADHESIVE BK
10	R9908-4002	A	EA	1	LABEL, QUICK NOZZLE ASSY LH
11	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

Parts List

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/24/2006	WS



© RAILWAY EQUIPMENT CO., 2006

RAILWAY EQUIPMENT CO.
 DELAWARE, WYOMING (763) 972-4290

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS AND FRACTIONS
 ARE TO BE FRACTIONS
 UNLESS OTHERWISE SPECIFIED
 DIMENSIONS ARE IN MILLIMETERS

DATE: 10/24/06
 WKT: SEE B.O.M.
 N/A

SCALE: 3/8
 PARTS SHEET: B
 SHEET 1 OF 1






REV: A

TITLE: OUTSIDE TRACK NOZZLE ASSY LH (ASSEMBLY)

REVISION HISTORY			
REV	ECO	DESCRIPTION	DATE
A	06-0024	NEW PART	10/19/2006
BY			WS

Parts List			
ITEM	PART NUMBER	REV	UOM QTY
1	92769	B	EA 1
2	927702	A	EA 1
3	28106	-	EA 1
4	2833-9015	B	EA 4
5	2833-8110	-	EA 4
6	2833-8210	-	EA 4
7	2832-8101	-	EA 4
8	60195	B	EA 1
9	R9508-4003	A	EA 1
10	927490	A	EA 1

DESCRIPTION	DATE	BY
NEW PART	10/19/2006	WS



UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO THREE PLACES
 ANGULAR DIMENSIONS ARE TO NEAREST
 .XX * OR FRACTIONS TO NEAREST
 1/32 ** DO NOT SCALE DRAWINGS
 DRAWN: WS


RAILWAY EQUIPMENT CO. 2006
RAILWAY EQUIPMENT CO.
 DELAWARE, MINNESOTA (763) 972-2200

DATE: 10/19/06
 DWG NO: 9508-4003
 REVISION: A
 SCALE: 3/8" = 1" DRAWING: B SHEET: 1 OF 1

TITLE: OUTSIDE TRACK NOZZLE ASSY RH
 (ASSEMBLY)




ITEM	PART NUMBER	QTY	DESCRIPTION
1	927488	A	NOZZLE, TRACK DUCT, NO DAMPER
2	92745	A	HOLDOWN STRAP T. DUCT
5	92742	-	SPRING, TRACK DUCT SUPPORT
4	92743	B	CLIP, HOLDOWN SPRING
7	60195	FT	1.67" GASKET, .25 X 1.0 ADHESIVE BK

Parts List




REV	ECO	DESCRIPTION	DATE	BY
A	06-0028	NEW PART	11/30/2006	RMJ

REVISION HISTORY



PACKOUT VIEW
SCALE 1 / 4



UNLESS OTHERWISE SPECIFIED:		DIMENSIONS ARE IN INCHES	
DECIMALS		ANGULAR	
.XX + .02		FRACTIONS	
.00001 SCALE DRAWING			
DRAWN: RMJ			
DATE: 11/30/06			
WGT: N/A			
N/A ALLOWANCE			
DWG NO: 927490		REV: A	
SCALE: 1/2		SHEET 1 OF 1	

RAILWAY EQUIPMENT CO., 2006


RAILWAY EQUIPMENT CO.
DEPT. 110, MILWAUKEE, WI 53210
TEL: 414-224-2200

TITLE: NOZZLE, TRACK DUCT ASSY

REV.	QTY.	BY	DATE	APPROVED
B		TB	10/19/00	
C		RJ	11/28/06	

REVISION DESCRIPTION
 ADD 927701
 CORNERS CUT OFF ON DUCT

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	2631851114	EA	4	BOLT, HEX HD 3/8-16 x 1" SS
2	2633-8110	EA	4	WASHER, PLAIN 3/8"
3	2633-90156	EA	4	WASHER, INSULATOR
4	28106	EA	4	SPACER, ROUND, .38 X .625 X .375
5	927570	EA	1	GASKET, POINT NOZZLE
6	2633-9014	EA	4	WASHER, 5/8 FLAT PLATED
7	14046	EA	1	BAG, ZIPTOP 9x12 4mil
8	2633-8210	EA	4	WASHER, SPLIT LOCK 3/8"
9	927701A	EA	1	SCREEN, POINT NOZZLE





SECTION A-A



© RAILWAY EQUIPMENT CO. 1997-2002
RAILWAY EQUIPMENT CO.
 DUBLAND, MINNESOTA (763) 972-3800

UNLESS OTHERWISE SPECIFIED: DIMENSIONS IN INCHES FRACTIONS ARE IN 16ths DECIMALS ARE IN 10ths DIMENSIONS TO FACE UNLESS OTHERWISE NOTED DIMENSIONS TO CENTER UNLESS OTHERWISE NOTED DO NOT SCALE DRAWING	TITLE ISOLATION KIT ASSEMBLY POINT NOZZLE TIE DUCT
DRAWN EFK	DATE 04/11/97
MATERIAL N/A	REV C
SCALE 1/4"	DRAWING SIZE B
SHEET 1	OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	2831851114	EA	4	BOLT, HEX, 3/8-16 x 1" SS
2	2833-8110	EA	4	WASHER, FLAIN 3/8
3	2833-9015	EA	4	WASHER, INSULATOR
4	28106	EA	4	SPACER, ROUND, .38 X .625 X .375
5	92729	EA	1	GASKET, TRACK DUCT NOZZLE
6	80195	FT	1.87	GASKET, ADHESIVE, .25 X 1"
7	14045	EA	1	BAG, ZIPTOP 12 X 13 4mil
8	2833-8210	EA	4	WASHER, SPLIT LOCK 3/8
9	927702	EA	1	SCREEN, TRACK DUCT NOZZLE




APPLY ADHESIVE GASKET
ITEM #5, TO TOP SURFACES
OF TRACK DUCT NOZZLE
FLANGE (2 PLACES)




REV	DATE	BY	REVISION DESCRIPTION	DATE	APPROVED
A	06/08/05	TB	NEW PART	12/29/00	

FORM NO.	DATE	REV	ISSUED BY	DATE
			T. BUHL	12/19/00
TITLE: ASSY ISO KIT TRACK NOZZLE TIE DUCT DRAWING NO: 9278-0027		QUANTITY: 1 of 1		
DRAWN BY: [Blank] CHECKED BY: [Blank] APPROVED BY: [Blank]		DATE: [Blank]		
© RAILWAY EQUIPMENT CO. 2000 RAILWAY EQUIPMENT CO. 12241N. AMERSON RD (781) 978-8800				

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	952226	EA	1	INSUL COVER, OFFSET DUCT
2	28019	EA	8	SHOULDER BOLT 1/4-20 X 1.3
3	952224	EA	1	DUCT, OFFSET, WITH HEAVY BASE
4	32002	SQ.FT.	6	INSULATION FIBERGLASS
5	9528-0074	EA	1	GASKET KIT, 9X9 SHP FLEX
6	6093-0102	EA	1	TY-RAP



REV	SCALE	BY	REVISION DESCRIPTION	DATE	APPROVED
A	008	RF	NEW PART	09/07/05	



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS
HOLE DIMENSIONS ARE TO HOLE DRILLING
DIMENSIONS ARE TO HOLE DRILLING
DIMENSIONS ARE TO HOLE DRILLING
DIMENSIONS ARE TO HOLE DRILLING

DATE: 09/07/05
DRAWN: RPF
CHECKED: N/A
SCALE: 1/4"

© RAILWAY EQUIPMENT CO. 2005
RAILWAY EQUIPMENT CO.
BRALVO, MINNESOTA (763) 878-8200








TITLE: OFFSET DUCT, 2'
REINFORCED, LIFTOUT
ASSEMBLY / B.O.M.

DWG NO.: 9528-3404
SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1

REV: A

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927443	EA	1	TRACK DUCT BASE 5'
2	92740	EA	1	END PLATE, TRACK DUCT
3	92730	EA	1	TRACK DUCT COVER 5'
4	92774	EA	1	TRACK DUCT SUPPORT BRACKET
5	92785	EA	1	DEFLECTOR, TRACK DUCT, SMALL
6	29051	EA	9	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
7	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH

REV.	EQD.	REV.	REVISION DESCRIPTION	DATE	APPROVED
A	05-0017	RF	NEW SPLICE SYSTEM	05/24/05	---
B	05-0017	RO	NEW SUPPORT ASSEM DESIGN	10/27/05	---



FULL SCALE

© RAILWAY EQUIPMENT CO. 2005








RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 973-3200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS TO TWO PLACES
 FRACTIONS TO 16THS
 HOLE SIZES TO 1/32" UNLESS
 OTHERWISE SPECIFIED

DRAWN: RPF
 DATE: 05/24/05
 MATERIAL: SEE PRINT
 TITLE: TRACK DUCT
 5' POINT LTD
 ASSEMBLY / B.O.M.
 DWG NO.: 9278-0226
 SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1

REV.	Q.C.A.	BY	REVISION DESCRIPTION	DATE	APPROVED
A	05-007	RF	NEW SPLICE SYSTEM	05/24/05	----
B	05-007	RO	NEW SUPPORT ASSM DESIGN	10/27/05	----





ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92735	EA	1	TRACK DUCT BASE 5'
2	92730	EA	1	TRACK DUCT COVER 5'
3	927441	EA	1	CENTER COVER, E.Z. SPLICE
4	927442	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	92774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/ 2" HEX HEAD
8	6093-0100	EA	1	TY-RAP, 4" .10 WIDTH





FULL SCALE

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO 2 PLACES
 FRACTIONS ARE TO 16THS
 DIMENSIONS TO 30" ARE TO 1/16"
 DIMENSIONS OVER 30" ARE TO 1/32"
 DIMENSIONS TO 1/8" ARE TO 1/16"
 DIMENSIONS TO 1/4" ARE TO 1/32"
 DIMENSIONS TO 1/2" ARE TO 1/16"
 DIMENSIONS TO 1" ARE TO 1/16"
 DIMENSIONS TO 2" ARE TO 1/16"
 DIMENSIONS TO 4" ARE TO 1/16"
 DIMENSIONS TO 8" ARE TO 1/16"
 DIMENSIONS TO 16" ARE TO 1/16"
 DIMENSIONS TO 32" ARE TO 1/16"
 DIMENSIONS TO 64" ARE TO 1/16"
 DIMENSIONS TO 128" ARE TO 1/16"
 DIMENSIONS TO 256" ARE TO 1/16"
 DIMENSIONS TO 512" ARE TO 1/16"
 DIMENSIONS TO 1024" ARE TO 1/16"
 DIMENSIONS TO 2048" ARE TO 1/16"
 DIMENSIONS TO 4096" ARE TO 1/16"
 DIMENSIONS TO 8192" ARE TO 1/16"
 DIMENSIONS TO 16384" ARE TO 1/16"
 DIMENSIONS TO 32768" ARE TO 1/16"
 DIMENSIONS TO 65536" ARE TO 1/16"
 DIMENSIONS TO 131072" ARE TO 1/16"
 DIMENSIONS TO 262144" ARE TO 1/16"
 DIMENSIONS TO 524288" ARE TO 1/16"
 DIMENSIONS TO 1048576" ARE TO 1/16"
 DIMENSIONS TO 2097152" ARE TO 1/16"
 DIMENSIONS TO 4194304" ARE TO 1/16"
 DIMENSIONS TO 8388608" ARE TO 1/16"
 DIMENSIONS TO 16777216" ARE TO 1/16"
 DIMENSIONS TO 33554432" ARE TO 1/16"
 DIMENSIONS TO 67108864" ARE TO 1/16"
 DIMENSIONS TO 134217728" ARE TO 1/16"
 DIMENSIONS TO 268435456" ARE TO 1/16"
 DIMENSIONS TO 536870912" ARE TO 1/16"
 DIMENSIONS TO 1073741824" ARE TO 1/16"
 DIMENSIONS TO 2147483648" ARE TO 1/16"
 DIMENSIONS TO 4294967296" ARE TO 1/16"
 DIMENSIONS TO 8589934592" ARE TO 1/16"
 DIMENSIONS TO 17179869184" ARE TO 1/16"
 DIMENSIONS TO 34359738368" ARE TO 1/16"
 DIMENSIONS TO 68719476736" ARE TO 1/16"
 DIMENSIONS TO 137438953472" ARE TO 1/16"
 DIMENSIONS TO 274877906944" ARE TO 1/16"
 DIMENSIONS TO 549755813888" ARE TO 1/16"
 DIMENSIONS TO 1099511627776" ARE TO 1/16"
 DIMENSIONS TO 2199023255552" ARE TO 1/16"
 DIMENSIONS TO 4398046511104" ARE TO 1/16"
 DIMENSIONS TO 8796093022208" ARE TO 1/16"
 DIMENSIONS TO 17592186044416" ARE TO 1/16"
 DIMENSIONS TO 35184372088832" ARE TO 1/16"
 DIMENSIONS TO 70368744177664" ARE TO 1/16"
 DIMENSIONS TO 140737488355328" ARE TO 1/16"
 DIMENSIONS TO 281474976710656" ARE TO 1/16"
 DIMENSIONS TO 562949953421312" ARE TO 1/16"
 DIMENSIONS TO 1125899906842624" ARE TO 1/16"
 DIMENSIONS TO 2251799813685248" ARE TO 1/16"
 DIMENSIONS TO 4503599627370496" ARE TO 1/16"
 DIMENSIONS TO 9007199254740992" ARE TO 1/16"
 DIMENSIONS TO 18014398509481984" ARE TO 1/16"
 DIMENSIONS TO 36028797018963968" ARE TO 1/16"
 DIMENSIONS TO 72057594037927936" ARE TO 1/16"
 DIMENSIONS TO 14411518807585584" ARE TO 1/16"
 DIMENSIONS TO 28823037615171168" ARE TO 1/16"
 DIMENSIONS TO 57646075230342336" ARE TO 1/16"
 DIMENSIONS TO 115292150460684672" ARE TO 1/16"
 DIMENSIONS TO 230584300921369344" ARE TO 1/16"
 DIMENSIONS TO 461168601842738688" ARE TO 1/16"
 DIMENSIONS TO 922337203685477376" ARE TO 1/16"
 DIMENSIONS TO 1844674407370954752" ARE TO 1/16"
 DIMENSIONS TO 3689348814741909504" ARE TO 1/16"
 DIMENSIONS TO 7378697629483819008" ARE TO 1/16"
 DIMENSIONS TO 14757395258967638016" ARE TO 1/16"
 DIMENSIONS TO 29514790517935276032" ARE TO 1/16"
 DIMENSIONS TO 59029581035870552064" ARE TO 1/16"
 DIMENSIONS TO 118059162071741104128" ARE TO 1/16"
 DIMENSIONS TO 236118324143482208256" ARE TO 1/16"
 DIMENSIONS TO 472236648286964416512" ARE TO 1/16"
 DIMENSIONS TO 944473296573928833024" ARE TO 1/16"
 DIMENSIONS TO 1888946593147857666048" ARE TO 1/16"
 DIMENSIONS TO 3777893186295715332096" ARE TO 1/16"
 DIMENSIONS TO 7555786372591430664192" ARE TO 1/16"
 DIMENSIONS TO 15111572745182861328384" ARE TO 1/16"
 DIMENSIONS TO 302231454903657226576" ARE TO 1/16"
 DIMENSIONS TO 604462909807314453152" ARE TO 1/16"
 DIMENSIONS TO 1208925819614628906304" ARE TO 1/16"
 DIMENSIONS TO 2417851639229257812608" ARE TO 1/16"
 DIMENSIONS TO 4835703278458515625216" ARE TO 1/16"
 DIMENSIONS TO 96714065569170312510432" ARE TO 1/16"
 DIMENSIONS TO 19342813113834062510432" ARE TO 1/16"
 DIMENSIONS TO 3868562622766812510432" ARE TO 1/16"
 DIMENSIONS TO 773712524553362510432" ARE TO 1/16"
 DIMENSIONS TO 154742504910672510432" ARE TO 1/16"
 DIMENSIONS TO 30948500982134510432" ARE TO 1/16"
 DIMENSIONS TO 6189700196426910432" ARE TO 1/16"
 DIMENSIONS TO 12379400392853820864" ARE TO 1/16"
 DIMENSIONS TO 24758800785707641728" ARE TO 1/16"
 DIMENSIONS TO 49517601571415283456" ARE TO 1/16"
 DIMENSIONS TO 99035203142830566912" ARE TO 1/16"
 DIMENSIONS TO 19807040628566113824" ARE TO 1/16"
 DIMENSIONS TO 39614081257132227648" ARE TO 1/16"
 DIMENSIONS TO 79228162514264455296" ARE TO 1/16"
 DIMENSIONS TO 158456325028528910592" ARE TO 1/16"
 DIMENSIONS TO 316912650057057821184" ARE TO 1/16"
 DIMENSIONS TO 633825300114115642368" ARE TO 1/16"
 DIMENSIONS TO 1267650600228231284736" ARE TO 1/16"
 DIMENSIONS TO 2535301200456462569472" ARE TO 1/16"
 DIMENSIONS TO 5070602400912925138944" ARE TO 1/16"
 DIMENSIONS TO 1014120480182585027888" ARE TO 1/16"
 DIMENSIONS TO 2028240960365170055776" ARE TO 1/16"
 DIMENSIONS TO 4056481920730340111552" ARE TO 1/16"
 DIMENSIONS TO 8112963841460680223104" ARE TO 1/16"
 DIMENSIONS TO 1622592768292136044608" ARE TO 1/16"
 DIMENSIONS TO 3245185536584272089216" ARE TO 1/16"
 DIMENSIONS TO 6490371073168544178432" ARE TO 1/16"
 DIMENSIONS TO 1298074214633688356864" ARE TO 1/16"
 DIMENSIONS TO 2596148429267376713728" ARE TO 1/16"
 DIMENSIONS TO 5192296858534753427456" ARE TO 1/16"
 DIMENSIONS TO 10384593717069506854912" ARE TO 1/16"
 DIMENSIONS TO 20769187434139013709824" ARE TO 1/16"
 DIMENSIONS TO 41538374868278027419648" ARE TO 1/16"
 DIMENSIONS TO 83076749736556054839296" ARE TO 1/16"
 DIMENSIONS TO 166153499473112109678592" ARE TO 1/16"
 DIMENSIONS TO 332306998946224219357184" ARE TO 1/16"
 DIMENSIONS TO 664613997892448438714368" ARE TO 1/16"
 DIMENSIONS TO 1329227995784896774288704" ARE TO 1/16"
 DIMENSIONS TO 2658455991569793548577408" ARE TO 1/16"
 DIMENSIONS TO 53169119831395870971554176" ARE TO 1/16"
 DIMENSIONS TO 106338239662791741943108352" ARE TO 1/16"
 DIMENSIONS TO 212676479325583483886216704" ARE TO 1/16"
 DIMENSIONS TO 425352958651166967772433408" ARE TO 1/16"
 DIMENSIONS TO 850705917302333935544866816" ARE TO 1/16"
 DIMENSIONS TO 1701411834604667871089733632" ARE TO 1/16"
 DIMENSIONS TO 3402823669209335742179466656" ARE TO 1/16"
 DIMENSIONS TO 6805647338418671484358933312" ARE TO 1/16"
 DIMENSIONS TO 13611294676837342968717866624" ARE TO 1/16"
 DIMENSIONS TO 27222589353674685937435333248" ARE TO 1/16"
 DIMENSIONS TO 54445178707349371874868666496" ARE TO 1/16"
 DIMENSIONS TO 108890357414698743749737332992" ARE TO 1/16"
 DIMENSIONS TO 217780714829397487499474665984" ARE TO 1/16"
 DIMENSIONS TO 435561429658794974998949331968" ARE TO 1/16"
 DIMENSIONS TO 871122859317589949997998663936" ARE TO 1/16"
 DIMENSIONS TO 174224571835517999995997327872" ARE TO 1/16"
 DIMENSIONS TO 348449143671035999991994655744" ARE TO 1/16"
 DIMENSIONS TO 696898287342071999983989311488" ARE TO 1/16"
 DIMENSIONS TO 1393796574684143999967978622976" ARE TO 1/16"
 DIMENSIONS TO 2787593149368287999935957445952" ARE TO 1/16"
 DIMENSIONS TO 5575186298736575999871914891904" ARE TO 1/16"
 DIMENSIONS TO 11150372597473151999743837783808" ARE TO 1/16"
 DIMENSIONS TO 22300745194946303999486675567616" ARE TO 1/16"
 DIMENSIONS TO 446014903898926079989733511354304" ARE TO 1/16"
 DIMENSIONS TO 892029807797852159979467027108608" ARE TO 1/16"
 DIMENSIONS TO 178405961559570431959593405421216" ARE TO 1/16"
 DIMENSIONS TO 356811923119140863919118680842432" ARE TO 1/16"
 DIMENSIONS TO 713623846238281727838233761648864" ARE TO 1/16"
 DIMENSIONS TO 14272476924765634556764675232976" ARE TO 1/16"
 DIMENSIONS TO 28544953849531269113529350465952" ARE TO 1/16"
 DIMENSIONS TO 57089907699062538227058700931904" ARE TO 1/16"
 DIMENSIONS TO 11417981539812507645411740183808" ARE TO 1/16"
 DIMENSIONS TO 22835963079625015290823480367616" ARE TO 1/16"
 DIMENSIONS TO 45671926159250030581646960735232" ARE TO 1/16"
 DIMENSIONS TO 91343852318500061163293921470464" ARE TO 1/16"
 DIMENSIONS TO 182687704637000122326587842944128" ARE TO 1/16"
 DIMENSIONS TO 365375409274000244653175685888256" ARE TO 1/16"
 DIMENSIONS TO 730750818548000489306351371776512" ARE TO 1/16"
 DIMENSIONS TO 1461501637096000978612702743552024" ARE TO 1/16"
 DIMENSIONS TO 2923003274192001957225405487104048" ARE TO 1/16"
 DIMENSIONS TO 5846006548384003914450810974208096" ARE TO 1/16"
 DIMENSIONS TO 11692013096768007828901621948416192" ARE TO 1/16"
 DIMENSIONS TO 23384026193536015657803243896832384" ARE TO 1/16"
 DIMENSIONS TO 46768052387072031315606487793664768" ARE TO 1/16"
 DIMENSIONS TO 93536104774144062631212975587329536" ARE TO 1/16"
 DIMENSIONS TO 187072209548288125262425951175659104" ARE TO 1/16"
 DIMENSIONS TO 374144419096576250524851902351318208" ARE TO 1/16"
 DIMENSIONS TO 748288838193152501049703804702636416" ARE TO 1/16"
 DIMENSIONS TO 1496577676366245020998407609405272832" ARE TO 1/16"
 DIMENSIONS TO 2993155352732490041996815198810545456" ARE TO 1/16"
 DIMENSIONS TO 59863107054649800839936303976210910912" ARE TO 1/16"
 DIMENSIONS TO 11972621411329960167987260795241821824" ARE TO 1/16"
 DIMENSIONS TO 239452428226599203359745215914843643648" ARE TO 1/16"
 DIMENSIONS TO 47890485645319840671949043182887287392" ARE TO 1/16"
 DIMENSIONS TO 9578097129063968133989808636574574784" ARE TO 1/16"
 DIMENSIONS TO 19156194258127936277979617273149149696" ARE TO 1/16"
 DIMENSIONS TO 38312388516255872555959234546298339328" ARE TO 1/16"
 DIMENSIONS TO 76624777032511745111918469092596678656" ARE TO 1/16"
 DIMENSIONS TO 153249554065023490223836938185193357312" ARE TO 1/16"
 DIMENSIONS TO 306499108130046980447673876370386714624" ARE TO 1/16"
 DIMENSIONS TO 61299821626009396089534775274077329248" ARE TO 1/16"
 DIMENSIONS TO 122599643252018792179069550548154658496" ARE TO 1/16"
 DIMENSIONS TO 245199286504037584358139101096309178992" ARE TO 1/16"
 DIMENSIONS TO 490398573008075168716278202192618357984" ARE TO 1/16"
 DIMENSIONS TO 980797146016150337432556404385236715968" ARE TO 1/16"
 DIMENSIONS TO 196159429203230067486511280870451343936" ARE TO 1/16"
 DIMENSIONS TO 392318858406460134973022561740926868784" ARE TO 1/16"
 DIMENSIONS TO 784637716812920269946045123481853371776" ARE TO 1/16"
 DIMENSIONS TO 156927543362584053989209024696366735552" ARE TO 1/16"
 DIMENSIONS TO 313855086725168107978418049392733471104" ARE TO 1/16"
 DIMENSIONS TO 627710173450336215956836098785466842208" ARE TO 1/16"
 DIMENSIONS TO 1255420346900672439136721177570933644416" ARE TO 1/16"
 DIMENSIONS TO 2510840693801344878273442355141867288832" ARE TO 1/16"
 DIMENSIONS TO 50216813876026897565468471102833567776" ARE TO 1/16"
 DIMENSIONS TO 100433627752053795130936942205667135552" ARE TO 1/16"
 DIMENSIONS TO 2008672555041075902618738444113342271104" ARE TO 1/16"
 DIMENSIONS TO 401734511008215180523747688822664422208" ARE TO 1/16"
 DIMENSIONS TO 8034690220164303610474953776453288444416" ARE TO 1/16"
 DIMENSIONS TO 1606938044032860722094990755290656888832" ARE TO 1/16"
 DIMENSIONS TO 32138760880657214441898151105813177776" ARE TO 1/16"
 DIMENSIONS TO 642775217613144288837793022116263555552" ARE TO 1/16"
 DIMENSIONS TO 128555043522628857767558604423253111104" ARE TO 1/16"
 DIMENSIONS TO 257110087045257715535117308846506222208" ARE TO 1/16"
 DIMENSIONS TO 514220174090515431070234617693012444416" ARE TO 1/16"
 DIMENSIONS TO 1028440348181030862140469235386024888832" ARE TO 1/16"
 DIMENSIONS TO 20568806963620617242809387077720977776" ARE TO 1/16"
 DIMENSIONS TO 41137613927241234485618774155441955552" ARE TO 1/16"
 DIMENSIONS TO 82275227854482468971235482310883911104" ARE TO 1/16"
 DIMENSIONS TO 164550457708964937942470964617767822208" ARE TO 1/16"
 DIMENSIONS TO 329100915417929875884941932135536444416" ARE TO 1/16"
 DIMENSIONS TO 658201830835859751769889864271068888832" ARE TO 1/16"
 DIMENSIONS TO 13164036616717195035397797285421377776" ARE TO 1/16"
 DIMENSIONS TO 26328073233434390070795594570842755552" ARE TO 1/16"
 DIMENSIONS TO 52656146466868780141591189141685511104" ARE TO 1/16"
 DIMENSIONS TO 105312292933737560283183782283711022208" ARE TO 1/16"
 DIMENSIONS TO 210624585867475120566367564567422444416" ARE TO 1/16"
 DIMENSIONS TO 421249171734950241132735129134844888832" ARE TO 1/16"
 DIMENSIONS TO 84249834346990048226547025826968977776" ARE TO 1/16"
 DIMENSIONS TO 16849966873398009645309405165937955552" ARE TO 1/16"
 DIMENSIONS TO 33699933746796019290618810331875911104" ARE TO 1/16"
 DIMENSIONS TO 67399867493592038581237206663751822208" ARE TO 1/16"
 DIMENSIONS TO 134799735187184077162474413327536444416" ARE TO 1/16"
 DIMENSIONS TO 26959947037436815432494882665507288832" ARE TO 1/16"
 DIMENSIONS TO 53919894074873630864999753331014577776" ARE TO 1/16"
 DIMENSIONS TO 107839788149747261729999506662029155552" ARE TO 1/16"
 DIMENSIONS TO 215679576299494523459999013324058311104" ARE TO 1/16"
 DIMENSIONS TO 431359152598989046919998026648116622208" ARE TO 1/16"
 DIMENSIONS TO 862718305197978093839996053296232444416" ARE TO 1/16"
 DIMENSIONS TO 172543661039595618767993210659246488832" ARE TO 1/16"
 DIMENSIONS TO 345087322079191237535986421318492977776" ARE TO 1/16"
 DIMENSIONS TO 69017464415838247507197284263698595552" ARE TO 1/16"
 DIMENSIONS TO 138034928831674550142394565263971911104" ARE TO 1/16"
 DIMENSIONS TO 276069857663349100284789130527943822208" ARE TO 1/16"
 DIMENSIONS TO 552139715326698200569578261057876444416" ARE TO 1/16"
 DIMENSIONS TO 110427943065339640113915752211575288832" ARE TO 1/16"
 DIMENSIONS TO 22085588613067928022783150442315177776" ARE TO 1/16"
 DIMENSIONS TO 44171177226135856045566300884630355552" ARE TO 1/16"
 DIMENSIONS TO 8834235445227171209113260176926111104" ARE TO 1/16"
 DIMENSIONS TO 17668470890454342418226520353852222208" ARE TO 1/16"
 DIMENSIONS TO 3533694178090868483645304070770444416" ARE TO 1/16"
 DIMENSIONS TO 7067388356181736967290608141540888832" ARE TO 1/16"
 DIMENSIONS TO 1413477671236347393458121628291777776" ARE TO 1/16"
 DIMENSIONS TO 2826955342472694786916432556583555552" ARE TO 1/16"
 DIMENSIONS TO 5653910684945389573832865113167111104" ARE TO 1/16"
 DIMENSIONS TO 1130782136989077914766573026234222208" ARE TO 1/16"
 DIMENSIONS TO 2261564273978155829533460532468444416" ARE TO 1/16"
 DIMENSIONS TO 4523128547956311659066810664936888832" ARE TO 1/16"
 DIMENSIONS TO 90


ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927538	EA	1	TRACK DUCT BASE 10'
2	927441	EA	1	TRACK DUCT COVER 10'
3	927441	EA	1	CENTER COVER, E.Z. SPLICE
4	927442	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	927774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
8	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH



REV.	EDA.	BY	REVISION DESCRIPTION	DATE	APPROVED
J	---	TB	REMOVE 92744, 28080, 28081	05/28/99	---
K	02-	RF	REPLACE 29016 W/29051	08/29/02	---
L	06-	RF	NEW SPLICE SYSTEM	05/18/05	---
M	06-	RO	NEW SUPPORT ASSEM. DESIGN	10/27/05	---



1/8 SCALE




FULL SCALE

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS DIMENSIONS IN MILLIMETERS DO NOT SCALE DRAWINGS		DRAWN RPF	
DATE 02/15/93		TITLE TRACK DUCT 10' MID ASSEMBLY / B.O.M.	
DRAWN RPF		DWG NO. 9278-1201	
DATE 02/15/93		SCALE 1/4"	
DRAWN RPF		DRAWING SIZE B	
DATE 02/15/93		SHEET 1 OF 1	
DRAWN RPF		REV M	
DATE 02/15/93		SCALE 1/4"	
DRAWN RPF		DRAWING SIZE B	
DATE 02/15/93		SHEET 1 OF 1	
DRAWN RPF		REV M	

© RAILWAY EQUIPMENT CO. 1993-2005
RAILWAY EQUIPMENT CO.
 DARIANO, MINNESOTA
 (763) 978-2800

REV.	Q.C.A.	BY	REVISION DESCRIPTION	DATE	APPROVED
J	02-0046	TB	UPDATE TRACK DUCT SUPPORT	05/26/99	----
K	05-0017	RF	REPLACE 29016 W/29051	08/29/02	----
L	05-0047	RF	NEW SPLICE SYSTEM	05/18/05	----
M	05-0047	RO	NEW SUPPORT ASSM DESIGN	10/27/05	----


ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927538	EA	1	TRACK DUCT BASE 10'
2	92740	EA	1	END PLATE, TRACK DUCT
3	92741	EA	1	TRACK DUCT COVER 10'
4	927441	EA	1	CENTER COVER, E.Z. SPLICE
5	927442	EA	2	END COVER, E.Z. SPLICE
6	927450	EA	1	BASE, E.Z. SPLICE
7	92774	EA	1	TRACK DUCT SUPPORT BRACKET
8	92785	EA	1	DEFLECTOR, TRACK DUCT, SMALL
9	29051	EA	9	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
10	6093-0100	EA	1	TY-RAP, 4" .10 WIDTH



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS IN INCHES
TOLERANCES UNLESS OTHERWISE SPECIFIED:
FRACTIONS TO TWO DECIMALS
DECIMALS TO THREE
HOLE DIMENSIONS TO TWO DECIMALS
DO NOT SCALE DRAWING





DATE	02/15/93	DRAWN	RPF
MATERIAL	SEE PRINT	DATE	02/15/93
SCALE	1/4"	DRAWING SIZE	B
TITLE	TRACK DUCT 10' HEEL ASSEMBLY / B.O.M.	REV	M
DWG NO.	9278-1202	SHEET	1 OF 1

© RAILWAY EQUIPMENT CO. 1993-2005
RAILWAY EQUIPMENT CO.
DRIELAND, MINNESOTA (763) 972-3800



ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	9278-0207	EA	1	TRACK DUCT 7' HEEL
2	9278-0227	EA	1	ISO KIT, 1R NOZZLE LARGE
3	927480	EA	1	NOZZLE, TRACK DUCT
4	41023	EA	1	BOX, TRACK DUCT KIT

REV.	EDA.	REV.	REVISION DESCRIPTION	DATE	APPROVED
A	02-027	RF	NEW PART	07/03/02	----
B	03-023	RF	UPDATE NOZZLE	07/29/03	----
C	05-017	RF	NEW SPLICE DESIGN	05/25/05	----
D	05-027	RO	NEW TRACK DUCT NOZZLE	11/10/05	----
E	05-054	RJ	NEW TRACK DUCT NOZZLE	02/02/07	----



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS ARE TO FACE UNLESS NOTED OTHERWISE
TOLERANCES ARE:
FRACTIONS DECIMALS
.000 & .010 FRACTIONS .0005 & .0010 DECIMALS
DO NOT SCALE DRAWINGS

DRAWN: RPF
DATE: 07/03/02

APPROVED: N/A
DATE: N/A

SCALE: N/A

TITLE: TRACK DUCT KIT, 7' LARGE NOZZLE

DWG NO.: 9278-0270

REV: E






SHEET: 1 OF 1

© RAILWAY EQUIPMENT CO. 2002-2005

RAILWAY EQUIPMENT CO.
DELANO, MINNESOTA (763) 973-2300

REV.	DATE	BY	DESCRIPTION
D	6/21/91	EFK	REDESIGN FOR SPRING MOUNT.
E	9/25/92	EFK	CHG. P/N 927135 REV.B TO 927135 REV.C
F	7/8/94	EFK	CHG. P/N 92742 REV.A TO 92742 REV.B
G	5.26.99	TB	ADD ITEMS 10 THRU 15
H	4.11.01	TB	#92743B WAS 92743A
J	05/18/05	RF	NEW SPLICE SYSTEM
K	10/27/05	RO	SHORTENED 927550-551

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92745	EA	1	HOLDDOWN STRAP, TRACK DUCT
2	92750	EA	1	TRACK DUCT SUPPORT BASE
3	92751	EA	1	TRACK DUCT SPRING BRKT
4	92742	EA	2	SPRING, TRACK DUCT SUPPORT BRKT
5	283155110	EA	2	SPRING CLIP, TRACK DUCT SUP-BRKT
6	28315801	EA	2	1/4-20 X 5/8 HEX BOLT #5 HARD
7	28315810	EA	2	1/4-20 CENTERLOCK NUT
8	28045	EA	2	3/8 FLAT WASHER
9	14042	EA	1	LAG BOLT 3/8 X 2.5
10	14045	EA	1	BAG, ZIPLOCK 4 x 6 x .004
11	14045	EA	1	BAG, ZIPLOCK 12 x 15 x .004



© RAILWAY EQUIPMENT CO. 1990-2005


RAILWAY EQUIPMENT CO.
 MILWAUKEE, WISCONSIN (708) 875-3800

DESIGNED BY	DATE	6/21/91
CHECKED BY	DATE	
APPROVED BY	DATE	

DATE PLOTTED: 11/17/05
 PLOTTED BY: J. J. J. J.
 MATERIAL: STEEL
 FINISH: GALV.
 SCALE: 1:1

ITEM NO. 92774
 SHEET 1 OF 1

NOTE: DRIVE SETTINGS:
 30 P100=1
 P102=59.9
 P108=45
 P110=3
 P140=3



HOT AIR BLOWER CONTROL MODULE
 9338-0320

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO BE USED
 XX = DIMENSIONS IN PARENTHESES
 XXX = DIMENSIONS IN PARENTHESES
 DO NOT SCALE DRAWING


RAILWAY EQUIPMENT CO. 2011
 RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-2200

TITLE: **GAS HOT AIR BLOWER 5HP 240V 1 PHASE AC 3 PHASE DRIVE SCHEMATIC / CONNECTION DIAGRAM**

DATE: 05/27/2009
 DRAWN: JB
 DWG NO.: 9534-0156
 REV: A

SCALE: NONE
 SHEET: 1 OF 1

REV.	DATE	BY	DESCRIPTION
A	7/27/09	AS	REVISION B
B	7/27/09	AS	ADDED 208/230VAC
C	07/09/11	ES	NEW MODULE
D	07/09/11	CS	NEW MODULE



© RAILWAY EQUIPMENT CO. 2011


RAILWAY EQUIPMENT CO.
MINNEAPOLIS, MINNESOTA (763) 973-2200

TITLE: GAS HOT AIR BLOWER
208/230/460/575/VAC, 3PH, 2 STAGE
SCHEMATIC / CONNECTION DIAGRAM


DWG NO. 9504-0125 REV D

DRAWING BY: J.L.H. DRAWING SIZE: A SHEET 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	952840	EA	1	BURNER, 12 INCH WELDED
2	53070	EA	1	FLAME ROD, REF AUBURN #FRS-4-7/8
3	96070	EA	1	SPARK IGNITOR, REF AUBURN #I-31-1
4	283185112	EA	4	BOLT, 3/8-16 X 3/4
5	2832-8904	EA	4	NUT, 3/8-16 CENTER LOCK
6	952103	EA	1	SUPPORT BRACKET 12 INCH BURNER
7	881402	FT	3.5	WIRE, 14GA HIGH TEMP
8	6033-0100	EA	1	LUG, RING #10 16-14GA HI-TEMP
9	6032-0112	EA	1	LUG, RING 1/4 16-14GA NYLON
10	2831417408	EA	1	SCREW, #10-32 X 1/2 PANI SLT SS
11	2832-4201	EA	2	NUT, #10-32 HEX SS
12	2833-4310	EA	2	WASHER, #10 EXT. STAR
13	61028	EA	1	UNION, 1 IN SCH 40 BLACK
14	61028	EA	1	NIPPLE, 1 X 4 IN SCH 40 BLACK



IGNITOR FLAME SENSOR & SPARK
IGNITOR NOT SHOWN THIS VIEW



REV	DATE	DESCRIPTION
B	07/20/04	NEW BURNER
-	-	ADDED WIRE, NIPPLE & UNION

© RAILWAY EQUIPMENT CO. 2003-2004

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS ARE TO CENTER UNLESS NOTED OTHERWISE
DIMENSIONS ARE TO CENTER UNLESS NOTED OTHERWISE
DIMENSIONS ARE TO CENTER UNLESS NOTED OTHERWISE

DRAWN: RPF
DATE: 12/23/03
MATERIAL: N/A
TYP: 1/2004


TITLE:
BURNER
12 INCH STAINLESS
(ASSEMBLY / B.O.M.)

DWG NO.: 9528-0135
SCALE: 1/2" DRAWING SIZE: B SHEET: 1 OF 1

RAILWAY EQUIPMENT CO.
DARIANO, MINNESOTA (763) 973-2800

REV: B

GHAB MENU



OPERATING MANUAL

MODEL NO. 965 BUNGALOW

GAS FIRED HOT AIR BLOWER

TRACK SWITCH SNOW MELTER

WITH STEEL TIE DUCT

MANUFACTURED

BY

RAILWAY EQUIPMENT COMPANY

525 NINTH STREET SOUTH

DELANO, MINNESOTA 55328

TEL. 763-972-2200

FAX. 763-972-2900

E-Mail:

Support: Techsupport@rwy.com

Sales: Order@rwy.com



CAUTION

GENERAL HAZARD WARNING

FAILURE TO COMPLY WITH THE PRECAUTIONS AND INSTRUCTIONS PROVIDED WITH THIS HEATER, CAN RESULT IN DEATH, SERIOUS INJURY AND PROPERTY LOSS OR DAMAGE FROM HAZARDS OF FIRE, EXPLOSION, BURN, ASPHYXIATION, CARBON MONOXIDE POISONING, AND/OR ELECTRICAL SHOCK.

ONLY PERSONS WHO CAN UNDERSTAND AND FOLLOW THESE INSTRUCTIONS SHOULD USE OR SERVICE THIS HEATER.

IF YOU NEED ASSISTANCE OR HEATER INFORMATION, SUCH AS INSTRUCTION MANUALS, LABELS, ETC., CONTACT THE MANUFACTURER.



CAUTION

WARNING: FIRE, BURN, INHALATION, AND EXPLOSION HAZARD.

KEEP SOLID COMBUSTIBLES, SUCH AS BUILDING MATERIALS, PAPER OR CARDBOARD, A SAFE DISTANCE AWAY FROM THE HEATER AS RECOMMENDED BY THE INSTRUCTIONS. NEVER USE THE HEATER IN SPACES WHICH DO OR MAY CONTAIN VOLATILE OR AIRBORNE COMBUSTIBLES, OR PRODUCTS SUCH AS GASOLINE, SOLVENTS, PAINT THINNER, DUST PARTICLES OR UNKNOWN CHEMICALS.



CAUTION

NOT FOR HOME OR RECREATIONAL VEHICLE USE

The heater is designed and approved for use as a construction heater under ANSI Z83.7

We cannot anticipate every use which may be made of our heaters.

CHECK WITH LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT APPLICATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

PLEASE READ THIS INSTRUCTION MANUAL ENTIRELY BEFORE HANDLING THIS MATERIAL OR ATTEMPTING TO INSTALL, OPERATE OR SERVICE THIS HOT AIR BLOWER SYSTEM.

PLEASE READ THE WARNINGS AND CAUTIONS LISTED BELOW.



SHEET METAL EDGES MAY BE VERY SHARP AND CAN CAUSE SEVERE CUTS OR LACERATIONS. PROTECTIVE GLOVES AND CLOTHING SHOULD BE WORN. USE CAUTION WHEN HANDLING ALL SHEET METAL COMPONENTS.



THIS HOT AIR BLOWER TRACK SWITCH SNOWMELTER SYSTEM CAN BE OPERATED REMOTELY OR BY A SNOW DETECTOR SYSTEM. THEREFORE, OPERATION MAY BEGIN UNEXPECTEDLY. USE CAUTION WHEN IN THE AREA.



SYSTEM OPERATES WITH VARIOUS VOLTAGE LEVELS UP TO 600VAC. CONTACT WITH ELECTRICITY CAN BE HAZARDOUS OR LETHAL. MAKE SURE THAT THE MAIN CIRCUIT BREAKER IS TURNED OFF BEFORE ATTEMPTING TO SERVICE THIS SYSTEM. EVEN WITH CIRCUIT BREAKER OFF LINE VOLTAGE IS PRESENT AT THE TOP CIRCUIT BREAKER CONNECTIONS.



THIS SYSTEM CONTAINS A HIGH SPEED AIR FAN WHICH ROTATES AT UP TO 3600RPM AND CREATES FORCEFUL SUCTION WHEN OPERATING. DO NOT OPERATE THE BLOWER SYSTEM IF ANY OF THE DUCTWORK COMPONENTS HAVE BEEN REMOVED.



THIS SYSTEM OPERATES WITH NATURAL GAS OR PROPANE. BOTH ARE GASES WHICH ARE FLAMMABLE AND EXPLOSIVE. USE EXTREME CAUTION WHEN WORKING IN THE AREA. AVOID ANY OPEN FLAME, SPARKS OR OTHER SOURCE OF IGNITION.



THE OUTLET AIR TEMPERATURE FROM THIS GAS SNOW MELTER SYSTEM SHOULD NOT EXCEED 375°F FROM ANY NOZZLE OR DUCT. **DO NOT OPERATE THIS BLOWER SYSTEM IF THE OUTLET TEMPERATURE EXCEEDS 375°F.** AN ACCURATE THERMOMETER SHOULD BE USED TO REGULARLY CHECK THE OUTLET AIR TEMPERATURE. IF THE OUTLET TEMPERATURE EXCEEDS 375°F, CHECK TO MAKE SURE THAT THE FLOW OF AIR IS NOT RESTRICTED AT ANY POINT, THAT THE BLOWER/MOTOR ARE OPERATING PROPERLY, THAT THE CORRECT ORIFICE IS USED FOR THE TYPE OF FUEL USED, AND THAT THE REGULATOR(S) ARE PROPERLY ADJUSTED FOR THE FUEL BEING USED. CONSULT RAILWAY EQUIPMENT COMPANY IF YOU ARE UNABLE TO OPERATE THIS GAS SNOW MELTER SYSTEM BELOW 375°F.

A HIGH TEMPERATURE LIMIT SYSTEM HAS BEEN INCORPORATED INTO ALL RAILWAY EQUIPMENT COMPANY GAS SNOW MELTER SYSTEMS BEGINNING IN 1999. RAILWAY EQUIPMENT COMPANY ALSO HAS A HIGH TEMPERATURE LIMIT MODIFICATION KIT THAT CAN BE ADDED TO GAS SNOW MELTER SYSTEMS MANUFACTURED PRIOR TO 1999. IT IS RECOMMENDED THAT THIS HIGH TEMPERATURE LIMIT SYSTEM BE INSTALLED AND USED. CONSULT RAILWAY EQUIPMENT TO ORDER THE HIGH TEMPERATURE MODIFICATION KIT, OR IF YOU NEED ASSISTANCE REGARDING THE HIGH TEMPERATURE LIMIT SYSTEM.

THIS SNOW MELTER SYSTEM HAS BEEN DESIGNED TO PROVIDE DEPENDABLE EFFECTIVE OPERATION IN ALL WEATHER CONDITIONS WITHOUT SWITCH COVERS. SWITCH COVERS MAY CAUSE HIGHER AIR TEMPERATURES. IF SWITCH COVERS ARE USED, YOU MUST DETERMINE A SAFE OPERATING AIR TEMPERATURE AND ADJUST BURNER PARAMETERS ACCORDINGLY. ADJUSTMENT OF BURNER PARAMETERS MAY NEGATIVELY AFFECT BURNER PERFORMANCE AND COMBUSTION CHARACTERISTICS TO THE EXTENT THAT THE BURNER MAY BE UNABLE TO MAINTAIN COMBUSTION. CONSULT RAILWAY EQUIPMENT COMPANY REGARDING BURNER OPERATING PARAMETERS.

TWO (2) COMPLETE INSTRUCTION MANUALS HAVE BEEN INCLUDED WITH THIS SNOW MELTER SYSTEM. PLEASE KEEP ONE OF THE MANUALS WITH THE SYSTEM AFTER INSTALLATION. ANYONE OPERATING OR SERVICING THIS SNOW MELTER SYSTEM SHOULD READ THE MANUAL ENTIRELY BEFORE PROCEEDING.

IF YOU HAVE ANY QUESTIONS CONCERNING THE MANUFACTURE, DESIGN, FUNCTION, INSTALLATION, OPERATION OR MAINTENANCE, CONTACT RAILWAY EQUIPMENT COMPANY BEFORE PROCEEDING.


TABLE OF CONTENTS

I.	GENERAL INFORMATION	8
A.	MODEL NUMBER DESCRIPTION	8
B.	STANDARD FEATURES	8
II.	COMPONENT DESCRIPTION	10
A.	MAIN HAB UNIT	10
B.	STANDARD DUCTWORK	11
C.	OPTIONAL DUCTWORK	12
III.	INSTALLATION	14
A.	TIE DUCT	14
B.	BUNGALOW PLACEMENT	15
C.	POINT NOZZLES AND TRACK DUCTS	16
D.	GAS CONNECTION	17
E.	CHANGING THE GAS ORIFICE	20
F.	ELECTRICAL CONNECTION	21
IV.	CONTROL MODULE	23
A.	DESCRIPTION	23
B.	SET-UP AND ADJUSTMENTS	24
C.	LED STATUS INDICATING LIGHTS	29
D.	OPERATION	30
E.	FAULT CONDITIONS	31
V.	SEASONAL MAINTENANCE	35
VI.	LOW PRESSURE REGULATOR ADJUSTMENT	36
VII.	TROUBLESHOOTING	37
A.	UNIT DOES NOT START	37
B.	UNIT DOES NOT MAINTAIN OPERATIONS	37
C.	LOW HEAT LEVEL	37
D.	LOW AIRFLOW	38
E.	GAS VALVE	38
F.	HIGH HEAT LEVEL	38
VIII.	SNOW DETECTOR	39
A.	INSTALLATION	39
B.	OPERATION	40
C.	MAINTENANCE	40
D.	TROUBLESHOOTING	41

IX.	SPECIFICATIONS	42
X.	DRAWINGS	43
XI.	LIMITED WARRANTY	44

I. GENERAL INFORMATION

A. MODEL NUMBER DESCRIPTION



B. STANDARD FEATURES OF 950/951 SERIES TRACK SWITCH HOT AIR BLOWER

1. GHAB complies with AREMA 12.6.10.
2. Gas fired operation, allows for both propane and natural gas (convertible in the field)
3. Two stage operation (400,000 / 200,000 BTU) that allows savings on fuel costs.
4. 2 H.P. direct drive motor, totally enclosed fan cooled, 230VAC 60Hz, single phase.
5. High efficiency, quiet operation , 2000 CFM blower.
6. Remote operation via contact closure (low voltage, low current) with timed shut off.
7. Built-in snow detector system (requires Snow Detector assembly option).
8. Auto-Off-Force switch.
9. High temperature limit thermostat/shut off.
10. Adjustable air temperature control.
11. Adjustable rail temperature control.
12. Reply indication via GHAB contact closure.
13. Fail indication via GHAB contact closure.
14. Main circuit breaker.
15. Audible tone before blower startup
16. Weathertight gasketed control enclosure

17. Status indicating lights for all control functions
18. Start delay timer for sequential startup
19. Run timer for timed operation
20. Selectable "Transparent" snow detector operation
21. Snow detect timer
22. All ductwork and nozzles are thermally and electrically isolated from tracks
23. Quick-release track duct
24. Blower motor starter with overload protection
25. Remote auxiliary gas valve (115vac) supplied connection
26. Gas line accessories:
 - A. Manual gas valve
 - B. Gas line strainer
 - C. Low pressure regulator
 - D. Flexible gas line connection pipe
27. Elevated air intake
28. Adjustable delay for start up (10 Sec. -5 Min.)
29. Complete flame safeguard control:
 - A. Pre-ignition air purge.
 - B. Air flow proving switch
 - C. Direct spark ignition
 - D. Flame proving sensor
 - E. Post shut off air purge 4 Min.
 - F. Automatic shut off on loss of flame or air flow
 - G. Leaky gas valve
 - H. Automatic retry on flame loss
 - I. Automatic reset on flame safeguard control
 - J. All flame safeguard controls CSA listed.
30. All components mounted and wired within main unit – no external wiring required except for remote control, indications and optional snow detectors.
31. Galvanized case constructed of 14-gauge steel, high temperature baked enamel finish.
32. Convenient panel access to high efficiency burner, flame sensor and spark igniter.
33. Galvanized steel adjustable mounting foundations.
34. Standard ductwork: 1.5' flame duct with 2.5' straight insulated flexible duct and heavy duty insulated offset duct connects to main tie duct electrically insulated between rails, 24 inch (minimum) switch point nozzles.

The following items are recommended for use with propane gas service:

Tank "pigtail" with POL/POL fittings (P/N 45038-12" or 60127-36")
High pressure regulator (P/N 45103)
Gas line strainer (P/N 45040)
Remote solenoid valve (P/N 45036) OR
Complete Propane Package (P/N 9458-0100)

II. COMPONENT DESCRIPTION

A. MAIN HOT AIR BLOWER (HAB) UNIT

- 1. MAIN CIRCUIT BREAKER:** Provides main over-current protection and manual on-off control of electrical power.
- 2. MOTOR CONTACTOR:** Provides automatic blower motor control, with high current contacts.
- 3. MOTOR OVERLOAD RELAY:** Protects the blower motor from an over-current condition.
- 4. CONTROL MODULE:** Provides complete control of operation. See separate description and details, section IV.
- 5. CONTROL TRANSFORMER:** Provides control power for the control module and other control components. The multi-tapped secondary provides, 36VAC CT and 17VAC CT. The primary has 115VAC input plus a 230VAC step-up winding and 12.6 VAC CT windings.
- 6. IGNITION TRANSFORMER:** Provides 10000VAC to the spark igniter during the ignition sequence.
- 7. AIRFLOW SWITCH:** Located in the flame duct, the sail switch indicates proper airflow before and during burner operation. The differential setting is determined by elevation.
- 8. BURNER:** Contains the actual flame. Also holds the spark igniter and the flame-sensing rod.
- 9. PROPANE/NATURAL GAS ORIFICE PLATE:** Controls the rate of flow of gas to the burner.
- 10. SPARK IGNITER:** The spark plug type igniter provides spark for the burner. The spark igniter is momentary - sparks only until the flame has been established.

11. **FLAME DETECTION ROD:** The flame detection rod monitors the flame at the burner nozzle using the rectification principle. This provides a low-level signal to the control module if a proper flame exists.
12. **AIR TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the ambient air temperature.
13. **RAIL TEMPERATURE SENSOR:** This is an analog type sensing circuit to monitor the actual rail temperature.
14. **GAS VALVE:** This is an electric solenoid valve which controls the flow of gas for burner operation. It is controlled directly from the control module.
15. **BLOWER MOTOR:** The 3HP 3450RPM motor is totally enclosed and fan cooled.
16. **BLOWER:** The high efficiency blower wheel provides up to 3600CFM airflow. It is dynamically balanced for smooth and quiet operation.
17. **BUZZER:** The buzzer will sound a 10-second tone immediately before the motor contactor is energized.

B. STANDARD DUCTWORK

1. **HEAT DUCT:** The first section of ductwork attached to the main HAB unit. This duct contains the burner, air flow switch, spark igniter and the duct pressure sensor.
2. **FLEX DUCT:** Connects the heat duct to the offset duct. It is a section of flexible duct, 24" long, enclosed in an insulated sheet metal wrapper.
3. **HEAVY DUTY OFFSET DUCT:** Connects the flex duct to the tie outlet duct. This duct provides an 8" offset and encloses the air mixer.
4. **TIE OUTLET DUCT:** The outlet duct extends under the rails in place of a tie and directs the airflow to the point nozzles and track ducts. The rail attaches to the duct using tie plates and E clips. The tie plates are electrically insulated from the rail using an insulating kit. There are six openings in the top for point nozzles and track duct nozzles. Refer to drawing 9528-4805 and 963N32902 for the duct layout.
5. **TRACK DUCTS:** These ducts rest on brackets on the ties and the outlet duct. They are installed over the track duct nozzles. The track ducts consist of a 5' point, a 5' mid, and 10' sections to complete the desired length.

6. **TRACK DUCT NOZZLE:** Attaches to the inner two rectangular openings on the top of the outlet duct. Directs airflow down the length of the switch through the track ducts.
7. **TRACK DUCT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0027 for proper installation.
8. **QUICK CHANGE NOZZLE PLATE:** This plate allows for quick removal or installation of nozzles to the tie duct, by simply loosening of four bolts the nozzle assembly can be removed or installed.
9. **TRACK DUCT SUPPORT BRACKET:** These brackets are used to secure the track duct in position. Refer to drawing 92774.
10. **SWITCH POINT NOZZLE:** These nozzles direct heated air down the switch point. They are mounted on the outlet duct. They can be adjusted for proper airflow direction. Nozzles may be shortened by up to 10" for proper fit.
11. **POINT NOZZLE ISOLATING KIT:** This is an electrically insulating gasket with insulating washers and hardware to provide isolation between the nozzles and the outlet duct. Refer to drawing 9278-0021 for proper installation.

C. OPTIONAL DUCTWORK

1. **EXTENSION DUCTS:** Extension ducts of various lengths are available to meet specific requirements. These are insulated and enclosed in a metal wrapper. Make sure the duct is mounted in the correct orientation, as there is an access opening underneath the insulating wrapper cover. If additional duct extensions are required, this assembly can be added between the outlet duct and the offset duct.
2. **7' TRACK DUCT:** These track ducts are seven feet long. They are often mounted outside of the track near the switch machine. A kit is available (P/N 9278-0270) that includes a 7' track duct, a track duct nozzle and a track duct isolation kit.

OTHER DUCTWORK ASSEMBLIES ARE AVAILABLE. CONSULT THE FACTORY FOR SPECIAL DUCTWORK NEEDS.

(INTENTIONALLY LEFT BLANK)

III. INSTALLATION

INSTALLATION SHOULD BE DONE IN THIS ORDER:

- A. TIE DUCT OUTLET DUCT/OFFSET DUCT
- B. MAIN HAB UNIT/FLEX DUCT
- C. POINT NOZZLES AND TRACK DUCTS
- D. GAS
- E. CHANGING THE GAS ORIFICE
- F. ELECTRICAL

**PLEASE READ THROUGH THE ENTIRE
INSTRUCTIONS BEFORE BEGINNING INSTALLATION.**

A. TIE DUCT

1. Remove the appropriate tie. Choose the tie that will result in the point nozzles being as close to the switch point as possible without interfering with normal switch operation. The distance from the center of the tie duct to the end of the point nozzles is 33". If necessary, up to 10" may be cut off each point nozzle.
2. Remove sufficient ballast to provide at least 14" clearance from the bottom of the rails.
3. Carefully slip the tie duct under the rails and position it so that the rails are directly above the tie plates. Ensure that the tie duct is centered between the adjacent ties.
4. Place a rubber pad on the tie plate, then using a suitable lever, raise one end of the tie duct until the rail lies correctly on the pad on the tie plate. Place two e-clip insulators, one on each side of rail, in place and then fasten the rail to the tie plate using two of the four 927248 rail clips. Use a heavy hammer or maul to drive the clips securely into place.
5. While keeping the tie duct supported in place, firmly pack ballast under the tie duct from the rail out to the end.
6. Repeat steps 4 and 5 for the other end of the tie duct.
7.
 - a. Remove the end flange plate nearest the HAB by loosening the six retainer bolts.
 - b. Install the two-foot heavy duty offset duct (P/N 9278-3403) to the tie duct using hardware and gasket supplied with the offset duct.
8. Firmly repack ballast under the entire tie duct.

B. BUNGALOW PLACEMENT

1. Attach the 2' offset duct (P/N 9528-3103) to the flame duct using the bolt and gasket kit from the flame duct.
2. Attach the 2-1/2' flex duct (P/N 9528-4220) to the offset duct on the flame duct, using the bolt kit from the offset duct.
3. Position the bungalow to line up with the 2' heavy duty offset duct and the 2' flex duct (Refer to Drawing #963N32902).
4. Connect the heavy duty offset duct to the flex duct using the bolts and gasket provided with the flex duct and level the bungalow.
5. Adjustable Air Intake. To start the GHAB in a new location, set the intake screen in the closed position. If there proves to be a moisture problem where frost builds up on the intake screen, the screen can be set in the open position to improve the air intake to the GHAB.
6. The airflow switch differential setting is factory set on "D" which is for elevations below 2000 ft. If your location is set at a higher elevation, this differential setting will need to be adjusted. Adjust per the following instructions:
 - a) Remove the galvanized cover over the airflow switch.
 - b) Remove the cover from the airflow switch.
 - c) Adjust the differential wheel on the base of the airflow switch as follows:

Below 2000 ft elevation, set Airflow Differential Wheel to "D"

Below 4000 ft elevation, set Airflow Differential Wheel to "C"

Below 6000 ft elevation, set Airflow Differential Wheel to "B"

Above 6000 ft elevation, set Airflow Differential Wheel to "A"

C. POINT NOZZLES AND TRACK DUCTS

REFER TO DRAWING 963N32902 FOR TRACK DUCT AND POINT NOZZLE POSITIONS.

1. Attach switch point nozzles to the openings in the outlet duct. Position nozzles for proper airflow direction. Instructions are included in the isolation kit (P/N 9278-0021) used with the point nozzles.
2. Attach track duct nozzles to the outlet duct, observing airflow direction. Refer to instructions included with the isolation kit (P/N 9278-0027).
3. Assemble the individual track duct sections into two complete track duct sections. The mid and heel sections contain splices wrapped around the outside of the duct. Unhook the clips to remove the three cover pieces. The bottom can now be removed from the duct.

To assemble the splice:

- a. Center the bottom splice piece on the seam between the two track ducts.
 - b. Connect the center cover piece over the seam. (NOTE: The center cover piece has slots to contain the bolts on the track duct).
 - c. Finally connect the two end cover pieces.
4. Lay the track ducts on the rail ties alongside where they will be installed.
 5. Refer to the drawing 92774. Place the track duct support brackets in position on the ties so that one is near the heel end and one near each joint. Use the lag bolts to fasten the brackets in place. Lay the track duct on the bracket bases. Place the hold-down straps over the track ducts. Attach the hold-down strap to the track duct support brackets by inserting the spring clip into the strap.
 6. Push in the square knockouts in the track ducts where airflow is desired. The knockout should be pushed in and bent completely so that no portion of the knockout obstructs the airflow in the duct. Knockout tabs that are not bent back completely will obstruct the airflow as it moves through the track duct resulting in reduced air pressure and airflow further along the track duct.
 7. Inspect the track duct nozzles for proper operation. The damper plate should rotate without binding. Ensure that the damper plate is in the proper position, then tighten the locking nut. Ensure that the damper plate is locked firmly in place.

D. GAS CONNECTION



When tightening gas line fittings or components to the HAB unit be sure that you do not rotate the pipe that enters the blower unit. This could cause the gas control valve inside the blower unit to rotate also. Please reference the label attached just above the pipe that enters the blower unit.

1. The following items are available as optional items
 - * High pressure regulator (P/N 45103)
 - * 36" Gas tank "pigtail" (P/N 60127)
 - * 12" Gas tank "pigtail" (P/N 45038)
 - * Remote gas valve (P/N 45036)

NOTE: A propane package is available (P/N 9458-0100) that includes a 36" tank pigtail, high pressure regulator, gas line strainer, gauge, remote solenoid valve in a pole mount enclosure, and a 4X4X8' post.

FOR NATURAL GAS INSTALLATION PROCEED TO STEP 5

2. *Install the copper "pigtail" to the propane tank. Each end of the pigtail is a reverse thread.
3. *Install the high pressure (red) regulator to the pigtail. Remember reverse thread on the pigtail connection.
4. Install the "Y" strainer downstream (but near) the high pressure regulator, or natural gas source.
5. *Install the remote gas valve downstream (but near) the "Y" strainer. Electrical connections from the remote gas valve are made to terminal posts TS1-10 (115vac) and NEUTRAL on the HAB unit. The valve must be mounted with the inlet and outlet horizontal, and the coil upwards.
6. Install adequate size gas pipe from the remote tank location to the main HAB unit. Check with local gas supplier for sizing recommendations.
7. The remaining gas line components are attached to the HAB unit, as shown on drawing R9500-0027. Remember to position the regulator vent fitting facing sideways so that moisture will not enter the regulator.
8. If you are having problems adjusting the gas pressure low enough, the spring in the low pressure regulator must be changed. To change the spring, complete the following steps:
 - a. Try adjusting the low pressure regulator for proper fuel pressure. If it can't be adjusted, follow instructions listed below for changing the regulator spring.
 - b. Turn power off and close manual gas valve.

- c. Remove the plug on top of the regulator.
- d. Turn the white plug inside the regulator counter-clockwise until it can be removed.
- e. Replace the violet spring with the red spring provided in the gas accessory kit.
- f. Replace the top plug.
- g. Go to gas pressure menu to adjust.
- h. Turn the manual gas valve to “ON” position and turn power on.
- i. Place the AUTO/OFF/FORCE switch (SW1) in the “FORCE” position.
- j. Place the burner control select in the hi-only position.
- k. After the 30-second pre-purge period, the unit will ignite. Check the gas pressure display. Adjust the white plug in regulator until the display reads 11” water column for propane or 7” water column for natural gas. NOTE: Clockwise to increase pressure, counter-clockwise to decrease pressure.
- l. Let the GHAB run for a 10 minute period.
- m. After the 10 minute period, take temperature readings at both point nozzles.
- n. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
- o. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1” w.c. at a time) until you reach the desired temperature.
- p. Replace the top plug.

* OPTIONAL ITEMS AVAILABLE FROM RAILWAY EQUIPMENT CO.

(INTENTIONALLY LEFT BLANK)

E. CHANGING THE GAS ORIFICE

1. This unit uses an orifice plate instead of individual orifices. The orifice plate contains the orifices for both propane and natural gas for both stages of operation.

CAUTION

2. Make sure the main circuit breaker is in the OFF position and the manual gas valve is closed before working on the HAB unit.
3. Remove the bottom intake cover from the HAB unit (Skip this step for bungalow units).
4. On the right hand side of the gas assembly you will see the orifice plate. The orifice plate has a tab facing out that says NG for natural gas or LP for propane. This will tell you how the unit is currently set up.
5. To change from one fuel to the other:
 - a. There are four bolts on each gas coupling plate. You need to fully remove the top two bolts on each coupling plate and you need to back out the bottom two bolts on each coupling plate 1/2 to 3/4 of an inch.
 - b. On the inlet manifold (left hand side of the gas assembly) you need to remove the two bolts securing the manifold to the outside of the GHAB.
 - c. You can now carefully slide the gas assembly to the left to free the orifice plate.
 - d. The orifice plate can be pulled away from the outlet manifold and up and out. NOTE: Take care removing the orifice plate so you don't damage the O-rings.
 - e. The orifice plate can now be flipped over for the other fuel and re-inserted in between the gas coupling and outlet manifold. NOTE: Take care replacing the orifice plate so you don't damage the O-rings.
 - f. Slide the gas assembly back to the right and insert the top bolts on the coupling plates.
 - g. Verify the tab facing out on the orifice plate is now the correct fuel.
 - h. Evenly tighten the eight bolts on the coupling plates.
 - i. Replace the bolts on the inlet manifold bracket (outside of GHAB).
 - j. Re-install the lower intake cover.
6. Turn on power and manual gas valve.
7. Test unit and check regulator adjustment and output temp.

F. ELECTRICAL CONNECTION

1. Power conductors should be brought into the large LB box on the side of the bungalow.



THE 230VAC SUPPLY LINES SHOULD BE SIZED TO ALLOW FOR THE AC MOTOR START-UP CURRENT WHICH IS 128 AMPS. UNDERSIZED CONDUCTORS AND OR LONG WIRE RUNS WILL DAMAGE THE MOTOR.

2. **INCOMING POWER:** The incoming power should be connected directly to the lugs in the main breaker box. The neutral should be connected to the neutral bus. The neutral should be grounded at the source.
3. **GROUND:** The breaker box ground should be tied directly to earth ground.

SPECIAL NOTE: THE CONTROL CHASSIS AND THE REST OF THE MAIN HAB UNIT MUST BE CONNECTED TO GROUND/NEUTRAL. THE RUBBER PAD BETWEEN THE RAIL AND TIE PLATE ALONG WITH THE E-CLIP INSULATORS WILL INSULATE THE MAIN UNIT FROM THE TRACKS.

4. **CONTROL INPUT:** Remote operator control can be provided by a circuit closure applied between terminal posts TS1-1 and TS1-2.
5. **INDICATION:** Reply indication can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-3 and TS1-4 will provide a dry contact closure for indication when the unit is operating under remote control.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC indication is now present on post TS1-3 with common at terminal post TS1-6.
6. **FAIL:** Reply fail can be done two ways:
 - a. Dry contact closure: Terminal posts TS1-5 and TS1-4 will provide a dry contact closure for fail when the unit is in a fault mode.
 - b. +24 VDC: Place a jumper between terminal posts TS1-2 and TS1-4. +24 VDC fail is now present on post TS1-5 with common at terminal post TS1-6.

7. DUCT WORK OVERTEMP SENSOR (P/N 9338-0355):

- a. On the tie duct remove the two bolts holding down the overtemp sensor cover nearest the HAB unit. Install the sensor onto the duct work using the two bolts that were removed.
- b. Run conduit along duct work back to HAB enclosure; connect connector to enclosure knock out; tighten. (NOTE: Cut conduit to length if needed.)
- c. Run wires from sensor into enclosure and plug connector into OVERTEMP (RED) J10 located on the control module.
- d. Use five clamps (P/N 60030) to secure conduit to the side of duct work using existing screws.

8. RAIL TEMP SENSOR (P/N 9228-0615)115# rail (P/N 9228-0616)136# rail

- a. Attach the sensor to the outside web of the stock rail approximately four feet ahead of the point nozzle. Use spring clips to attach to rail.
- b. Run wires from sensor into enclosure and plug connector into RAIL TEMP (YELLOW) J11 located on the control module.

IV. CONTROL MODULE

A. DESCRIPTION

The hot air blower control module contains all of the elements and functions necessary for advanced snow melter operation. The unique dual-chip microcomputer has been programmed with logic and timing sequences to provide complete heater control as well as operational control and system interface. Some of the many features included in the control module are:

- Auto-Off-Local selector switch
- Adjustable air temperature setting
- Built-in snow detector (Requires Optional Snow Detector Head)
- Adjustable start-up delay sequence
- Adjustable run timer for timed or continuous operation
- Adjustable snow detect timer for use with optional snow detector
- Operator control and indication
- Remote fault reset
- Audible tone before blower start-up
- Input/output status indication lights:
 - Inputs:
 - Air temperature
 - Remote Control
 - Moisture Detector One or two snow detector(s) (Optional)
 - Airflow switch
 - Flame Sensor
 - Rail Temp Sensor
 - High Temp Sensor
 - Outputs:
 - Blower motor
 - Ignition spark
 - External Gas Valve
 - Hi Gas valve
 - Low Gas valve
 - Indication
 - Fail
- Flame safety control:
 - 10 second tone before blower turn on
 - Air flow proving
 - 30 second pre-purge before ignition
 - Direct spark ignition
 - 10 second maximum ignition period before lock-out
 - Rectification type flame rod sensor
 - Automatic retry on flame loss
 - 4 minute post-purge period after gas valve turn-off
 - Automatic reset

Fault if flame does not go out after gas valve is commanded off

B. SET-UP AND ADJUSTMENTS: To change settings and adjust times do the following:

Mode Up Push Button

Pushing the Mode Up push button (PB2) will cycle up through the menus. Each time you press the mode up push button you will advance one menu selection.

Mode Down Push Button

Pushing the Mode Down push button (PB3) will cycle down through the menus. Each time you press the mode down push button you will move down one menu selection.

Increase Values

The Increase Values push button (PB4) allows you to increase the values.
NOTE: Values will be saved.

Decrease Values

The Decrease Values push button (PB5) allows you to decrease the values.
NOTE: Values will be saved.

The following is the layout of the controller menu:

Controller Menu

The controller has 6 menus categories, they are:

1. Status
2. Fault History
3. Set Points
4. Factory Defaults

Menu Selection

To select the desired menu, press the Mode Up or Down button until *******MENU SELECT******* is displayed, on line 1, and then use the Increase or Decrease Value button to select the appropriate menu. Once the appropriate menu is selected, use the Mode Up or Down buttons to view the contents of the menu.

NOTE: Use the Increase or Decrease Values button to change setpoint values.

STATUS MENU

- 1. OUTSIDE TEMP AND PRESET VALUE**
Displays the current ambient temperature and temperature preset value. If ambient temperatures is below the preset value, the unit will start if requested.
- 2. MOTOR CURRENT AND MOTOR VOLTAGE**
Motor current displays the actual motor current in amps while motor is running. Motor voltage displays the actual motor voltage in volts while motor is running.
- 3. GAS PRESSURE AND DUCT PRESSURE**
Gas pressure is the actual differential pressure at the burner. The unit of measure is inches of water ("H₂O). To view gas pressure, the burner should be burning. The correct setting should be 11"H₂O for propane, be 7"H₂O for natural gas. While adjusting, the burner should be in high only. Adjust regulator to change gas pressure value. Duct temperature is the actual duct temperature in degrees F or C.
- 4. FLAME CURRENT**
Flame current displays the actual flame current in micro amps while a flame is present.
- 5. RAIL TEMP AND DUCT TEMP**
Rail temperature is the actual rail temperature in degrees F or C. Duct temperature is the actual duct temperature in degrees F or C.
- 6. AC FREQUENCY**
Displays the frequency of the line voltage.
- 7. TOTAL GAS AND RESET GAS**
Total gas displays the calculated amount of gas that has been used. The unit of measure is gallons if propane is selected. The unit of measure is cubic feet if natural gas is selected. Reset gas is the same as total gas except it can be reset. To reset, press the decrease value button.
- 8. HOUR METER AND RESET HOUR**
Hour meter displays the total hours that GHAB has been running. Reset hour is the same as hour meter except it can be reset. To reset, press the decrease value button.
- 9. TANK LEVEL, BAT AND TEMP**
Tank level displays the actual level of propane tank in percent full (optional tank level monitor must be installed). Bat displays the battery level of the tank monitor. Temp displays the temperature in the battery monitor.

FAULT HISTORY MENU

NOTE: Some faults may not show in Fault History until there is an actual fault.
Press the decrease or increase value button to reset fault count.

- 1. FLAME LOSS AND FLAME ON**
Flame loss counter is total count of flame loss faults. Flame on counter is total count of flame on faults.
- 2. SAIL LOSS AND SAIL ON**
Sail loss counter is total count of sail loss faults. Sail on counter is total count of sail on faults.
- 3. MOTOR V FAULT AND OVERLOAD**
Motor volts low or high counter. Overloads counter is total motor overloads faults.
- 4. GAS VALVE LEAK AND PRESSURE FAULT**
Gas valve counter is total count of leaking gas valve faults. Gas pressure low or high counter.
- 5. DUCT PRESS FAULT AND VAP. PRESS LOW**
Duct pressure fault counter is total count of duct pressure faults. Vaporization low fault counter is total count of vaporization low faults.
- 6. MOTOR CURRENT AND COMM RESET**
Motor current fault is total count of motor current faults. Comm reset fault is total count of communication reset faults.
- 7. DAY COUNTER AND POWER UP**
Day counter is the number of days the unit has been powered up. Power up counter is the total number of times the control module has been turned on.
- 8. OVER TEMPS WARNING COUNTER**
Counts the total number of Over Temp warnings.
- 9. AUTO OVERTEMP RESET COUNTER**
Counts the total number of times the Over Temp was reset.

SET POINTS MENU

1. USER LEVEL

The options are BASIC and ADVANCED.

Basic – access to basic menus.

Advanced – access to advanced menus (requires password).

2. PASSWORD

A password is needed to access the advanced menus. To enter in the password, use the increase or decrease value buttons. Password 5 allows advanced menu items to be changed.

3. SELECT TEMPERATURE SETPOINT

The ambient temperature below which the unit will energize is set on this screen. When the outside temperature is below this setpoint, the unit will be allowed to operate if requested. The factory default is 38° F (3° C). The range is from 0° F to 100° F (-18° C to 38° C).

4. SELECT RUN TIMER VALUE

The run timer can be set from 0 to 1000 minutes. If zero is selected, the outputs will operate continuously, until control on is disabled. If another value is selected, the unit will run until the run timer counts down to zero, after which the unit will shut down and drop indication. The unit can be restarted by removing the contact closure between TB2-1 and 2, then reinstalling it. If Run Timer Pulse Mode is activated, the minimum run time value is 10 minutes. The factory default setpoint is 60 minutes.

5. RUN TIMER PULSE MODE

The choices are on or off, factory default is off. When on is selected, a pulse will start run time sequence and continue until run timer has timed out. When off is selected, run timer will time out as long as remote is on. When remote on is removed blower will stop.

6. SELECT SNOW TIMER VALUE

The snow timer can be set from 10 to 1000 minutes. The snow time starts counting down when the moisture detector no longer sees snow. The factory default setpoint is 60 minutes.

7. SELECT SNOW SENSOR SPEED

Snow sense speed sets the delay time after the moisture detector sees moisture and starts the snow cycle. The delay time can be set from 1 to 60 seconds. The moisture sensor must see moisture for entire time to start cycle.

8. SELECT SNOW INDICATION

The choices are OFF or ON. With snow indication off, indication will remain off during snow time if no faults are present. With snow indication on, indication will remain on during snow time if no faults are present.

9. SELECT START DELAY VALUE

The start delay timer can be set from 0 to 250 seconds in 10 second increments. It is used to delay the start of GHAB so when several blowers are at the same location they do not start at same time.

10. SELECT BURNER OPERATION

The choices are LOW, HIGH, AUTO, AUTO OFF.

Hi Only – 100% BTU output with or without Rail Sensor.

Low Only – 50% BTU output of Hi with or without the rail sensor.

Auto – Switches between high and low dependant on the rail & duct temperature sensor and setpoint. Note: If no rail sensor is connected, it will run at low (50% output). Units with only single stage installed, should select high only.

Auto Off – When rail temperature reaches the rail temp setpoint, the GHAB will shut down. When the rail temperature lowers to the ambient temperature setpoint, the GHAB will start again.

11. OPERATION MODE

The choices are NATURAL, PROPANE, COLD AIR, COLD AIR/PROPANE, COLD AIR/NATURAL.

NATURAL – The GHAB's burner is fueled by natural gas.

PROPANE – The GHAB's burner is fueled by propane.

COLD AIR – The GHAB will turn its blower on with air temperature. It will not use a burner.

COLD AIR/PROPANE –The GHAB will turn its blower on with air temperature. It will then turn its propane burner on with moisture or control.

COLD AIR/NATURAL –The GHAB will turn its blower on with air temperature. It will then turn its natural gas burner on with moisture or control.

12. SELECT MOTOR SIZE

The choices are:

2 HP 230V 1PH, 3 HP 230V 1PH, 5 HP 230V 1PH,

2 HP 460V 3PH, 3 HP 460V 3PH, 5 HP 460V 3PH,

2 HP 575V 3PH, 3 HP 575V 3PH, 5 HP 575V 3PH,

2 HP 3PH Drive, 3 HP 3PH Drive, 5 HP 3PH Drive

2 HP 230V 3PH, 3 HP 230V 3PH, 5 HP 230V 3PH.

13. RAIL TEMP SETPOINT

This can be set from 0° F to 280° F (-18° C to 138° C).

- 14. DUCT TEMP SETPOINT**
This can be set from 150° F to 250° F (66° C to 121° C).
- 15. DUCT PRESSURE HIGH SETPOINT**
This can be set from 3" H2O to 30" H2O.
- 16. DUCT PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 5" H2O.
- 17. GAS PRESSURE HIGH SETPOINT**
This can be set from 7" H2O to 30" H2O.
- 18. GAS PRESSURE LOW SETPOINT**
This can be set from 0" H2O to 10" H2O.
- 19. MOTOR CURRENT HIGH SETPOINT**
This can be set from 5 to 100 amps.
- 20. MOTOR CURRENT LOW SETPOINT**
This can be set from 0 to 10 amps.
- 21. MOTOR VOLTAGE HIGH SETPOINT**
This can be set from 250 to 650 volts.
- 22. MOTOR VOLTAGE LOW SETPOINT**
This can be set from 150 to 550 volts.
- 23. AC FREQUENCY HIGH SETPOINT**
This can be set from 0 to 100 Hz.
- 24. AC FREQUENCY LOW SET POINT**
This can be set from 0 to 100 Hz.
- 25. LOCAL WITH/WITHOUT AIR TEMPERATURE**
Sets the local feature to, or not to, be dependant on the air temperature.
- 26. OVERTEMP BYPASS**
With overtemp bypass enable, the unit will not fault if the overtemp sensor is missing. This feature is only for use on units that have a two wire overtemp sensor. Current production units are equipped with a four wire overtemp sensor. **NOTE: BYPASSING THE OVERTEMP SENSOR MAY CAUSE HARMFUL OPERATING CONDITIONS.**
The following steps are required to bypass the overtemp sensor:

a) Display: MENU SELECT

SETPOINTS

- b) Select: ADVANCED
- c) Enter password: 10
- d) Display screen: OVERTEMP BYPASS
DISABLED
- e) Change to: ENABLED

- 27. SELECT F OR C**
Will change the temperature scale to either Fahrenheit or Celsius.
- 28. AUTO OVERTEMP RESET**
Auto overtemp reset will reset the overtemp once it has been triggered.
- 29. SELECT TANK SIZE**
The choices are no tank sensor, tank heater, 250 gallon increments up to 5,000 gallons. No tank sensor should ALWAYS be selected UNLESS a tank sensor reporting to the module is installed. Note: Tank Size menu is only available if propane is selected.
- 30. TANK SERIAL #**
Tank serial # is the tank level monitor's serial number. This is only used if a tank sensor reporting to the module is installed.
- 31. MACHINE SERIAL NUMBER**
Machine serial # is the serial number of the whole GHAB unit.
- 32. SERIAL NUMBER/MAC**
Shows the MAC address for the unit.
- 33. AMBIENT OFFSET**
Used to calibrate the ambient temperature sensor.
- 34. RAIL OFFSET**
Used to calibrate the rail temperature sensor.
- 35. DUCT OFFSET**
Used to calibrate the duct temperature sensor.
- 36. PROG REV AND DATE**
Shows the program revision and the date it was compiled.

37. **BOOTLOADER**

The choices are DO NOT RUN BOOTLOADER, START FACTORY DEFAULT BOOTLOADER and START NEW CODE.

DO NOT RUN BOOTLOADER – Will not run the bootloader.

START FACTORY DEFAULT BOOTLOADER – Will run the factory bootloader.

START NEW CODE – Will download and run the new code.

FACTORY DEFAULTS MENU

Factory default is used to place all parameters back to factory default settings.

To restore to factory default:

In the menu selection, select FACTORY DEFAULTS and then press either the up or down mode button. Next press either the increase or decrease value button to restore to default.

AUTO/OFF/LOCAL SWITCH (SS1)

- a) **AUTO:** This position will allow operation by placing a circuit closure across terminal posts 1 and 2. It will also allow operation by an optional snow detector.
- b) **OFF:** If off, GHAB cannot be run from remote or snow detector.
- c) **LOCAL:** If LOCAL without air temp parameter is enabled, placing SS1 in the LOCAL position enables the snow melter regardless of outside air temperature. The snow melter will remain on until LOCAL is turned off. This is useful for hot weather testing.

C. LED STATUS INDICATING LIGHTS

1 AIR TEMPERATURE:

On when the ambient air temperature is below set point.

2 MOISTURE:

On when the optional snow detector sensing head(s) senses moisture.

3 CONTROL:

- On when there is a circuit closure across terminal posts 1 and 2.
- 4 **BLOWER:**
On when the controller has turned on the output to the blower motor contactor.
 - 5 **AIRFLOW:**
On when the sail switch in the air stream is sensing adequate airflow.
 - 6 **IGNITION:**
On when the controller has enabled the output to the ignition transformer.
 7. **HIGH GAS VALVE:**
On when the controller has enabled the output to the high gas valve.
 8. **LOW GAS VALVE:**
On when the Controller has enabled the output to the Low Gas Valve.
 - 9 **FLAME:**
On when the flame sensing determines that there is proper combustion.
 10. **INDICATION:**
On when there is a circuit closure across terminal posts 1 and 2 and the unit is operating, or the air temperature is above the set point. Also may be on when there is a fault condition under snow detector.
 11. **FAIL:**
This LED is on when ever a fault is present.

D. OPERATION

With switch SS1 in the “auto” position, the unit can be activated by applying a circuit closure between terminals TS1-1 and 2. If the outside temperature is above set point the unit will not start a snow melt sequence but will turn on the “indication” LED and provide a relay contact closure between TS1-3 and 4 to indicate to the remote station that the unit is operational.

If a circuit closure exists between TS1-1 and 2, and the air temperature is below set point. the unit will begin a snow melt sequence. The unit executes a 0 to 300 sec. time delay depending on the setting of the START DELAY TIMER. Then, a 10-sec. audible tone sounds as a warning that the blower motor is about to turn on.

The airflow switch is checked to see if it is closed. If it is, the blower will display SAIL SWITCH ON FAULT.

If the airflow switch is open the motor will turn on. After the blower motor is turned on, the airflow switch is monitored. It closes if airflow is normal. If it does not close within 10 sec. (or 30 sec. for an AC drive) after blower turn-on, the blower displays SAIL SWITCH OFF FAULT. When the airflow switch closes, a 30 second prepurge time will start. After the prepurge time is completed the gas valve opens, the ignition turns on and the burner is monitored for a normal flame condition. If a flame is not detected within 10 seconds, the gas valve is closed, the ignition spark is removed and the blower displays NO FLAME DETECTED FAULT.

If a normal flame condition is detected the “indication” contact closure is established between TS1-3 and 4. The unit will run for a period of time determined by the setting of the RUN TIMER. If the run timer is set at “0” the unit will continue to run until the circuit closure between TS1-1 and 2 is removed.

If the blower is equipped with the two stage gas valve option and the rail temp sensor is installed, then under normal operation when the rail reaches the preset temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the rail falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity.

If the blower is equipped with the two stage gas valve option and the duct temp sensor is installed, then under normal operation when the duct reaches the preset duct temperature setting, the low gas valve will open and the high gas valve will close. This will result in a fuel reduction of 50%. When the duct falls below the programmed temperature, the high gas valve will open and the low gas valve will close resulting in the burner returning to 100% capacity. If the duct temp sensor sees a temperature above 325° F (163° C) both gas valves will be disabled. This prevents over temps.

There is a burner control adjustment available in the control module adjustments that allow the burner to be set to high only, low only or automatic controlled by the rail temp

sensor. If the two-stage option is not installed, the burner control switch should be set to high only. Refer to (SET UP AND ADJUSTMENTS) in Section IV 8.

SNOW DETECTOR OPERATION. If the unit is operating with one or two optional snow detector assemblies and moisture is detected by either (or both), a snow melt sequence will begin, provided that the air temperature is below the set point. The unit will start as described in Section IV Part B under (Select Snow Timer).

E. FAULT CONDITIONS

1. SAIL SWITCH ON FAULT:

During startup the processor checks the status of the airflow switch. If the airflow switch is closed or shorted the blower motor will turn on and the blower will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is closed it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for.

2. SAIL SWITCH OFF FAULT:

Sail switch off fault is set when blower is running and air flow switch is open. After the fault is set the blower motor will run a 4-minute purge to try to clear the airflow switch. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the airflow switch for proper operation. If the airflow switch still shows that it is open it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the sail switch is free to move and if there are any obstructions in duct work.

3. NO FLAME DETECTED FAULT:

No flame detected fault is set when blower is running and air flow switch is closed with gas valve open. If no flame is detected within 10 seconds the fault will be set. After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-minute cycle, the blower will once again check the flame rod for proper operation. If no flame is present it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

4. FLAME DETECTED ON FAULT:

Flame detected on fault is set when blower is running and air flow switch is closed with gas valve closed. If flame is detected before gas valve is opened the fault will be set. After the fault is set the blower motor will run a 4-minute purge to try to clear the flame rod. The motor will then shut off and sit idle for 1 minute. Upon completion of this 5-

minute cycle, the blower will once again check the flame rod for proper operation. If flame is present with gas off it will run the 5-minute loop again. This will repeat until fault is cleared or blower is no longer called for. Check to see if the flame rod is shorted to ground, the flame rod is loose, the flame rod is dirty or if the insulators is fully installed so that no moisture can short out the flame rod.

5. GAS VALVE FAILURE:

During the blower shutdown operation if the unit senses flame after the post-purge, the unit will not shutdown. Instead it will go into gas valve failure mode. In this mode the blower continues to run, the reply will also indicate a problem, and the buzzer will sound. The unit will lock out all other operations and will not be able to be reset except at the unit itself.

6. CHECK FUSE # 1 24 VDC POWER:

Fuse # 1 is tripped. Check the following circuits:

- a. Overtemp switch and wiring.
- b. Check TS1-2 +24 control on wiring.

7. CHECK FUSE # 2 IGNITION TRANSFORMER:

Fuse # 2 is tripped. Check the following circuits:

- a. Ignition transformer and wiring.

8. CHECK FUSE # 3 GAS VALVE / SAIL SWITCH:

Fuse # 3 is tripped. Check the following circuits:

- a. Check Sail switch and wiring.
- b. Check hi and low gas valve and wiring.
- c. Check external gas valve and wiring.

9. CHECK FUSE # 4 BLOWER MOTOR:

Fuse # 4 is tripped. Check the following circuits:

- a. Check blower motor contactor and wiring.

10. CHECK FUSE # 6 SNOW HEAD # 1:

Fuse # 6 is tripped. Check the following circuits:

- a. Check snow detector head # 1 and wiring.
- b. Check Gas pressure sensor and wiring.
- c. Check Duct pressure sensor and wiring.

11. CHECK FUSE # 7 SNOW HEAD # 2:

Fuse # 7 is tripped. Check the following circuits:

- a. Check snow detector head # 2 and wiring.
- b. Check Sail switch and wiring.

12. CHECK FUSE # 9 ANALOG 5VDC:

Fuse # 9 is tripped. Check the following circuits:

- a. Check 5V supply for pressure sensor.

13. CHECK FUSE # 10 PRESSURE/BAT CHARGER:

Fuse # 10 is tripped. Check the following circuits:

- a. Check pressure sensor.
- b. Check 24V supply for battery backup.

14. OVERTEMP FIX PROBLEM PRESS DECREASE:

Overtemp sensor has tripped. If the temperature inside the Tie duct exceeds 375 degrees F, it will cause the ductwork overtemp circuit to trip, shutting down the HAB system. Only pushing the decrease value push button will reset the unit, giving opportunity to check the cause of the overtemp condition.

15. OVERTEMP FIX PROBLEMPRESS DECREASE ___ MIN:

The overtemp sensor has tripped. The HAB system will shut down for some time period then it will reset the unit. NOTE: AUTO OVERTEMP RESET must be enable in order to see this fault.

16. OVERTEMP WARNING RESTART IN ___ SEC:

If the temperature is close to overtemp value, the unit will restart in a certain time period.

17. OVERTEMP MISSING INSTALL OVERTEMP:

Caused my missing overtemp sensor.

18. MOTOR VOLTAGE LOW:

Motor voltage low is caused by inadequate electrical service supply. During motor start up if motor voltage drops below 190 VAC, the motor will eventually be damaged. If this under-voltage occurs, an error will be set. Press decrease value button to clear the fault.

19. MOTOR VOLTAGE HIGH:

Motor voltage high is caused by high motor voltage. Can be caused by high voltage from the electric company.

20. MOTOR OVERLOAD, RESET OVERLOAD DEVICE:

High motor current will trip the motor overload on the control panel. This device is connected to the bottom of the motor contactor on the control panel. Reset by pressing the red button on the device. Check unit for high motor current, bad bearings, or obstructions in the blower wheel.

21. MOTOR CURRENT LOW:

Caused by low motor current.

22. MOTOR CURRENT HIGH:

Motor current high is caused when sensed current is 3 amps over motor name plate for 20 seconds. Check motor for high current, bad bearings, obstruction in blower wheel.

23. GAS PRESSURE LOW:

Gas pressure low is caused by supply gas pressure during operation dropping to a low level. Check gas delivery system.

24. GAS PRESSURE HIGH:

Gas pressure high is caused by high gas pressure going to the burner. Check gas delivery system. Adjust the regulator on the gas delivery system to lower the gas pressure.

25. DUCT PRESSURE LOW:

Duct pressure low is caused by not enough duct back pressure. Possible causes are missing flame cover or missing duct work.

26. DUCT PRESSURE HIGH:

Duct pressure high is caused by too much duct back pressure. Possible causes are duct work obstructions

27. PROPANE TANK LOW WARNING FILL TANK:

Propane tank low is caused by low propane tank level. Note propane tank level monitor must be installed and setup, for this warning to appear.

28. TANK VAPORIZATION PRESSURE LOW WARNING:

Tank vaporization pressure low warning is caused by low tank temperatures.

29. UTILITY POWER LOST:

Utility power lost is caused by no incoming AC voltage. Must have a battery backup in order to receive this fault.

V. SEASONAL MAINTENANCE

A. SPRING:

1. Turn off gas source.
2. Turn off electric power at source.
3. Disconnect and remove the control module. Store in a clean, dry place.
4. Turn off manual gas valve.

B. FALL

1. Check all ductwork for clear airflow. Ensure that the point and track duct nozzle screens are not damaged and are completely covering the openings. Make sure that no debris or rodents have obstructed any area of the ductwork.
2. Inspect the track duct nozzles for proper operation. The damper plate should rotate without binding. Ensure that the damper plate is in the proper position, then tighten the set screws and locking nut. Ensure that the damper plate is locked firmly in place.
3. Remove the flame duct cover. Check the burner. Make sure the spark igniter plug and flame rod are in good, clean condition. Check the wiring to make sure rodent or vibration have not damaged the insulation.
4. Check the airflow sail switch to make sure it is operating properly.
5. Replace the flame duct cover.
6. Install the control module and connect the wires.
7. Turn on the gas source.
8. Turn on the manual gas valve.
9. Turn on the electric power at source.
10. Perform the gas pressure regulator adjustment procedure as described on the following page of this manual.
11. Perform a flame failure test:
 - a) Place switch SS1 in the FORCE position.
 - b) Turn off the manual gas valve.
 - c) Turn on the main circuit breaker.
 - d) After 40 seconds (plus any start delay period) the fault message NO FLAME DETECTED FAULT should be displayed. If the fault does not appear, the control module is faulty and should be replaced.
12. Check the flame current. Refer to Section IV, Control Module (B), SET-UP AND ADJUSTMENT 18A.
13. Check the air temperature for proper setting.

VI. LOW PRESSURE REGULATOR ADJUSTMENT/OUTPUT TEMP TEST

- A. Place switch SS1 in the FORCE position.
- B. Turn the manual gas valve to “ON” position and turn power on.
- C. Place the burner control in the hi-only position. Refer to Section IV SET-UP AND ADJUSTMENTS b. 7.
- D. After the 30-second pre-purge period, the unit will ignite. Check the gas pressure value. Adjust the white plug in regulator until the gauge reads 11” water column for propane or 7” water column for natural gas. NOTE: Clockwise to increase pressure, counter-clockwise to decrease pressure.
- E. Let the GHAB run for a 10 minute period.
- F. After the 10 minute period, take temperature readings at both point nozzles.
- G. Determine the ambient temperature at the location and subtract the ambient temperature from the point nozzle reading. This temperature should not exceed 250°F for optimum efficiency.
- H. If the temperature is above 250°F, adjust the gas pressure at the low pressure regulator down (1” w.c. at a time) until you reach the desired temperature.
- I. Replace the top plug.
- J. Return all switches to their normal operating position.

VII. TROUBLESHOOTING

A. UNIT DOES NOT START

1. Check circuit breaker.
2. Check control fuse. The control fuse is an auto resettable type fuse. To check, turn the main circuit breaker off for one minute, then turn back on
3. Check for 18VAC between the following points:
TS1-6 and TS1-7
TS1-6 and TS1-8.
Change T1 control transformer if either measurement is incorrect.
4. Check for air temperature below set point.
5. Is the control module programmed for a start-up delay?
6. Monitor the fault display on the control module.
7. Turn the circuit breaker off, then reset the motor overload relay. The motor overload relay is adjustable. It should be set for the motor name plate current.
8. Push the RESET Button (PB1).

B. UNIT DOES NOT MAINTAIN OPERATION

1. Monitor the flame current as described in section IV B. 18.
2. Check the fuel supply. Refer to Section VID.
3. Check 230VAC and 115VAC from either leg to the center tap neutral (with the unit running). It must be within +10% to -10%.
4. Check the burner. The burner must be clean and free of carbon.
5. The flame rod should be clean and secure. Refer to section D for flame current test.
6. Check the wire from the flame rod to the control module for continuity. Pull the white plug connector on the lower right side of the control module. Use an Ohmmeter to measure continuity from the terminal of the flame rod to the white connector. The reading should be less than 1 ohm.

C. LOW HEAT LEVEL

1. Perform a regulator adjustment/output temp test refer to Section 5.
2. Check the fuel supply.
3. Make sure the burner is clean.
4. Make sure the orifice plate is installed for the fuel being used.
5. Check the low pressure regulator.
6. Check to see if the burner control is on low only or if it is in auto and the Rail Temp Sensor setting is forcing it to low output.

D. LOW AIRFLOW

1. Check for obstructions in all ductwork and the air intake.
2. If there is frost buildup on the air intake screen, move the screen to the “open” position.
3. Check the voltage and current levels on the blower motor.
4. Make sure knockouts on the track duct are pushed all the way back in the track duct.
5. Check the spacing between the inlet cone and the blower wheel. The gap should be less than 1/16 of an inch.

E. GAS VALVE



CHECK THE AREA TO BE SURE THERE ARE NO LINGERING GAS FUMES BEFORE DOING ANYTHING WHICH MAY CAUSE A SPARK!

1. Turn off gas to the blower.
2. Turn off power to the blower.
3. Check the gas valve for obstructions.
4. Check the gas valve for proper operation.

F. HIGH HEAT LEVEL

1. Check for proper orifice installation.
2. Perform the low pressure regulator and Temp Test found in Section VI.

VIII. SNOW DETECTOR

A. SNOW DETECTOR INSTALLATION

1. The snow detector sensing circuitry is contained within the control module. All that is required for snow detector operation is to connect the sensing head(s).
2. Either one or two sensing heads may be used.
3. Each sensing head has three lead wires; black, white, and green. Connect as follows:
 - a) green: one or both connected to TS1-6.
 - b) black #1: connected to TS1-7.
 - c) black #2: connected to TS1-8.
 - d) white: one or both connected to TS1-9.

NOTE: Refer to the diagrams when connecting wires for the sensing heads. It is important to properly connect the sensing head wires. Improper connection of the sensing head wires may result in damage to the control module and/or the sensing head.

4. To operate more than one HAB unit from a HAB unit that is controlled by a snow detector(s), connect terminal posts #6 together and terminal posts #9 together. (Do not connect terminal post #6 to terminal post #9.) When connecting snow detectors to more than one HAB unit, first connect one HAB. Then connect the snow detector to one more HAB. If the snow detector does not operate properly, exchange L1 and L2 on the newest HAB circuit breaker. NOTE: BE SURE L1 AND L2 ARE DE-ENERGIZED BEFORE EXCHANGING THEM. Continue to add HABs to the snow detector in the same manner until all the desired HABs are connected. DO NOT EXCEED 200' CABLE LENGTH (18 AWG WIRE).
5. The sensing heads should be mounted in a vertical position.
6. Experience has shown that positioning a snow detector sensing head in the switch area between the ties and between the switch point and the track duct is effective. A second sensing head is then placed away from the switch area, such as on a bungalow or pole.

B. SNOW DETECTOR OPERATION

NOTE: A snow detector sensing head only detects moisture. With temperature sensing capability, the HAB unit assumes moisture is due to snow when the air temperature is below set point.

All operating functions are similar to remote operation with the following exceptions:

1. **INDICATION:** During normal operation under snow detector control, the indication contact across terminal posts 3 and 4 will not be closed.
2. **TIMED OPERATION:** The snow detector has many different time scenarios . Refer to Section IV Part B to determine which scenario best meets the needs in your location.
3. **RUN TIMER:** During remote operation, if the snow detector senses moisture, the unit will operate according to the settings. The unit will then operate for the duration of the run timer setting.
4. **FAULT CONDITION:** A fault condition under snow detector control will cause the indication contact across terminal posts TS-3 and TS-4 to close. To reset the unit after a fault condition, momentarily apply a circuit closure between terminal posts TS-1 and TS-2 with Ss1 in the Auto position. The unit may now be operated either under remote control or snow detector control.

C. SNOW DETECTOR MAINTENANCE

The snow detector sensing head contains a small, self-regulating heater that will melt snow or ice into water. The sensing head relies on moisture to create a low resistance circuit path. The heater will also cause the moisture to evaporate within a short period. If the surface becomes non-conductive due to contamination by grease or oil, the sensing head will not operate. To ensure effective and dependable snow detector operation, it is important to inspect the sensing heads frequently and clean them thoroughly if necessary.. Use a solution of water and mild detergent or isopropyl alcohol to clean the sensing grid. Use a clean, dry cloth to wipe the grid. Make sure there is no residue left on the surface.

D. SNOW DETECTOR TROUBLESHOOTING

NOTE: A newly-installed snow detector sensing head should operate 15-20 minutes to allow the internal heater to reach normal operating temperature.

1. NO HEAT ON THE SENSING HEAD

- a. Check for voltage between terminal post 6 and 7, and between terminal post 6 and 8. It should be 18VAC \square 2VAC. If not:
 - (1) Check the display on the control module.
 - (2) The control transformer may be defective.
 - (3) There may be a bad circuit connection.
- b. Remove the black and the green lead wires from the terminal posts. Check resistance between them. If resistance is greater than 10 ohms, the sensing head is defective and should be replaced.

2. DOES NOT DETECT MOISTURE

- a. Clean the snow detector as described above.
- b. If unit still does not detect moisture, check the wiring connections between detector head and terminal posts.
- c. If unit still does not detect moisture, replace the control module with a known good control module. If still not operating properly, replace the sensing head.

NOTE: If a snow detector head becomes saturated with moisture, it can sometimes be restored to normal operation by removing it and “baking” it in a conventional oven for several hours. Do not exceed 150 \square F.

3. CONSTANT INDICATION OF MOISTURE DETECTION

- a. Clean and adjust the snow detector heads as described in section C, Snow Detector Maintenance.
- b. Remove white lead(s) from terminal post 9. If moisture indication is still on, the control module is defective and should be replaced.

IX. SPECIFICATIONS

VOLTAGE : 230VAC, 1PH 60 HZ, 50 Amp,
With 115VAC/115VAC center tap
neutral

MOTOR : 3 HP, 3450RPM, TEFC
85 Amp starting current
14.5 Amp running current

VOLTAGE : 230 VAC, 1PH 60HZ 50 AMP
(3PH AC DRIVE)

MOTOR : 3 HP, 3450RPM, TEFC
18 Amp starting current
18 Amp running current

VOLTAGE : 460 VAC, 3PH 60HZ 15 AMP

MOTOR : 3 HP, 3450RPM, TEFC
37.5 Amp starting current
3.7 Amp running current

VOLTAGE : 575 VAC, 3PH 60HZ 15 AMP

MOTOR : 3 HP, 3450RPM, TEFC
30 Amp starting current
3 Amp running current

AIRFLOW : 2500 CFM

COMBUSTION RATE : 600,000 BTU/HR
300,000 BTU/HR

FUEL : Propane or Natural Gas

FLOW RATE: Natural Gas 600 CFH/300 CFH
Propane: 240 CFH/120 CFH
6.6 GPH/3.3 GPH

INDICATION CONTACTS: 30VDC 1A or 125VAC 300mA

X. DRAWINGS

BUNGALOW POSITIONING	963N32902
GHAB SWITCH LAYOUT	9559-0020
BUNGALOW MAIN UNIT	9638-0501
GHAB MAIN UNIT	9558-6115
TIE DUCT ASSEMBLY 136LB E-CLIP	9528-4805
TIE DUCT ASSEMBLY 115LB E-CLIP	9528-4605
POINT / TRACK ASSEMBLY RH	9508-4000
POINT / TRACK ASSEMBLY LH	9508-4001
TRACK DUCT ASSEMBLY LH	9508-4002
TRACK DUCT ASSEMBLY RH	9508-4003
NOZZLE TRACK DUCT ASSEMBLY	927490
ISOLATION KIT, TIE DUCT POINT NOZZLE	9278-0021
ISOLATION KIT, TIE DUCT TRACK NOZZLE	9278-0027
HEAVY DUTY OFFSET DUCT WITH MIXER	9528-3402
2 INSULATED FLEX DUCT	9528-4220
TRACK DUCT, 5' POINT	9278-0226
TRACK DUCT, 5' MID	9278-0227
TRACK DUCT, 10', MID	9278-1201
TRACK DUCT, 10', HEEL	9278-1202
SWITCH ROD DUCT 7'	9278-0270
TRACK DUCT SUPPORT BRACKET ASSEMBLY	92774
GHAB ELECT. PANEL LAYOUT	9558-0150
GHAB ELECT. PANEL LAYOUT	9558-0156
GHAB ELECT. SCHEMATIC	9524-0125
GHAB ELECT. SCHEMATIC	9554-0133
GHAB ELECT. SCHEMATIC	9524-0223
GAS PIPING, 2 STAGE	9658-0138
BURNER ASSEMBLY	9528-0135

LIMITED WARRANTY

XI.

Railway Equipment Co., Inc. ("Railway") warrants all of its products to be free from defects in material and workmanship when used under specified operating conditions and within specified limits. Railway's warranty shall extend for a period of two (2) years from the date of shipment to the original purchaser.

This warranty is expressly in lieu of and excludes all other expressed or implied warranties, including but not limited to warranties of merchantability and fitness for a particular purpose.

Railway, its agents, or representatives shall in no circumstance be liable for any direct, indirect, special, penal, or consequential loss or damage of any nature resulting from the malfunction of the product.

Remedies under this warranty are expressly limited to repair or replacement of the product at the sole discretion of Railway.

Before returning any defective product to Railway, contact the factory at the address or telephone number at the bottom of this article for a Return Merchandise Authorization number and instructions as to how and where the return is to be shipped. Materials received without this authorization will be returned at the customer's expense.

Products returned to Railway under warranty must be shipped freight prepaid, and return freight charges for repaired or replaced products, in or out of warranty, will be at customer's expense.

Railway reserves the right to reject any warranty claim on a product that has been altered by the user or damaged in shipping due to inadequate packaging or mishandling by freight carrier.

By returning a product to Railway the owner grants permission to Railway to open and disassemble the product as required for evaluation. Railway has the sole responsibility for determining the cause and nature of failure, and Railway's determination with regard thereto shall be final. Railway reserves the right to repair or replace any unit at its sole discretion.

A returned product that is found, upon inspection by Railway, to be operational within specification is subject to an inspection and testing fee, regardless of its warranty period.

Railway's liability on any claim of any kind (including negligence) for any loss or damage arising out of or resulting from this agreement, or from the performance of breach thereof, of from the products or services furnished hereunder, shall in no case exceed the price of the specific product or service which gives rise to the claim. All such liability shall terminate upon the expiration of the warranty period of two (2) years, as hereinabove stated.

The furnishing of advice or other assistance without separate compensation therefor will not subject Railway to any liability, either in contract, warranty, tort (including negligence) or otherwise.

Any alteration or modification of the product, or addition on non-Railway components to the product, unless expressly permitted by Railway in its documentation, will void warranty coverage.

This warranty is non-transferable, and warranty coverage is limited to initial user only.

Installation and/or use of the product shall demonstrate acceptance of the terms of this warranty.

Each of the foregoing paragraphs in this article will apply to the full extent permitted by law. The invalidity, in whole or part, of any paragraph will not affect the remainder of such paragraph or any other paragraph.

RAILWAY EQUIPMENT CO.

P.O. Box 68 – Delano, Minnesota 55328 USA

Tel. (763) 972-2200 Fax (763) 972-2900


E-Mail - mail@rwy.com

(INTENTIONALLY LEFT BLANK)


SNOW DETECTOR




DETAIL B
SCALE 1 / 16



POINT SNOW DETECTOR
(OPTIONAL ITEM)




DETAIL D
SCALE 1 / 16



UNLESS OTHERWISE SPECIFIED, DIMENSIONS ARE IN INCHES DRAWING DIMENSIONS SHALL PRECEDE PARTS LIST DIMENSIONS		© RAILWAY EQUIPMENT CO. 2011	
DRAWN BY: G. JONAS		RAILWAY EQUIPMENT CO. MINNEAPOLIS, MINNESOTA 55401	
DATE: 07/12/11		TITLE: BUNGALOW, GRAB, 136# TIE DUCT	
REVISIONS:		DRAWING NO: 963N32902	
SCALE: 1/32		SHEET SIZE: B	
SHEET 2 OF 2		K	

REV.	EQD.	BY	REVISION DESCRIPTION	DATE	APPROVED
A	0013	RJ	NEW PART	6/27/07	---




UNLESS OTHERWISE SPECIFIED: DIMENSIONS IN PARENTHESES INDICATE DIMENSIONS TO BE USED		© RAILWAY EQUIPMENT CO. 2005	
DRAWN BY: R. J. JENSEN		RAILWAY EQUIPMENT CO. DELANO, MINNESOTA (763) 973-2200	
CHECKED BY: R. J. JENSEN		TITLE: CHAB SWITCH LAYOUT (ASSEMBLY)	
DATE: 6/27/07		DWG. NO.: 9559-0020	
MATERIAL: ASSY		SCALE: N/A	
DRAWN: RJ		DRAWING SIZE: B	
DATE: 6/27/07		SHEET: 1 OF 1	
MATERIAL: ASSY		REV: A	
SCALE: N/A		REV: A	

BA=0.000 for 90°

REVISION HISTORY				
RE	ECO #	DESCRIPTION	DATE	BY
K	11-0014	NEW MODULE/THERMOCOPLERS	7/8/2011	GJ

Parts List					
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	14042	A	EA	1	BAG, 4 X 6 002 ZIP TOPS
2	14165	-	EA	4	LATCH FOR SCREENS
3	2831551142	-	EA	2	BOLT, 1/4-20 X 3 HEX HEAD
4	2831851116	-	EA	11	BOLT, 3/8-16 X 1 HEX CAP
5	2831851120	-	EA	12	BOLT, 3/8-16 X 1-1/4 HEX HEAD
6	2832-5101	-	EA	2	NUT, 1/4-20 HEX
7	2832-5901	-	EA	30	NUT, 1/4-20 CENTERLOCK
8	2832-8101	-	EA	21	NUT, 3/8-16 HEX
9	2833-5129	-	EA	4	WASHER, 1/4 X 1.5 FENDER
10	2833-5211	-	EA	2	WASHER, 1/4 SPLIT LOCK
11	2833-8110	-	EA	10	WASHER, 3/8 FLAT
12	2833-8210	-	EA	21	WASHER, 3/8 SPLIT LOCK
13	29017	-	EA	10	BOLT, #8-32 X 3/8 WASHER HEAD
14	29032	-	EA	7	BOLT, 1/4-20 X 3/4 HEX SLOT
15	29051	-	EA	65	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
16	45017	-	EA	1	BALL VALVE, 3/4, BRASS
17	45039	A	EA	1	REGULATOR, LOW PRESSURE
18	60114	A	EA	1	UNION, 3/8 SCH 40 BLK
19	60118	-	EA	1	REDUCER, 1 TO 3/8 SCH 40 BLK
20	60128	-	EA	1	NIPPLE, 3/8 X 2 SCH 40 BLACK
21	60154	-	EA	22	GASKET, .112X1 ADHESIVE
22	60185	A	FT	14	GASKET, 0.25 X 0.75 ADHESIVE BACK
23	60190	-	EA	1	HOSE, 3/8X24 SS BRAIDED
24	60236	-	EA	1	TEE, 3/8 X 1/4 X 3/8 SCH 40
25	60237	-	EA	2	FITTING, COMPRESSION 1/4X1/4
26	61011	-	EA	2	NIPPLE, 3/4 X 1.5 SCH 40 BLACK
27	61025	-	EA	2	NIPPLE, 1 X 2 IN SCH 40 BLACK
28	61035	-	EA	1	REDUCER, 1 TO 3/4 SCH 40 BLACK
29	61052	-	EA	1	FLEXHOSE 1 X 24-1.25 IN OD
30	61058	A	IN	24	TUBING, 1/4 INCH O.D. COPPER
31	61065	A	EA	1	GASKET, 11X12, HIGH TEMP
32	93533	D	EA	1	ASSY, HI TEMP SENSOR SHORT
33	9508-0356	A	EA	1	RAIL TEMP SNSR T/C MAGNETIC
34	9508-0416	A	EA	1	DUCT, OFFSET, 2 LIFT-OUT
35	9528-3103	A	EA	1	ASSY, FLAME DUCT, 18X12X4'
36	9528-3209	B	EA	1	MAIN GHAB, HIGH, 5HP
37	9538-6115	K	EA	2	TRIM, OUTLET TOP
38	960615	A	EA	3	TRIM, OUTLET SIDE
39	960616	A	EA	2	TRIM, OUTLET BOTTOM
40	960617	A	EA	1	TRIM, OUTLET SIDE
41	960631	A	EA	1	ASSY, TEMPERATURE SENSOR
42	9608-0405	A	EA	1	BUNGALOW, 26HP GHAB, 6 X 6
43	9638-1000	B	EA	1	ASSY, ELEC BUNGALOW 230 IPH
44	9638-1100	A	EA	1	ASSY, ELEC BUNGALOW 230 IPH



UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO 3 PLACES
 FRACTIONS ARE TO 16 PLACES
 DIMENSIONS IN PARENTHESES ARE FOR INFORMATION ONLY
 DRAWN: GJONAS



RAILWAY EQUIPMENT CO., 2011
 RAILWAY EQUIPMENT CO.
 MANVELL, MINNESOTA (763) 922-2200

DATE: 07/08/11
 TITLE: ASSY, BUNGALOW W 5HP 240V GHAB
 DRAWING NO: 9638-0501K
 SHEET: 1 OF 1

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	28019	A	EA	1	BLOWER WHEEL, 1250 WITH HUB
2	28020	A	EA	1	INLET CONE, 1250 90%
3	28035	-	EA	6	MOUNT, RUBBER, MM, 1/4-20
4	28107	-	EA	1	NUT, 1/4-20 THUMB, NYLON
5	28126	-	EA	2	SPACER, 1/4 IN ID 3/8 IN LONG
6	28129-0003	-	EA	3	BOLT, 1/4-20 X 1 CARRIAGE
7	2831411108	-	EA	1	SCREW, #10-32 X 1/2 PAN SLT
8	2831411112	-	EA	1	SCREW, #10-32 X 3/4 PAN SLT
9	2831651110	-	EA	4	BOLT, 1/4-20 X 5/8 HEX HEAD
10	2831651116	-	EA	4	BOLT, 3/8-16 X 1 HEX CAP
11	2831861112	-	EA	23	BOLT, 3/8 X 0.75 CARRIAGE
12	2832-4101	-	EA	3	NUT, #10-32 HEX
13	2832-5101	-	EA	12	NUT, 1/4-20 HEX
14	2832-5901	-	EA	3	NUT, 1/4-20 CENTERLOCK
15	2832-8101	-	EA	14	NUT, 3/8-16 HEX
16	2832-8904	-	EA	27	NUT, 3/8-16 CENTERLOCK
17	2833-4210	-	EA	1	WASHER, #10 SPLT LOCK
18	2833-4310	-	EA	4	WASHER, #10 EXT. STAR
19	2833-5110	-	EA	6	WASHER, 1/4 FLAT
20	2833-5211	-	EA	10	WASHER, 1/4 SPLT LOCK
21	2833-8040	-	EA	4	RIVET, BUTTON HEAD PLATED STL
22	2833-8110	-	EA	4	WASHER, 3/8 FLAT
23	2833-8119	-	EA	8	WASHER, 3/8" X 1-1/2 FENDER
24	2833-8210	-	EA	14	WASHER, 3/8 SPLT LOCK
25	29016	-	EA	2	BOLT, 1/4-20 X 1/2 HEX SLOT
26	29051	-	EA	70	BOLT, 1/4-20 X 1/2 WITH 1/2 HD
27	32002	-	SOFT	3.5	INSULATION, FIBERGLASS
28	60002	-	EA	1	3/8 ROMEX
29	60169	-	EA	2	TY-RAP 0.30 X 8
30	60172	-	EA	1	LUG, RING #10-22-18GA HI-TEMP
31	60185	A	FT	8	GASKET, 0.25 X 0.75 ADHESIVE BACK
32	60195	-	FT	6	GASKET, .25 X 1.0 ADHESIVE BK
33	6032-0110	-	EA	1	LUG, RING 1/4-22-18GA NYLON
34	6033-0100	-	EA	5	TY-RAP, 4IN 0.10 WIDTH
35	61032	-	EA	1	NIPPLE, 1 X 3 IN SCH 40 BLACK
36	61037	-	EA	1	NIPPLE, 1 X 17 SCH 40 BLACK
37	61058	-	EA	1	ELBOW, 1IN SCH 40 BLACK
38	61070	-	EA	4	U-BOLT, MRO BOLT #05
39	80040-0955	C	EA	1	NAMEPLATE, 9654955 GHAB
40	92919	A	EA	8	WASHER, 1/4 EXT. STAR
41	9338-0026	A	EA	1	ASSY, BUZZER
42	9338-0036	A	EA	1	ASSY, GAS SENSOR EXT CABLE
43	9308-0039	A	EA	1	ASSY, DUCT SENSOR EXT CABLE
44	9508-0430	A	EA	1	ASSY, WIRED IGNITION XFMR
45	9508-0431	B	EA	1	ASSY, HARNESS AIR FLOW SWITCH
46	9508-0495	B	EA	1	ASSY, FLAME WIRE
47	95201	C	EA	1	BASE, MOTOR, 184T, GHAB
48	95202	A	EA	1	BASE, MOTOR, 184T, GHAB
49	952127	C	EA	1	PLATE, MOTOR BASE, 184T GHAB
50	9528-0135	B	EA	1	STUD PLATE
51	9558-0150	B	EA	1	BURNER, 12IN
52	960131	A	EA	1	ENCLOSURE, HAB
53	960632	B	EA	1	ENCLOSURE, HAB
54	960801	A	EA	1	BLOWER, AIR CUT FLANGE 3/8HP
55	96346	A	EA	1	BUNGALOW ENCL. MOUNTING PLATE
56	9638-0023	C	EA	1	MOTOR MOUNTING PLATE, HAB
57	963800	B	EA	1	ASSEMBLY, IGNITION WIRE
58	963801	B	EA	1	BLOWER OUTLET FLANGE 5HP
59	963802	B	EA	1	BLOWER BODY, 5HP BUNGALOW
60	963803	B	EA	1	PC, MOTOR BODY, HIGH 5HP
		B	EA	1	BLOWER SHROUD, 36HP

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
61	963804	B	EA	1	BASE, GHAB, 5HP
62	963805	A	EA	1	DEFLECTOR, INTAKE 5HP GHAB
63	963806	A	EA	1	SUPPORT, GAS SHP BUNGALOW
64	963807	A	EA	3	SUPPORT, GAS LINE, 5HP
65	963808	A	EA	1	CAP, INTAKE INSIDE 5HP
66	9658-0028	B	EA	1	ASSY, WIRED MOTOR, 3HP/230VPH
67	9658-0138	A	EA	1	ASSY, GHAB PIPING 3HP BUNGALOW
68	R8039-0816	A	EA	1	LABEL, FAN ROTATION
69	R8039-0830	A	EA	1	LABEL, GHAB WARNINGS
70	R8039-0955	A	EA	1	LABEL, ID PLATE AGA/CSA
71	R9650-0105	C	EA	2	MANUAL, 965 BUNGALOW 3HP 230V

REV	ECO	DESCRIPTION	DATE	BY
E	11-0025	NEW PART (REVISED TO MATCH EPICOR)	03/04/11	MF
K	11-0014	UPDATED MODULE REV J	07/21/11	GJ



DETAIL A
SCALE 1 / 2


UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESES ARE METRIC EQUIVALENTS
TOLERANCES ARE AS SHOWN
DRAWING IS FOR INFORMATION ONLY
DATE: 08/25/06
DRAWN: RMU
CHECKED: N/A
TOLERANCE: N/A

RAILWAY EQUIPMENT CO.
MINNEAPOLIS, MINNESOTA (612) 975-8200
THE ASSY, MAIN 3HP GHAB BUNGALOW
BUNGALOW ASSY & BOM
DRAWING NO: 9558-6115
SCALE: 1/16
DWS SIZE: B
SHEET 1 OF 1

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS



Parts List					Parts List						
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927237	A	EA	2	COVER PLATE, TEMP SENSOR	14	927387	B	EA	2	E-CLIP INSULATOR PAD TIE PLATE 136#
2	2833-9009	-	EA	8	WASHER, 3/4 SPLIT LOCK	15	14151	-	EA	1	WIRE BURLAPBAG CLOSING TIES 6"
3	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK	16	R8039-0904	D	EA	2	CAUTION LABEL, TIE DUCT 136#
4	2831851114	-	EA	4	BOLT, 3/8-16 X 1 HEX HEAD, SS	17	R8039-0914	D	EA	1	TAG, ACCESS PARTS FOR TIE DUCT
5	28121	-	EA	8	BOLT, 3/4-10 X 1 1/2 HEX SS	18	9528-4109	B	EA	1	FLANGE ADAPTER KIT, 9X9 DUCT
6	2831851116	-	EA	16	BOLT, 3/8-16 X 1 HEX CAP	19	14153	-	EA	1	BAG, WOVEN YELLOW 23.5 X 48
7	2832-8904	-	EA	16	NUT, 3/8-16 CENTERLOCK	20	12425	-	IN	720	TAPE ROLL 2" WIDE HEAVY
8	927386	A	EA	4	E-CLIP INSULATOR	21	2833-9020	-	EA	16	WASHER, M12 SPLIT LOCK
9	927248	A	EA	4	RAIL CLIP, TIE DUCT	22	927602	A	EA	2	COVER, POINT/TRACK NOZZLE
10	952286	A	EA	1	ASSY, TIE DUCT QUICK CHANGE	23	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
11	95234	C	EA	2	GASKET, 5HP TIE DUCT	24	2831951121	-	EA	12	BOLT, 1/2-13 X 1.25 HEX SS
12	952267	A	EA	2	COVER PLATE WITH LIFTING LUG	25	2831951123	-	EA	4	BOLT, 1/2-13 X 1.75 HEX SS
13	927355	B	EA	2	TIE PLATE 136# E-CLIP-PAD TYPE						



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESES ARE MILLIMETERS		RAILWAY EQUIPMENT CO., 2006	
DRAWN: WJ/S		RAILWAY EQUIPMENT CO. DEVELOPMENT CENTER (C263) 972-3300	
DATE: 10/23/06		TITLE: TIE DUCT, 136# QUICK CHANGE (ASSEMBLY)	
DWG NO: 9528-4805		REV: A	
SCALE: 1/8		SHEET: 1 OF 1	

Parts List				Parts List							
ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION	ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927366	B	EA	2	TIE PLATE 115# E-CLIP PAD TYPE	14	95234	C	EA	2	GASKET, SHP TIE DUCT
2	927237	A	EA	2	COVER PLATE, TEMP SENSOR	15	952267	A	EA	2	COVER PLATE WITH LIFTING LUG
3	2831951121	-	EA	12	BOLT, 1/2-13 X 1.25 HEX SS	16	14151	-	EA	1	WIRE BURLAPBAG CLOSING TIES 6"
4	2833-9009	-	EA	8	WASHER, 3/4 SPLIT LOCK	17	R8039-0905	D	EA	2	CAUTION LABEL, TIE DUCT 115#
5	2833-8210	-	EA	4	WASHER, 3/8 SPLIT LOCK	18	R8039-0915	D	EA	1	TAG, ACCESS PARTS FOR TIE DUCT
6	2831851114	-	EA	4	BOLT, 3/8-16 X 1 HEX HEAD, SS	19	95284109	B	EA	1	FLANGE ADAPTOR KIT, 9X9 DUCT
7	28121	-	EA	8	BOLT, 3/4-10 X 1 1/2 HEX SS	20	14153	-	EA	1	BAG, WOVEN YELLOW 23.5 X 48
8	2831851116	-	EA	16	BOLT, 3/8-16 X 1 HEX CAP	21	12425	-	IN	720	TAPE ROLL, 2" WIDE HEAVY
9	2832-9904	-	EA	16	NUT, 3/8-16 CENTERLOCK	22	2833-9020	-	EA	16	WASHER, M12 SPLIT LOCK
10	927368	A	EA	2	PAD FOR E-CLIP RUBBER 115# TIE	23	927602	A	EA	2	COVER, POINTTRACK NOZZLE
11	927366	A	EA	4	E-CLIP INSULATOR	24	927603	A	EA	2	COVER, OUTSIDE TRACK NOZZLE
12	927248	A	EA	4	RAIL CLIP, TIE DUCT	25	2831951123	-	EA	4	BOLT, 1/2-13 X 1.75 SS HEX
13	952286	A	EA	1	ASSY, TIE DUCT QUICK CHANGE						

REVISION HISTORY				
REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/23/2006	WS



RAILWAY EQUIPMENT CO., 2006

RAILWAY EQUIPMENT CO.
DEPT. INV. M/VN/S/974 (751) 972-8290

TIE DUCT, 115# QUICK CHANGE
(ASSEMBLY)

DATE: 10/23/06
DRAWN: WS
CHK: JG
APP: JG
DESIGN: WS

DWG NO: 9528-4605
DATE: 10/23/06
SCALE: 1/8
DWS: B
SHEET 1 OF 1

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DECIMALS - ANGULAR
FRACTIONS - DIMENSIONS
FOR NOTATIONAL ELEMENTS


WARRANTY: SEE B.O.M.
N/A

REV: A

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/24/2006	WS

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927600	B	EA	1	POINT/TD NOZZLE MOUNT PLATE RH
2	927701	A	EA	1	SCREEN, POINT NOZZLE
3	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
4	92757	D	EA	1	GASKET, ISO, PT NOZZLE RED
5	92759	B	EA	1	GASKET, ISO, TR NOZZLE RED
6	93617	D	EA	1	POINT NOZZLE, 4 X 4 GALV
7	2833-9015	B	EA	8	WASHER, ISOLATING NOZZLE
8	28106	-	EA	8	SPACER, .38X.625X-.375 ROUND
9	2833-9014	-	EA	4	WASHER, 5/8 FLAT SAE
10	2833-8110	-	EA	8	WASHER, 3/8 FLAT
11	2833-8210	-	EA	8	WASHER, 3/8 SPLIT LOCK
12	2832-8101	-	EA	8	NUT, 3/8-16 HEX
14	R6508-4000	A	EA	1	LABEL, QUICK NOZZLE ASSY RH
15	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

REVISION HISTORY	DESCRIPTION	DATE	BY
A	NEW PART	10/24/2006	WS




UNLESS OTHERWISE SPECIFIED:	RAILWAY EQUIPMENT CO. 2006
DIMENSIONS ARE IN INCHES	
DECIMALS ARE TO NEAREST HUNDRED	
FRACTIONS ARE TO NEAREST SIXTEENTH	
ANGLES ARE TO NEAREST MINUTE	
FINISHES ARE TO BE SHOWN	
DO NOT SCALE DRAWING	
DRAWN: WS	
DATE: 10/24/06	
MATERIAL: SEE B.O.M.	
SCALE: 1/4"	
REVISIONS:	
REV: A	
SHEET 1 OF 1	
DWG NO: 9508-4000	
ISSUE SIZE: B	
(ASSEMBLY)	
TITLE: POINT/TRACK NOZZLE ASSY RH	
DELTAVO, MINNESOTA (763) 972-2200	
RAILWAY EQUIPMENT CO.	

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	927606	B	EA	1	POINT/TD NOZZLE MOUNT PLATE LH
2	927701	A	EA	1	SCREEN, POINT NOZZLE
3	927702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
4	92757	D	EA	1	GASKET ISO_PT NOZZLE RED
5	92759	B	EA	1	GASKET, ISO_TR NOZZLE RED
6	93617	D	EA	1	POINT NOZZLE, 4 X 4 GALV.
7	2833-9015	B	EA	8	WASHER, INSULATING NOZZLE
8	28106	-	EA	8	SPACER, .38X.625X.375 ROUND
9	2833-9014	-	EA	4	WASHER, 5/8 FLAT SAE
10	2833-8110	-	EA	8	WASHER, 3/8 FLAT
11	2833-8210	-	EA	8	WASHER, 3/8 SPLTT LOCK
12	2832-8101	-	EA	8	NUT, 3/8-16 HEX NUT
13	R9308-4001	A	EA	1	LABEL, QUICK NOZZLE ASSY LH
14	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

Parts List

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/19/2006	WS








RAILWAY EQUIPMENT CO., 2006

<p>UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DECIMALS TO THREE PLACES FRACTIONS TO SIXTEENTHS ANGLES TO NEAREST MINUTE HOLE POSITION UNLESS OTHERWISE SPECIFIED</p> <p>DATE: 10/19/06 WKS: SEE B.O.M. TOLERANCES: N/A</p>	<p>TITLE: POINT/TRACK NOZZLE ASSY LH (ASSEMBLY)</p> <p>DWG NO: 9508-4001 SCALE: 1/4" = 1" SHEET 1 OF 1</p>
---	---

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	92789	B	EA	1	GASKET, ISO, TR NOZZLE RED
2	92702	A	EA	1	SCREEN TRACK DUCT NOZZLE LARGE
3	28106	-	EA	1	SPACER, .38X.825X.375 ROUND
4	2833-9015	B	EA	4	WASHER, INSULATING NOZZLE
5	2833-9110	-	EA	4	WASHER, 3/8 FLAT
6	2833-9210	-	EA	4	WASHER, 3/8 SPLUT LOCK
7	2832-9101	-	EA	4	NUT, 3/8-16 HEX
8	927604	B	EA	1	TRACK DUCT NOZZLE MOUNT PLATE
9	60195	-	FT	1.67	GASKET, .25 X 1.0 ADHESIVE BK
10	R99508-4003	A	EA	1	LABEL, QUICK NOZZLE ASSY RH
11	927490	A	EA	1	NOZZLE, TRACK DUCT ASSY

Parts List

REV	ECO	DESCRIPTION	DATE	BY
A	06-0024	NEW PART	10/19/2006	WS



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DECIMALS TO THREE PLACES
FRACTIONS TO SIXTEENTHS
ANGULAR TO NEAREST MINUTE
DIMENSIONS IN PARENTHESES ARE FOR REFERENCE

DATE: 10/19/06
WKS: SEE B.O.M.
DIVISION: WSS

SCALE: 3/8
DRAWING NO.: 9508-4003
TENS. ALLOWANCE:
SHEET 1 OF 1


RAILWAY EQUIPMENT CO., 2006
RAILWAY EQUIPMENT CO.
BELLEVUE, WASHINGTON (781) 972-8200

TITLE: OUTSIDE TRACK NOZZLE ASSY RH (ASSEMBLY)

REV: A


REVISION HISTORY			
REV	ECO	DESCRIPTION	DATE
A	06-0028	NEW PART	11/30/2006
			BY RMJ

Parts List			
ITEM	PART NUMBER	QTY	DESCRIPTION
1	927488	EA	1 NOZZLE, TRACK DUCT, NO DAMPER
2	92745	EA	1 HOLDDOWN STRAP, T. DUCT
5	92742	EA	2 SPRING, TRACK DUCT SUPPORT
4	92743	EA	2 CLIP, HOLDDOWN SPRING
7	60195	IN	20 GASKET, .25 X 1.0 ADHESIVE BK





PLACE P/N:60195 ON LEDGE (FRONT & BACK) BEFORE INSTALLING DUCT

PLACE P/N:60195 UNDER STRAP FOR TRANSPORTATION.





PACKOUT VIEW
SCALE 1 / 4




UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES DIMENSIONS IN PARENTHESIS ARE IN MILLIMETERS		RAILWAY EQUIPMENT CO.
DRAWN: RMJ		RAILWAY EQUIPMENT CO.
DATE: 11/30/06		DESIGN: M11A153024 (763) 072-3300
DWG NO: 927490		TITLE: NOZZLE, TRACK DUCT ASSY
SCALE: 1/2		SHEET: 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	2831891114	EA	4	BOLT, HEX HD 3/8-16 x 1" SS
2	2833-8110	EA	4	WASHER, FLAT 3/8"
3	2833-9015B	EA	4	WASHER, INSULATOR
4	28106	EA	4	SPACER, ROUND, .39 X .825 X .375
5	92757D	EA	1	GASKET, POINT NOZZLE
6	2833-9014	EA	4	WASHER, 5/8 FLAT PLATED
7	14046	EA	1	BAG, ZIPTOP 9x12 4mil
8	2833-8210	EA	4	WASHER, SPLIT LOCK 3/8"
9	927701A	EA	1	SCREEN, POINT NOZZLE



REV	EDA	REV	REVISION DESCRIPTION	DATE	APPROVED
B	---	TB	ADD 927701	10/19/00	---
C	06-0203	RJ	CORNERS CUT OFF ON DUCT	11/29/06	---



© RAILWAY EQUIPMENT CO. 1997-2002

RAILWAY EQUIPMENT CO.
 DELANO, MINNESOTA (763) 973-3200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO BE ROUNDED UP
 TO THE NEXT HIGHER VALUE
 DO NOT SCALE DRAWINGS


DRAWN: EFK
 DATE: 04/11/97

TITLE: ISOLATION KIT ASSEMBLY
 POINT NOZZLE
 TIE DUCT


DWG NO.: 9278-0021
 SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1

REV: C

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	952226	EA	1	INSUL COVER, OFFSET DUCT
2	29019	EA	8	SHOULDER BOLT 1/4-20 X 1.3
3	952224	EA	1	DUCT, OFFSET, WITH HEAVY BASE
4	32002	SQ.FT.	6	INSULATION FIBERGLASS
5	9528-0074	EA	1	GASKET KIT, 9X9 SHP FLEX
6	6093-0102	EA	1	TY-RAP
7	952236	EA	1	MIXER, AIRFLOW 9X9 OFFSET W/DM
8	93625	EA	1	GASKET, 9 X 9 LIFT-OUT
9	2831851116	EA	2	BOLT, 3/8-16 X 1, HEX HEAD
10	2832-8904	EA	2	NUT, 3/8-16 CENTERLOCK



REV	SCALE	BY	DATE	APPROVED
A	008	RF	02/28/05	



UNLESS OTHERWISE SPECIFIED,
DIMENSIONS ARE IN INCHES
DECIMALS ARE TO BE ROUNDED
UP TO THE NEXT HIGHER
HUNDRETHS PLACE
DIMENSIONS IN PARENTHESES
ARE TO BE USED FOR
MATERIALS NOT LISTED
HEREIN

DATE: 02/28/05
DRAWN: RPF
CHECKED: N/A
APPROVED: N/A

SCALE: 1/4" = 1"

© RAILWAY EQUIPMENT CO. 2005
RAILWAY EQUIPMENT CO.
DELAWARE, MINNESOTA (763) 872-8200


TITLE: OFFSET DUCT, 2', W/MIXER
REINFORCED, LIFTOUT
ASSEMBLY / B.O.M.

DWG NO.: 9528-3402
SHEET: 1 OF 1
REV: A



REV.	QTY.	BY	DATE	APPROVED
A	1	JK	10/21/03	---

REV.	QTY.	BY	DATE	APPROVED
A	1	JK	10/21/03	---

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	9528-0074	EA	1	GASKET KIT, 9X9 5HP FLEX
2	952709	EA	1	DUCT, FLEX, 2' STRAIGHT
3	6093-0102	EA	1	TY-RAP
4	32002	SQF	8	INSULATION, FIBERGLASS
5	952244	EA	1	FLEX WRAP, TOP 2 FOOT
6	952245	EA	1	FLEX WRAP, BOTTOM 2'
7	29051	EA	6	BOLT, 1/4"-20 X 1/2 WITH 1/2 HD



PLACE INSULATION AROUND
FLEX DUCT BEFORE
INSTALLING PROTECTIVE WRAP










UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS 3/16 & 1/8 .005 1/4 & 3/8 .010 1/2 & 3/4 .015 1 & 2 .020 DO NOT SCALE DRAWING		DRAWN JJK	
DATE	10/21/03	REV	A
MATERIAL	N/A	REV	A
DESIGN	N/A	SCALE	1/4"
REV	1	DRAWING SIZE	B
DATE	10/21/03	SHEET	1 OF 1

© RAILWAY EQUIPMENT CO. 2003
RAILWAY EQUIPMENT CO.
 DELRANO, CALIFORNIA (951) 972-3500

TITLE	DUCT, FLEX, INSULATED 2' STRAIGHT (ASSEMBLY)
DWG NO.	9528-4220
SCALE	1/4"
DRAWING SIZE	B
SHEET	1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927443	EA	1	TRACK DUCT BASE 5'
2	92740	EA	1	END PLATE, TRACK DUCT
3	92730	EA	1	TRACK DUCT COVER 5'
4	92774	EA	1	TRACK DUCT SUPPORT BRACKET
5	92785	EA	1	DEFLECTOR, TRACK DUCT, SMALL
6	29051	EA	9	BOLT, 1/4"-20X1/2" W/2" HEX HEAD
7	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH

REV.	DATE	BY	DESCRIPTION	DATE	APPROVED
A	05-07	RF	NEW SPLICE SYSTEM	05/24/05	---
B	05-07	RO	NEW SUPPORT ASSEM DESIGN	10/27/05	---



FULL SCALE

© RAILWAY EQUIPMENT CO. 2005








RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 973-3200

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO BE ROUNDED UP
 TO THE NEXT HIGHER HUNDREDTHS
 OF AN INCH
 DIMENSIONS IN PARENTHESES
 ARE FOR INFORMATION ONLY
 DO NOT SCALE DRAWINGS

DRWING: RPF
 DATE: 05/24/05
 MATERIAL: SEE PRINT
 TITLE: TRACK DUCT
 5' POINT LTD
 ASSEMBLY / B.O.M.
 DWG NO.: 9278-0226
 SCALE: 1/4" DRAWING SIZE: B SHEET: 1 OF 1

REV.	LOC.	BY	REVISION DESCRIPTION	DATE	APPROVED
A	05-007	RF	NEW SPLICE SYSTEM	05/24/05	----
B	05-007	RO	NEW SUPPORT ASSM DESIGN	10/27/05	----

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92735	EA	1	TRACK DUCT BASE 5'
2	92730	EA	1	TRACK DUCT COVER 5'
3	927441	EA	1	CENTER COVER, E.Z. SPLICE
4	927442	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	92774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/ 2" HEX HEAD
8	6093-0100	EA	1	TY-RAP, 4" .10 WIDTH



FULL SCALE

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DECIMALS ARE TO 2 PLACES
 FRACTIONS ARE TO 1/32
 DIMENSIONS TO 30" & OVER
 TO BE TO NEAREST 1/8"
 DO NOT SCALE DRAWING

DATE: 05/24/05
 DRAWN: RPF
 TITLE: TRACK DUCT 5' MID ASSEMBLY / B.O.M.

© RAILWAY EQUIPMENT CO. 2005
 RAILWAY EQUIPMENT CO.
 DUBLINO, MINNESOTA (763) 972-3500

DATE: 05/24/05
 DRAWN: RPF
 TITLE: TRACK DUCT 5' MID ASSEMBLY / B.O.M.








DATE: 10/27/05
 DRAWN: RO
 TITLE: NEW SUPPORT ASSM DESIGN

DATE: 05/24/05
 DRAWN: RF
 TITLE: NEW SPLICE SYSTEM


SCALE: 1/4" = 1'-0"

SHEET 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	927538	EA	1	TRACK DUCT BASE 10'
2	92741	EA	1	TRACK DUCT COVER 10'
3	927441	EA	1	CENTER COVER, E.Z. SPLICE
4	927442	EA	2	END COVER, E.Z. SPLICE
5	927450	EA	1	BASE, E.Z. SPLICE
6	92774	EA	1	TRACK DUCT SUPPORT BRACKET
7	29051	EA	6	BOLT, 1/4"-20X1/2" W/ 2" HEX HEAD
8	60931-0100	EA	1	TY-RAP, 4" .10 WIDTH



1/8 SCALE



REV.	EDA.	BY	REVISION DESCRIPTION	DATE	APPROVED
J	---	TB	REMOVE 92744, 28080, 28081	05/28/99	---
K	02-00	RF	REPLACE 29016 W/29051	08/29/02	---
L	06-07	RF	NEW SPLICE SYSTEM	05/18/05	---
M	06-07	RO	NEW SUPPORT ASSEM. DESIGN	10/27/05	---

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESES
ARE IN MILLIMETERS
DIMENSIONS IN PARENTHESES
DO NOT SCALE DRAWING

DRAWN: RPF
DATE: 02/15/93

INTITIAL: SEE PRINT

SCALE: 1/4" DRAWING SIZE B SHEET 1 OF 1

© RAILWAY EQUIPMENT CO. 1993-2005
RAILWAY EQUIPMENT CO.
DARIANO, MINNESOTA (763) 978-2800





TITLE: TRACK DUCT
10' MID
ASSEMBLY / B.O.M.

DWG NO.: 9278-1201
REV: M

FULL SCALE

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	9278-0207	EA	1	TRACK DUCT 7' HEEL
2	9278-0277	EA	1	ISO KIT, IR NOZZLE LARGE
3	927490	EA	1	NOZZLE, TRACK DUCT
4	41023	EA	1	BOX, TRACK DUCT KIT

REV.	ECN.	REV.	REVISION DESCRIPTION	DATE	APPROVED
A	02-027	RF	NEW PART	07/03/02	---
B	03-023	RF	UPDATE NOZZLE	07/29/03	---
C	05-017	RF	NEW SPLICE DESIGN	05/25/05	---
D	05-027	RO	NEW TRACK DUCT NOZZLE	11/10/05	---
E	05-054	RJ	NEW TRACK DUCT NOZZLE	02/02/07	---



UNLESS OTHERWISE SPECIFIED:
DIMENSIONS ARE IN INCHES
DIMENSIONS IN PARENTHESES ARE
IN MILLIMETERS
TOLERANCES UNLESS OTHERWISE SPECIFIED:
FRACTIONS DECIMALS
0.005 0.010 0.015 0.020
0.005 0.010 0.015 0.020
0.005 0.010 0.015 0.020
0.005 0.010 0.015 0.020






DRAWN: RPF
DATE: 07/03/02
MATERIAL: N/A
SCALE: N/A

© RAILWAY EQUIPMENT CO. 2002-2005
RAILWAY EQUIPMENT CO.
DARIANO, MINNESOTA (763) 973-2200

TITLE: TRACK DUCT KIT, 7' LARGE NOZZLE
DWG NO.: 9278-0270
SCALE: N/A DRAWING SIZE: B SHEET: 1 OF 1
REV: E

REV.	DATE	BY	DESCRIPTION
D	6/21/91	EFK	REDESIGN FOR SPRING MOUNT.
E	9/25/92	EFK	CHG. P/N 927135 REV.B TO 927135 REV.C
F	7/8/94	EFK	CHG. P/N 92742 REV.A TO 92742 REV.B
G	5.26.99	TB	ADD ITEMS 10 THRU 15
H	4.11.01	TB	#92743B WAS 92743A
J	05/18/05	RF	NEW SPLICE SYSTEM
K	10/27/05	RO	SHORTENED 927550-551

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	92745	EA	1	HOLDDOWN STRAP, TRACK DUCT
2	92750	EA	1	TRACK DUCT SUPPORT BASE
3	92751	EA	1	TRACK DUCT SPRING BRKT
4	92742	EA	2	SPRING, TRACK DUCT SUPPORT BRKT
5	283155110	EA	2	SPRING CLIP, TRACK DUCT SUP-BRKT
6	28315801	EA	2	1/4-20 X 5/8 HEX BOLT #5 HARD
7	2833-810	EA	2	1/4-20 CENTERLOCK NUT
8	28045	EA	2	3/8 FLAT WASHER
9	14042	EA	1	LAG BOLT 3/8 X 2.5
10	14045	EA	1	BAG, ZIPLOCK 4 x 6 x .004
11	14045	EA	1	BAG, ZIPLOCK 12 x 15 x .004



© RAILWAY EQUIPMENT CO. 1990-2005

RAILWAY EQUIPMENT CO.
 MILWAUKEE, WISCONSIN (708) 878-8800

DESIGNED BY	DATE	6/21/91
CHECKED BY	DATE	
APPROVED BY	DATE	

ISSUED BY: EFK
 DATE: 6/21/91
 SHEET: 1 of 1

PROJECT: TRACK DUCT SUPPORT BRKT SUB-ASSEMBLY
 PART NO.: 92774

SCALE: 1:1

MATERIAL: 304 SS

FINISH: POLISHED

UNLESS OTHERWISE SPECIFIED:
 ALL DIMENSIONS ARE IN INCHES
 DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS
 FINISH: 304 SS
 TOLERANCES: ±.015

RAILWAY EQUIPMENT CO.
 1200 W. WISCONSIN ST.
 MILWAUKEE, WI 53227

REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW

REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW


REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW

REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW

REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW

REV	ECO #	DESCRIPTION	DATE	BY
A	13-0028	NEW PART	10/2/13	DW

ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	14046	-	EA	1	BAG, 9 X 12 4MIL ZIPTOP
2	2100131100	-	EA	1	DRIVE AC 3 HP 230V 3PH INPUT
3	21016	-	EA	1	CONNECTOR, HOUSING, 10 POS
4	21017	-	EA	1	STRAIN RELIEF, 10 POS
5	21020	-	EA	1	CONNECTOR, HOUSING, 2 POS
6	21021	-	EA	1	STRAIN RELIEF, 2 POS
7	21023	-	EA	1	STRAIN RELIEF, 3 POS
8	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA
9	28029	-	EA	1	TERMINAL ASSY, 1 X 12 POS
10	28090	-	EA	1	CAP, TERMINAL POST INSULATING
11	28091	-	EA	1	SHIELD, TERMINAL POST INSULATE
12	2831211106	-	EA	1	SCREW, #6-32 X 3/8 PAN SLT
13	2831281103	-	EA	2	SCREW, #6-32 X 3/16 FLSTR SLT
14	2831311106	-	EA	7	SCREW, #8-32 X 3/8 PAN SLT
15	2831411106	-	EA	9	SCREW, #10-32 X 3/8 PAN SLT
16	2831411108	-	EA	4	SCREW, #10-32 X 1/2 PAN SLT
17	2831411110	-	EA	3	SCREW, #10-32 X 5/8 PAN SLT
18	2831541132	-	EA	2	SCREW, 1/4-20 X 2 RND SLT
19	2832-5101	-	EA	6	NUT, 1/4-20 HEX
20	2833-2210	-	EA	2	WASHER, #6 SPLIT LOCK
21	2833-3110	-	EA	1	WASHER, #8 FLAT SAE
22	2833-4310	-	EA	2	WASHER, #10 EXT. STAR
23	2833-5110	-	EA	2	WASHER, 1/4 FLAT
24	2833-5211	-	EA	6	WASHER, 1/4 SPLIT LOCK
25	45185	-	EA	1	CONTACTOR, 40 AMP 3POLE, 115V COIL
26	51204	-	EA	1	BRACKET, GE CIRCUIT BREAKER
27	51205	-	EA	1	CIR BRKR, 50A 240V 2POLE
28	5300-0203	-	EA	1	HEATER, STRIP 115V 125W
29	53080	-	EA	1	SENSOR, AIR TEMP
30	60172	-	EA	2	LUG, RING #10 22-18GA HI-TEMP
31	6032-0110	-	EA	12	LUG, RING 1/4 22-18GA NYLON
32	6032-0111	-	EA	4	LUG, RING #10 16-14GA NYLON
33	6032-0112	-	EA	3	LUG, RING 1/4 16-14GA NYLON
34	6034-0102	-	EA	5	LUG, PUSH-ON F. 250 22-18GA
35	6034-0103	-	EA	1	LUG, PUSH-ON F. 250 16-14GA
36	6090-0102	-	EA	1	CABLE TIE MOUNTS
37	6093-0004	-	IN	1	WIRE DUCT, 1.5IN X 3IN
38	6093-0100	-	EA	25	TY-RAP, 4IN 0.10 WIDTH
39	6093-0303	-	IN	1	WIRE DUCT, COVER 1.5 IN
40	681001	-	EA	1	WIRE, 10GA BLACK 600V 105C
41	681601	-	IN	47.5	WIRE, 16GA GREEN - HOOK UP
42	681803	-	IN	40	WIRE, 18GA BELDEN HIGH TEMP
43	681832	-	IN	61.5	WIRE, 18GA 300V 105C BLACK
44	681833	-	IN	39	WIRE, 18GA THINWALL WHITE 300V
45	681834	-	IN	57	WIRE, 18GA THINWALL RED 300V
46	681835	-	IN	134	WIRE, 18GA THINWALL BROWN 300V
47	681836	-	IN	190	WIRE, 18GA THINWALL BLUE 300V
48	8039-0813	A	EA	1	LABEL, HOT DO NOT TOUCH
49	9220-0029	A	EA	1	COVER, HEAT SHIELD
50	9338-0015	C	EA	1	TRANSFORMER, CONTROL MODULE
51	9338-0320	J	EA	1	CONTROL MODULE, GHAB W/ DISP
52	9338-0325	B	EA	1	SURGE ARRESTOR ASSY, 240V 1PH
53	95075	B	EA	1	PANEL, ELECTRIC HAB
54	9508-0037	A	EA	1	ASSY, CURRENT COIL 100A AC
55	R9130-0021	B	EA	1	LABEL, TERM POST SINO NET



ITEM	PART NUMBER	REV	UOM	QTY	DESCRIPTION
1	14046	-	EA	1	BAG, 9 X 12 4MIL ZIPTOP
2	2100131100	-	EA	1	DRIVE AC 3 HP 230V 3PH INPUT
3	21016	-	EA	1	CONNECTOR, HOUSING, 10 POS
4	21017	-	EA	1	STRAIN RELIEF, 10 POS
5	21020	-	EA	1	CONNECTOR, HOUSING, 2 POS
6	21021	-	EA	1	STRAIN RELIEF, 2 POS
7	21023	-	EA	1	STRAIN RELIEF, 3 POS
8	21212	-	EA	1	CONNECTOR, HOUSING, 3 POS 18GA
9	28029	-	EA	1	TERMINAL ASSY, 1 X 12 POS
10	28090	-	EA	1	CAP, TERMINAL POST INSULATING
11	28091	-	EA	1	SHIELD, TERMINAL POST INSULATE
12	2831211106	-	EA	1	SCREW, #6-32 X 3/8 PAN SLT
13	2831281103	-	EA	2	SCREW, #6-32 X 3/16 FLSTR SLT
14	2831311106	-	EA	7	SCREW, #8-32 X 3/8 PAN SLT
15	2831411106	-	EA	9	SCREW, #10-32 X 3/8 PAN SLT
16	2831411108	-	EA	4	SCREW, #10-32 X 1/2 PAN SLT
17	2831411110	-	EA	3	SCREW, #10-32 X 5/8 PAN SLT
18	2831541132	-	EA	2	SCREW, 1/4-20 X 2 RND SLT
19	2832-5101	-	EA	6	NUT, 1/4-20 HEX
20	2833-2210	-	EA	2	WASHER, #6 SPLIT LOCK
21	2833-3110	-	EA	1	WASHER, #8 FLAT SAE
22	2833-4310	-	EA	2	WASHER, #10 EXT. STAR
23	2833-5110	-	EA	2	WASHER, 1/4 FLAT
24	2833-5211	-	EA	6	WASHER, 1/4 SPLIT LOCK
25	45185	-	EA	1	CONTACTOR, 40 AMP 3POLE, 115V COIL
26	51204	-	EA	1	BRACKET, GE CIRCUIT BREAKER
27	51205	-	EA	1	CIR BRKR, 50A 240V 2POLE
28	5300-0203	-	EA	1	HEATER, STRIP 115V 125W
29	53080	-	EA	1	SENSOR, AIR TEMP
30	60172	-	EA	2	LUG, RING #10 22-18GA HI-TEMP
31	6032-0110	-	EA	12	LUG, RING 1/4 22-18GA NYLON
32	6032-0111	-	EA	4	LUG, RING #10 16-14GA NYLON
33	6032-0112	-	EA	3	LUG, RING 1/4 16-14GA NYLON
34	6034-0102	-	EA	5	LUG, PUSH-ON F. 250 22-18GA
35	6034-0103	-	EA	1	LUG, PUSH-ON F. 250 16-14GA
36	6090-0102	-	EA	1	CABLE TIE MOUNTS
37	6093-0004	-	IN	1	WIRE DUCT, 1.5IN X 3IN
38	6093-0100	-	EA	25	TY-RAP, 4IN 0.10 WIDTH
39	6093-0303	-	IN	1	WIRE DUCT, COVER 1.5 IN
40	681001	-	EA	1	WIRE, 10GA BLACK 600V 105C
41	681601	-	IN	47.5	WIRE, 16GA GREEN - HOOK UP
42	681803	-	IN	40	WIRE, 18GA BELDEN HIGH TEMP
43	681832	-	IN	61.5	WIRE, 18GA 300V 105C BLACK
44	681833	-	IN	39	WIRE, 18GA THINWALL WHITE 300V
45	681834	-	IN	57	WIRE, 18GA THINWALL RED 300V
46	681835	-	IN	134	WIRE, 18GA THINWALL BROWN 300V
47	681836	-	IN	190	WIRE, 18GA THINWALL BLUE 300V
48	8039-0813	A	EA	1	LABEL, HOT DO NOT TOUCH
49	9220-0029	A	EA	1	COVER, HEAT SHIELD
50	9338-0015	C	EA	1	TRANSFORMER, CONTROL MODULE
51	9338-0320	J	EA	1	CONTROL MODULE, GHAB W/ DISP
52	9338-0325	B	EA	1	SURGE ARRESTOR ASSY, 240V 1PH
53	95075	B	EA	1	PANEL, ELECTRIC HAB
54	9508-0037	A	EA	1	ASSY, CURRENT COIL 100A AC
55	R9130-0021	B	EA	1	LABEL, TERM POST SINO NET

UNLESS OTHERWISE SPECIFIED:
 DIMENSIONS ARE IN INCHES
 DIMENSIONS IN PARENTHESES ARE IN MILLIMETERS
 DIMENSIONS IN BRACKETS ARE IN METERS
 DIMENSIONS IN SQUARE BRACKETS ARE IN FEET AND INCHES
 DIMENSIONS IN CIRCLES ARE IN MILLIMETERS
 DIMENSIONS IN DIAMETERS ARE IN MILLIMETERS
 DIMENSIONS IN SQUARE DIAMETERS ARE IN MILLIMETERS


RAILWAY EQUIPMENT CO. 2011
 RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-2200

TITLE: GHAB CONTROL 3HP 240V AC DRIVE
 (ASSEMBLY / B. O. M.)

DRAWING DW: 9558-0156
 DATE: 10/02/13
 MAT: N/A
 REVISION: A
 SHEET 1 OF 1

SCALE: 1:4
 DIMS SIZE: B

REV.	DATE	BY	DESCRIPTION
A	7/7/09	ES	ADDED 20V/230VAC NEW MODULE
B	2/24/09	ES	REVISION B
C	09-09-04	ES	ADDED 20V/230VAC
D	11-09-04	CS	NEW MODULE



© RAILWAY EQUIPMENT CO. 2011


RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-2200

TITLE: GAS HOT AIR BLOWER
 208/230/460/575/VAC, 3PH, 2 STAGE
 SCHEMATIC / CONNECTION DIAGRAM

DWG NO. 9504-0125 REV D

DRAWING BY J.L.H. DRAWING SIZE A SHEET 1 OF 1



REV.	EDA.	BY	REVISION DESCRIPTION	DATE	APPROVED
B		JS	REVISION B	2/22/09	
C		CS	NEW MODULE	07/09/11	



**HOT AIR BLOWER
CONTROL MODULE**
9338-0320

© RAILWAY EQUIPMENT CO. 2011
RAILWAY EQUIPMENT CO.
 MINNEAPOLIS, MINNESOTA (763) 972-2800
 TITLE: GAS HOT AIR BLOWER
 3/5HP 240V 1 PHASE
 SCHEMATIC / CONNECTION DIAGRAM
 DWG NO. 9524-0223
 DRAWING BY: WS DRAWING SIZE: A SHEET: 1 OF 1

ITEM NO.	PART NO.	UOM	QTY	DESCRIPTION
1	952840	EA	1	BURNER, 12 INCH WELDED
2	53070	EA	1	FLAME ROD, REF AUBURN #FRS-4-7/8
3	56070	EA	1	SPARK IGNITOR, REF AUBURN #I-31-1
4	283181112	EA	4	BOLT, 3/8-16 X 3/4
5	2832-8904	EA	4	NUT, 3/8-16 CENTER LOCK
6	952103	EA	1	SUPPORT BRACKET 12 INCH BURNER
7	881402	FT	3.5	WIRE, 14GA HIGH TEMP
8	6033-0100	EA	1	LUG, RING #10 16-14GA HI-TEMP
9	6032-0112	EA	1	LUG, RING 1/4 16-14GA NYLON
10	2831411408	EA	1	SCREW, #10-32 X 1/2 PAN SLT SS
11	2832-4201	EA	2	NUT, #10-32 HEX SS
12	2833-4310	EA	2	WASHER, #10 EXT. STAR
13	61028	EA	1	UNION, 1 IN SCH 40 BLACK
14	61028	EA	1	NIPPLE, 1 X 4 IN SCH 40 BLACK



REV	EDA	RF	REVISION DESCRIPTION	DATE	APPROVED
B	004	RF	NEW BURNER	07/20/04	---
-	-	RJ	ADDED WIRE, NIPPLE & UNION	07/20/04	---

UNLESS OTHERWISE SPECIFIED:
DIMENSIONS IN INCHES
DIMENSIONS IN MILLIMETERS
TOLERANCES ARE AS SHOWN
DIMENSIONS ARE TO CENTER UNLESS NOTED OTHERWISE
DO NOT SCALE DRAWING

DRAWN: RPF
DATE: 12/23/03
MATERIAL: N/A
THE 1/2 INCH ALLOWANCE

© RAILWAY EQUIPMENT CO. 2003-2004
RAILWAY EQUIPMENT CO.
DELANO, MINNESOTA (763) 972-2200

TITLE: BURNER
12 INCH STAINLESS
(ASSEMBLY / B.O.M.)

DWG NO.: 9528-0135
SCALE: 1/2" DRAWING SIZE: B SHEET: 1 OF 1